OWNER'S MANUAL 2019







DEAR HUSQVARNA MOTORCYCLES CUSTOMER

Congratulations on your decision to purchase a Husqvarna motorcycle. You are now the owner of a state-ofthe-art sports motorcycle that will give you enormous pleasure if you service and maintain it properly.

We hope you enjoy riding this motorcycle!

Please enter the serial number of your vehicle below.

Chassis number (🕮 p. 14)	Stamp of dealer
Engine number (🕮 p. 14)	
Key number (p. 14)	

The Owner's Manual contained the latest information for this model series at the time of going to print. Slight deviations resulting from continuing development and design of the motorcycles can, however, not be completely excluded.

All specifications are non-binding. Husqvarna Motorcycles GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. Husqvarna Motorcycles accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2018 Husqvarna Motorcycles GmbH, Mattighofen Austria All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.



ISO 9001(12 100 6061)

Husqvarna Motorcycles applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard. Issued by: TÜV Management Service

Husqvarna Motorcycles GmbH Stallhofnerstraße 3 5230 Mattighofen, Austria

This document is valid for the following models:

FE 250 EU (F2103S4)

FE 250 AU (F2160S4)



1	MEAN	S OF REPRESENTATION	6		6.15	Idle speed adjusting screw	20
	1.1	Symbols used	6		6.16	Shift lever	
	1.2	Formats used			6.17	Foot brake lever	
					6.18	Side stand	
2	SAFET	Y ADVICE	7		6.19	Steering lock	
	2.1	Use definition – intended use	7		6.20	Locking the steering	
	2.2	Misuse			6.21	Unlocking the steering	23
	2.3	Safety advice		7	СОМВ	INATION INSTRUMENT	24
	2.4	Degrees of risk and symbols	7		7.1	Complementian in attraction and accomplished	0.4
	2.5	Tampering warning	8		7.1	Combination instrument overview	
	2.6	Safe operation	8		7.2	Activation	24
	2.7	Protective clothing	9		7.3	Message on the combination instrument	24
	2.8	Work rules	9		7.4		24
	2.9	Environment	9		7.4	Adjusting the combination instrument	2/
	2.10	Owner's Manual	9		7.5	Adjusting the kilometers or miles	
3	IMPOE	RTANT NOTES	10		7.6	Adjusting the clock	
3	IIVIFOF	TANT NOTES	. 10		7.7	Adjusting the service display	
	3.1	Manufacturer and implied warranty	. 10		7.8	Speed, time, and DST distance 1	
	3.2	Operating and auxiliary substances	. 10		7.9	Speed, time, and DST2 distance 2	
	3.3	Spare parts, accessories	. 10		7.10	AVG average speed, ART operating	20
	3.4	Service	. 10		7.10	hours, and ODO total distance	
	3.5	Figures	. 10			covered	28
	3.6	Customer service	. 11				
4	VIEW (OF VEHICLE	. 12	8	PREPA	RING FOR USE	29
	4.4	Viscos of colors for the factor of the facto	40		8.1	Advice on initially preparing for use	29
	4.1	View of vehicle, front left (example)	. 12		8.2	Running-in the engine	30
	4.2	View of vehicle, rear right (example)	12		8.3	Starting power of lithium-ion	
						batteries at low temperatures	31
5	SERIA	L NUMBERS	. 14		8.4	Preparing the vehicle for difficult	
	5.1	Chassis number	14			riding conditions	31
	5.2	Type label			8.5	Preparing vehicle for rides on dry	
	5.3	Key number			0.0	sand	32
	5.4	Engine number			8.6	Preparing vehicle for rides on wet	20
	5.5	Fork part number			0.7	sand	32
	5.6	Shock absorber article number			8.7	Preparing vehicle for rides on wet	22
					8.8	and muddy circuits Preparing vehicle for high	33
6	CONTI	ROLS	. 16		0.0	temperatures or slow riding	33
	6.1	Clutch lever	. 16		8.9	Preparing vehicle for low	00
	6.2	Hand brake lever	. 16		0.5	temperatures or snow	33
	6.3	Throttle grip	. 16			•	
	6.4	Kill switch	. 16	9	RIDING	INSTRUCTIONS	34
	6.5	Horn button	. 17		9.1	Checks and maintenance measures	
	6.6	Light switch	. 17			when preparing for use	34
	6.7	Turn signal switch	. 17		9.2	Starting the vehicle	
	6.8	Emergency OFF switch	. 17		9.3	Activating traction control	
	6.9	Electric starter button			9.4	Starting off	
	6.10	Combination switch	. 18		9.5	Shifting, riding	
	6.11	Indicator lamps overview			9.6	Braking	
	6.12	Opening the filler cap			9.7	Stopping, parking	
	6.13	Closing the filler cap			9.8	Transporting	
	6.14	Cold start button			9.9	Refueling	
						<u> </u>	

10	SERVIC	DE SCHEDULE	40			Checking the play of the steering	
	10.1	Additional information	40			head bearing	59
	10.2	Required work	40			Adjusting the steering head bearing	~~
	10.3	Recommended work				play 4	60
					12.13	Lubricating the steering head	0.1
11	IUNIN	G THE CHASSIS	43		40.44	bearing 4	
	11.1	Checking the basic chassis setting				Removing front fender	
		with the rider's weight	43			Installing front fender	
	11.2	Compression damping of the shock				Removing the shock absorber ⁴	
		absorber	43			Installing the shock absorber ⁴	
	11.3	Adjusting the low-speed				Removing the seat	
		compression damping of the shock			12.19	Mounting the seat	66
		absorber	43		12.20	Removing the air filter box cover	67
	11.4	Adjusting the high-speed			12.21	Installing the air filter box cover	67
		compression damping of the shock			12.22	Removing the air filter 4	67
		absorber	44		12.23	Installing the air filter 4	68
	11.5	Adjusting the rebound damping of			12.24	Cleaning the air filter and air filter	
		the shock absorber	45			box 4	68
	11.6	Measuring the rear wheel dimension			12.25	Sealing the air filter box 4	69
		unloaded	45		12.26	Removing the right side cover	69
	11.7	Checking the static sag of the			12.27	Installing the right side cover	70
		shock absorber	46			Removing the main silencer	
	11.8	Checking the riding sag of the				Installing the main silencer	
		shock absorber	46			Changing the glass fiber yarn filling	
	11.9	Adjusting the spring preload of the				in the main silencer	71
		shock absorber	47			Removing the fuel tank 4	
	11.10	Adjusting the riding sag 4				Installing the fuel tank 4	
	11.11	Checking the basic setting of the				Checking for chain dirt	
		fork	48			accumulation	75
	11 12	Adjusting the compression damping				Cleaning the chain	
		of the fork	49			Checking the chain tension	
	11.13	Adjusting the rebound damping of				Adjusting the chain tension	
		the fork	49			Checking the chain, rear sprocket,	′ ′
	11.14	Adjusting the spring preload of the	.0			engine sprocket, and chain guide	70
		fork	50			Checking the frame	
	11 15	Handlebar position				•	
		Adjusting the handlebar position 4				Checking the swingarm 4	
	11.10	Adjusting the natiolesal position 4	01			Checking throttle cable routing	
12	SERVIC	CE WORK ON THE CHASSIS	53			Checking the rubber grip	82
	12.1	Raising the motorcycle with a lift				Adjusting the basic position of the	00
	12.1	stand	53			clutch lever	83
	12.2	Removing the motorcycle from the	00			Checking/correcting the fluid level	
	12.2	lift stand	53			of the hydraulic clutch	83
	12.3	Bleeding the fork legs				Changing the hydraulic clutch	
			55			fluid 4	
	12.4	Cleaning the dust boots of the fork legs	E /			Removing the engine guard	
	10.5	9			12.46	Installing the engine guard	85
	12.5	Removing the fork protector		13	BRAKE	SYSTEM	86
	12.6	Installing the fork protector	55				-5
	12.7	Removing the fork legs 4				Adjusting the basic position of the	
	12.8	Installing the fork legs 4				hand brake lever	
	12.9	Removing the lower triple clamp 4				Checking the brake discs	
	12.10	Installing the lower triple clamp 🔦	57		13.3	Checking the front brake fluid level	87

	13.4	Adding front brake fluid 4 8		17.3	Adjusting the characteristic map of	
	13.5	Checking the front brake linings 8			the throttle response 4	
	13.6	Changing the front brake linings 4 8	9	17.4	Changing the mapping	
	13.7	Checking the free travel of foot		17.5	Adjusting the idle speed 4	. 121
	40.0	brake lever	1	17.6	Teaching the throttle valve	100
	13.8	Adjusting the basic position of the	0	477	position	. 122
	10.0	foot brake lever 4		17.7	Checking the basic position of the	100
	13.9	Checking the rear brake fluid level 9		17.0	shift lever	. 123
	13.10	Adding rear brake fluid 4		17.8	Adjusting the basic position of the	100
	13.11	Checking the rear brake linings 9			shift lever 4	. 123
	13.12	Changing the rear brake linings ⁴ 9	10	SERVI	CE WORK ON THE ENGINE	. 124
14	WHEE	LS, TIRES 9	7	18.1	Changing the fuel screen 4	124
	14.1	Removing the front wheel 4 9	7	18.2	Checking the engine oil level	. 125
	14.2	Installing the front wheel 4	8	18.3	Changing the engine oil and oil	
	14.3	Removing the rear wheel 4			filter, cleaning the oil screen 4	125
	14.4	Installing the rear wheel		18.4	Adding engine oil	. 128
	14.5	Checking the tire condition 10		CLEAN	IING, CARE	120
	14.6	Checking the tire air pressure 10	10	OLLAI	NING, OANE	. 123
	14.7	Checking spoke tension 10		19.1	Cleaning the motorcycle	. 129
				19.2	Checks and maintenance steps for	
15	ELECT	RICAL SYSTEM 10	3		winter operation	. 130
	15.1	Removing the battery 4 10		STORA	\GE	. 131
	15.2	Installing the battery 4 10		20.1	Storage	101
	15.3	Recharging the battery 4 10	4		•	
	15.4	Changing the main fuse 10	6	20.2	Preparing for use after storage	. 132
	15.5	Changing the fuses of individual	21	TROU	BLESHOOTING	133
	15.6	power consumers 10 Removing the headlight mask with	7 22	BLINK	CODE	136
	13.0	the headlight	9 23	TECHN	NICAL DATA	120
	15.7	Installing the headlight mask with	0 23	IECHI	NICAL DATA	. 130
	10.7	the headlight 10	9	23.1	Engine	. 138
	15.8	Changing the headlight bulb 11		23.2	Engine tightening torques	. 139
	15.9	Changing the turn signal bulb 11		23.3	Capacities	. 141
	15.10	Checking the headlight setting 11		23.3.1	Engine oil	. 141
	15.11	Adjusting the headlight range 11:		23.3.2	Coolant	
	15.12		-	23.3.3	Fuel	. 141
	10.12	instrument11	2	23.4	Chassis	. 141
	15.13	Diagnostics connector 11:		23.5	Electrical system	. 142
		_		23.6	Tires	. 142
16	COOL	NG SYSTEM 11	4	23.7	Fork	. 142
	16.1	Cooling system 11	4	23.8	Shock absorber	. 143
	16.2	Checking the antifreeze and		23.9	Chassis tightening torques	. 143
		coolant level11	4 24	SLIBST	TANCES	1/6
	16.3	Checking the coolant level 11	Z+	3063	TANCES	. 140
	16.4	Draining the coolant 4 11	0.5	AUXILI	ARY SUBSTANCES	. 148
	16.5	Refilling coolant 4		STANE	DARDS	149
17	TI INIINI	G THE ENGINE 11:				
17			8 27		OF SPECIAL TERMS	
	17.1	Checking the play in the throttle cable	28 8	LIST O	F ABBREVIATIONS	. 151
	17.2	Adjusting the play in the throttle	29	LIST O	F SYMBOLS	. 152
		cable 4 11	8	29.1	Yellow and orange symbols	. 152

29.2	Green and blue symbols	152
INDEX		153

1 MEANS OF REPRESENTATION

1.1 Symbols used

The meaning of specific symbols is described below.



Indicates an expected reaction (e.g. of a work step or a function).



Indicates an unexpected reaction (e.g. of a work step or a function).



All work marked with this symbol requires specialist knowledge and technical understanding. In the interests of your own safety, have these jobs performed by an authorized Husqvarna Motorcycles workshop. There, your motorcycle will be optimally cared for by specially trained experts using the specialist tools required.



Indicates a page reference (more information is provided on the specified page).



Indicates information with more details or tips.



Indicates the result of a testing step.



Indicates a voltage measurement.



Indicates a current measurement.



Indicates the end of an activity, including potential rework.

1.2 Formats used

The typographical formats used in this document are explained below.

Proprietary name Indicates a proprietary name.

Name[®] Indicates a protected name.

Brand™ Indicates a brand available on the open market.

Underlined terms Refer to technical details of the vehicle or indicate technical terms, which

are explained in the glossary.

2.1 Use definition – intended use

This vehicle is designed and built to withstand the normal stresses and strains of competitive use. This vehicle complies with the currently valid regulations and categories of the top international motorsport organizations.



Info

This vehicle is only authorized for operation on public roads in the homologated (restricted) version. The derestricted version of this vehicle must only be operated in closed off areas away from public highway traffic.

This vehicle is designed for use in offroad endurance competition, and not primarily for use in motocross.

2.2 Misuse

The vehicle must only be used as intended.

Dangers can arise for people, property and the environment through use not as intended.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Misuse also includes the use of operating and auxiliary fluids which do not meet the required specification for the respective use.

2.3 Safety advice

A number of safety instructions need to be followed to operate the product described safely. Therefore read this instruction and all further instructions included carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.



Info

Various information and warning labels are attached in prominent locations on the product described. Do not remove any information or warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.4 Degrees of risk and symbols



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.



Note

Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.5 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

- 1 The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
- 2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- 1 Removal or puncturing of the main silencer, baffles, header pipes or any other components which conduct exhaust gases.
- 2 Removal or puncturing of parts of the intake system.
- 3 Lack of proper maintenance.
- 4 Replacing moving part of the vehicle, or parts of the exhaust or intake system, with parts other than those specified by the manufacturer.

2.6 Safe operation



Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, shock absorber, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.

An appropriate driver's license is needed to ride the vehicle on public roads.

Have malfunctions that impair safety promptly eliminated by an authorized Husqvarna Motorcycles workshop. Adhere to the information and warning labels on the vehicle.

2.7 Protective clothing



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

In the interest of your own safety, Husqvarna Motorcycles recommends that you only operate the vehicle while wearing protective clothing.

2.8 Work rules

Special tools are necessary for certain tasks. The tools are not a component of the vehicle, but can be ordered using the number in parentheses. Example: bearing puller (15112017000)

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, seals, sealing rings, O-rings, pins, and lock washers).

In the case of certain screws, a thread locker (e.g. **Loctite**®) is required. Apply according to the manufacturer's instructions.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.

After completing a repair or service work, check the operating safety of the vehicle.

2.9 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.

Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

2.10 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and maintain your motorcycle. Only then will you find out how to customize the vehicle ideally for your own use and how you can protect yourself from injury.

Keep the Owner's Manual in an accessible place to enable you to refer to it as needed.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized Husqvarna Motorcycles dealer.

The Owner's Manual is an important component of the vehicle and must be handed over to the new owner if the vehicle is sold.

The Owner's Manual is also available for download from your authorized Husqvarna Motorcycles dealer and on the Husqvarna Motorcycles website.

International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.1 Manufacturer and implied warranty

The work prescribed in the service schedule must be carried out by an authorized Husqvarna Motorcycles workshop only and confirmed both in the customer's Service & Warranty Booklet and in the **Husqvarna Motorcycles Dealer.net**; otherwise, all warranty claims will be void. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the warranty.

Additional information on the manufacturer or implied warranty and the procedures involved can be found in the service booklet.

3.2 Operating and auxiliary substances



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

Do not allow fuel to enter the groundwater, the soil, or the sewage system.

Use operating and auxiliary substances in accordance with the Owner's Manual and specification.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by Husqvarna Motorcycles and have them installed by an authorized Husqvarna Motorcycles workshop. Husqvarna Motorcycles accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Your Husqvarna Motorcycles dealer will be glad to advise you.

The current **Husqvarna Motorcycles** accessories for your vehicle can be found on the Husqvarna Motorcycles website

International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. Incorrect adjustment and tuning of the engine and chassis can lead to damage and breakage of components. Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service. It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.

3.6 Customer service

Your authorized Husqvarna Motorcycles dealer will be happy to answer any questions you may have regarding your vehicle and Husqvarna Motorcycles.


A list of authorized Husqvarna Motorcycles dealers can be found on the Husqvarna Motorcycles website. International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

4.1 View of vehicle, front left (example)




- Hand brake lever (≅ p. 16)
- 2 Clutch lever (Pp. 16)
- 3 Filler cap
- 4 Air filter box cover
- **5** Side stand (≅ p. 21)
- 6 Engine number (🕮 p. 14)
- **7** Shift lever (≅ p. 21)

4.2 View of vehicle, rear right (example)




- Fork compression adjustment
- **2** Kill switch (♥ p. 16)
- 2 Horn button (🕮 p. 17)
- 2 Light switch (
 p. 17)
- 2 Turn signal switch (p. 17)
- 3 Emergency OFF switch (≅ p. 17)
- 4 Electric starter button (🕮 p. 18)
- **5** Throttle grip (🕮 p. 16)
- **6** Fork rebound adjustment
- Foot brake lever (p. 21)
- 8 Level viewer, engine oil
- 9 Shock absorber compression adjustment
- 10 Shock absorber rebound adjustment
- 1 Level viewer for brake fluid, rear

5.1 Chassis number




The chassis number **1** is stamped on the steering head on the right.

5.2 Type label




Type label 1 is fixed to the front of the steering head.

5.3 Key number




Key number **1** for the steering lock is stamped onto the lable on the key connector.

5.4 Engine number




Engine number **1** is embossed on the left side of the engine over the engine sprocket.

5.5 Fork part number




The fork part number 1 is stamped on the inner side of the fork

5.6 Shock absorber article number



Shock absorber article number 1 is stamped on the top of the shock absorber above the adjusting ring towards the engine side.


6.1 Clutch lever



Clutch lever 1 is fitted on the handlebar on the left.

The clutch is activated hydraulically and adjusts itself automatically.


6.2 Hand brake lever



The hand brake lever **1** is fitted on the right side of the handle-bar


The hand brake lever is used to activate the front brake.

6.3 Throttle grip



The throttle grip 1 is fitted on the right side of the handlebar.

6.4 Kill switch




Kill switch is fitted on the left side of the handlebar.

Possible states

- Kill switch

 in basic position the ignition circuit is closed in this position and the engine can be started.
- Kill switch ⊠ pressed the ignition circuit is open in this position, the engine goes out if it was running, or does not start if it was off.




The horn button **1** is fitted on the left side of the handlebar.

Possible states

- Horn button > in neutral position
- Horn button
 pressed the horn is actuated in this position.

6.6 Light switch




Light switch 1 is fitted on the left side of the handlebar.

Possible states

■ D	Low beam on – Light switch is in the central position. In this position, the low beam and tail light are switched on.
	High beam on – Light switch is turned to the left. In this position, the high beam and the tail light are switched on.

6.7 Turn signal switch



Turn signal switch
is fitted on the left side of the handlebar.

Possible states


	Turn signal off – The turn signal switch is in the central position.
4	Left turn signal, on – The turn signal switch is turned to the left.
•	Right turn signal, on – The turn signal switch is turned to the right.

6.8 Emergency OFF switch



The emergency OFF switch 1 is fitted on the right side of the handlebar.

Possible states



6.9 Electric starter button




The electric starter button **1** is fitted on the right side of the handlebar.

Possible states

- Electric starter button (3) in basic position
- Electric starter button ③ is pressed In this position, the electric starter is actuated.

6.10 Combination switch



The combination switch is fitted on the left side of the handlebar.

Possible states

1	STANDARD – STANDARD mapping is activated when LED 1 lights up.
1TC	STANDARD with TC – STANDARD mapping with traction control is activated when LED 1 and TC light up.
2	ADVANCED – ADVANCED mapping is activated, when LED 2 lights up.
2TC	ADVANCED with TC – ADVANCED mapping with traction control is activated when LED 2 and TC light up.



Warning

Voiding of the government approval for road use and the insurance coverage If the combination switch is installed, the vehicle's approval for road use is invalidated.

 Only operate the vehicle in closed-off areas remote from public road traffic if the combination switch is installed.


The engine characteristic can be changed using button **MAP** on the combination switch.

The traction control can also be activated via the combination switch.

6.11 Indicator lamps overview



Possible states



Turn signal indicator lamp flashes green – The turn signal is switched on.

6.12 Opening the filler cap



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



Note


Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Press release button **1**, turn the filler cap counterclockwise, and lift it off.

6.13 Closing the filler cap




Fit the filler cap and turn clockwise until release button locks in place.



Info

Route fuel tank breather hose 2 without kinks.

6.14 Cold start button



The cold start button **1** is fitted on the bottom of the throttle valve body.

The injection system extends the injection time if the engine is cold and the outside temperature is low. To help the engine burn the increased amount of fuel, it must be supplied with additional oxygen by pushing the cold start button.

After briefly opening up the throttle and then releasing the throttle grip again, or turning the throttle grip towards the front, the cold start button returns to its original position.




Info

Check whether the cold start button has returned to its basic position.

Possible states

- The cold start button is activated The cold start button is pushed in all the way.
- The cold start button is deactivated The cold start button is in its basic position.

6.15 Idle speed adjusting screw



The idle setting of the throttle valve body has a big influence on the vehicle's starting behavior, on stable idling, and on vehicle response when the throttle is opened.


An engine with a correctly set idle speed is easier to start than an engine with the idle speed set incorrectly.

The idle speed is adjusted using the idle speed adjusting screw **1**.


Increase the idle speed by turning the idle speed adjusting screw clockwise.

Decrease the idle speed by turning the idle speed adjusting screw counterclockwise.

6.16 Shift lever




The shift lever **1** is fitted on the left side of the engine.



The gear positions can be seen in the photograph.


The neutral or idle position is between the first and second gears.

6.17 Foot brake lever




The foot brake lever **1** is attached in front of the right footrest. The foot brake lever is used to activate the rear brake.

6.18 Side stand



The side stand 1 is attached to the left side of the vehicle.



The side stand is used for parking the motorcycle.



Info

When you are riding, side stand 1 must be folded up and secured with rubber band 2.

6.19 Steering lock




Steering lock is fitted on the left side of the steering head. The steering lock is used to lock the steering. Steering, and therefore riding, is no longer possible.

6.20 Locking the steering

Note

Danger of damage The parked vehicle can roll away or fall over.

Park the vehicle on a firm and level surface.



- Park the vehicle.
- Turn the handlebar as far as possible to the right.
- Grease steering lock regularly.

Universal oil spray (🕮 p. 148)


- Insert the key in the <u>steering lock</u> (
 p. 22), turn it to the left, press it in, and turn it to the right. Remove the key.
 - Steering is no longer possible.



Info

Never leave the key in the steering lock.

6.21 Unlocking the steering




- Insert the key in the <u>steering lock</u> (p. 22), turn it to the left, pull it out, and turn it to the right. Remove the key.
 - ✓ You can now steer the bike again.

i

Info


Never leave the key in the steering lock.

7.1 Combination instrument overview



- 1 Indicator lamps overview (🕮 p. 18)
- 2 Left button
- 3 Display
- 4 Right button


7.2 Activation




Activating combination instrument

The combination instrument is activated when one of the buttons is pressed or an impulse comes from the wheel speed sensor.

7.3 Message on the combination instrument



Possible states






Service – A service is due. Contact an authorized Husqvarna Motorcycles workshop.


7.4 Adjusting the combination instrument


Condition

The motorcycle is stationary.




- Press and hold both buttons for 3 5 seconds.
 - ✓ The Setup menu is displayed. The UNIT display flashes.
- Press one of the buttons to select UNIT for the speed in kilometers KM/H or miles M/H.





- ✓ Combination instrument changes to the next menu item. The ⊖ symbol flashes.
- Press one of the buttons to select the 24h or 12h display of the clock.



- Wait for 5 seconds.
 - ✓ Combination instrument changes to the next menu item. The ⊖ symbol flashes.

Resetting the time

- Press the left button.
 - The value decreases.

Advancing the time

- Press the right button.
 - ✓ The value increases.



- Wait for 5 seconds.
 - ✓ Combination instrument changes to the next menu item.
- Adjust the service.

Guideline

One-time service after	1 h
Service every	15 h

Shortening the service interval

- Press the left button.
 - The value decreases.


Extending the service interval


- Press the right button.
 - The value increases.



401913-01

Press and hold the left button.






7.5 Adjusting the kilometers or miles



Info

If the unit is changed, the value **ODO** is retained and converted accordingly.



Condition


The motorcycle is stationary.

- Press and hold both buttons for 3 5 seconds.
 - ✓ The Setup menu is displayed. The UNIT display flashes.
- Press one of the buttons to select UNIT for the speed in kilometers KM/H or miles M/H.


7.6 Adjusting the clock

Condition

The motorcycle is stationary.



- $\checkmark \hspace{0.1in}$ The Setup menu is displayed. The UNIT display flashes.
- Wait for the menu of the clock ⊙ to flash.
- Press one of the buttons to select the 24h or 12h display of the clock.



- Wait for 5 seconds.
 - ✓ Combination instrument changes to the next menu item. The ⊗ symbol flashes.

Resetting the time

- Press the left button.
 - The value decreases.


Advancing the time

401912-01

- Press the right button.
 - The value increases.

•

7.7 Adjusting the service display



Condition

The motorcycle is stationary.

- Press and hold both buttons for 3 5 seconds.
 - ✓ The Setup menu is displayed. The UNIT display flashes.
- Wait for the menu of the service display

 to flash.
- Adjust the service.

Guideline


One-time service after	1 h
Service every	15 h

Shortening the service interval


- Press the left button.
 - The value decreases.

Extending the service interval


- Press the right button.
 - ✓ The value increases.



- Press and hold the left button.
 - ✓ off appears on the display.



7.8 Speed, time, and DST distance 1



Press one of the buttons until **DST** appears on the combination instrument.

KM/H or M/H shows the speed.

 Θ shows the time.

DST shows the distance since the last reset, such as between two refueling stops.




Info

If the value of 39999.9 is exceeded, **DST** is automatically reset to 0.0.

Press the left button briefly.	Next display mode
Press the left button for 3 – 5 seconds.	DST can be preset to a value between 0.0 and 39999.9 by pressing the buttons.
Press the right button briefly.	Next display mode

Press the	DST is reset to 0.0.
right button	
for 3 – 5 sec-	
onds.	

7.9 Speed, time, and DST2 distance 2



Press one of the buttons until **DST2** appears on the combination instrument.

KM/H or M/H shows the speed.

Ø shows the time.

DST2 shows the distance 2 since the last reset, such as between two refueling stops.




Info

If the value of 39999.9 is exceeded, **DST2** is automatically reset to 0.0.

Press the left button briefly.	Next display mode
Press the left button for 3 – 5 seconds.	DST2 can be preset to a value between 0.0 and 39999.9 by pressing the buttons.
Press the right button briefly.	Next display mode
Press the right button for 3 – 5 seconds.	DST2 is reset to 0.0.

7.10 AVG average speed, ART operating hours, and ODO total distance covered



 Press one of the buttons until AVG, ART and ODO appear on the combination instrument.

AVG shows the average speed since the last reset.

ART shows the operating hours.

ODO shows the total distance covered.

Press the left button briefly.	Next display mode
Press the left button for 3 – 5 seconds.	The OPEN END WRENCH SYMBOL shows the remaining operating hours until the next service is due.
Press the right button briefly.	Next display mode
Press the right button for 3 – 5 seconds.	AVG is reset to 0.0.

8.1 Advice on initially preparing for use



Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

- Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
- Do not operate the vehicle if you are physically or mentally impaired.



Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.



Warning

Danger of crashing Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

- Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.



Warning

Danger of accidents An unadapted riding style impairs the handling characteristic.

- Adapt your riding speed to the road conditions and your riding ability.



Warning

Danger of accidents The vehicle is not designed to carry passengers.

- Do not ride with a passenger.



Warning

Danger of accidents The brake system fails in the event of overheating.

If the foot brake lever is not released, the brake linings drag continuously.

Take your foot off the foot brake lever when you are not braking.



Warning

Danger of accidents Total weight and axle loads influence the handling characteristic.

- Do not exceed the maximum permissible overall weight or the axle loads.



Warning

Risk of misappropriation People who act without authorization endanger themselves and others.

- Do not leave the vehicle unattended if the engine is running.
- Protect the vehicle against access by unauthorized persons.



Info

When using your motorcycle, remember that others may feel disturbed by excessive noise.

- Make sure that the pre-delivery inspection work has been carried out by an authorized Husqvarna Motorcycles workshop.
 - ✓ You receive a delivery certificate and the Service and Warranty Booklet at vehicle handover.
- Before your first trip, read the entire Owner's Manual carefully.
- Get to know the controls.

- Adjust the basic position of the hand brake lever. (p. 86)
- Adjust the basic position of the foot brake lever. ♣ (₱ p. 92)
- Set the basic position of the shift lever. 4 (
 p. 123)
- Get used to handling the motorcycle on a suitable surface before undertaking a more challenging trip.



Info

When off road, it is recommended that you are accompanied by another person on another vehicle so that you can help each other.

- Try also to ride as slowly as possible and in a standing position to get a better feeling for the motorcycle.
- Do not make any off-road trips that exceed your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
- If you carry any luggage, make sure you fix it firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.



Info

Motorcycles react sensitively to any changes of weight distribution.

Do not exceed maximum permissible weight and maximum permissible axle loads.
 Guideline

Maximum permissible overall weight	335 kg (739 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)



Info

The spoke tension must be checked after half an hour of operation.

Run in the engine. (
 p. 30)


8.2 Running-in the engine

During the running-in phase, do not exceed the specified engine speed and engine performance.
 Guideline

Maximum engine speed		
During the first operating hour	7,000 rpm	
Maximum engine performance		
During the first 3 operating hours	≤ 75 %	

- Avoid fully opening the throttle!

8.3 Starting power of lithium-ion batteries at low temperatures



Lithium-ion batteries are far lighter than lead batteries, have a low self-discharge rate, and have more starting power at temperatures over 15 °C (60 °F). At low temperatures, however, the starting power of lithium-ion batteries drops to below that of lead batteries.

Multiple starting attempts may be needed. Press the electric starter button for 5 seconds, and wait 30 seconds between attempts. The pauses are necessary so that the created heat can distribute through the lithium-ion battery and the battery is not damaged.

If the charged lithium-ion battery does not or only weakly turns over the electric starter when temperatures are below 15 °C (60 °F), then the battery is not faulty, but needs to be warmed up internally to increase its starting power (current output). The starting power increases as the battery warms up.

8.4 Preparing the vehicle for difficult riding conditions



Info

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can lead to considerably more rapid wear of components such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

Clean the air filter and air filter box. 4 (
 p. 68)



Info

Check the air filter approx. every 30 minutes.

- Seal the air filter box. ♣ (♥ p. 69)
- Check the connector for humidity and corrosion and to ensure it is firmly seated.
 - » If humidity, corrosion, or damage is found:
 - Clean and dry the connector, or change it if necessary.

Difficult riding conditions are:

- Rides on dry sand. (@ p. 32)
- Rides on wet sand. (p. 32)
- Rides on wet and muddy circuits. (@ p. 33)
- Rides at high temperatures or slow riding. (p. 33)
- Riding at low temperatures and in snow. (□ p. 33)

8.5 Preparing vehicle for rides on dry sand



Mount a dust cover on the air filter.

Dust cover for air filter (79006920000)



Info

Read the fitting instructions for **Husqvarna Motorcy**cles accessories.



Mount a sand cover on the air filter.

Sand cover for air filter (79006922000)



Info

Read the fitting instructions for **Husqvarna Motorcy**cles accessories.



- Clean the chain.
- Mount the steel sprocket.
- Grease the chain.

Universal oil spray (
p. 148)

- Clean the radiator fins.
- Straighten bent radiator fins carefully.

8.6 Preparing vehicle for rides on wet sand



Fit a rain cover on the air filter.

Waterproofing device for air filter (79006921000)



Info

Read the fitting instructions for **Husqvarna Motorcycles** accessories.



- Clean the chain.
- Mount the steel sprocket.
- Grease the chain.

Universal oil spray (🕮 p. 148)

- Clean the radiator fins.
- Straighten bent radiator fins carefully.

8.7 Preparing vehicle for rides on wet and muddy circuits



- Fit a rain cover on the air filter.

Waterproofing device for air filter (79006921000)



Info

Read the fitting instructions for **Husqvarna Motorcy**cles accessories.



- Mount the steel sprocket.
- Clean the motorcycle. (
 p. 129)
- Straighten bent radiator fins carefully.

8.8 Preparing vehicle for high temperatures or slow riding



- Adjust the secondary drive to the road conditions.



Info

The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary ratio.

- Clean the chain.

Chain cleaner (p. 148)

- Clean the radiator fins.
- Straighten bent radiator fins carefully.

8.9 Preparing vehicle for low temperatures or snow



Fit a rain cover on the air filter.

Waterproofing device for air filter (79006921000)



Info


Read the fitting instructions for **Husqvarna Motorcy**cles accessories.

9.1 Checks and maintenance measures when preparing for use



Info

Before every trip, check the condition of the vehicle and ensure that it is safe to operate. The vehicle must be in perfect technical condition when it is being operated.



- Check the electrical system.
- Check the rear brake fluid level. (p. 92)
- Check the rear brake linings. (🕮 p. 94)
- Check that the brake system is functioning properly.
- Check the coolant level. (p. 115)
- Check the chain, rear sprocket, engine sprocket, and chain guide. (
 p. 78)
- Check the chain tension. (Fig. 76)
- Check the tire condition. (p. 101)
- Check the spoke tension. (₽ p. 102)



Info

The spoke tension must be checked regularly as incorrect spoke tension will strongly impair riding safety.

- Clean the dust boots of the fork legs. (p. 54)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts, and hose clips regularly for tightness.
- Check the fuel level.

•

9.2 Starting the vehicle



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.


- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.

Note

Engine damage High revving speed with a cold engine negatively impacts the lifespan of the engine.

Always run the engine warm at a low speed.








- stand with rubber band **2**. Shift transmission to neutral.
- Turn the emergency OFF switch to the position \bigcirc .

Take the motorcycle off side stand 1 and secure the side

Ambient temperature: < 20 °C (< 68 °F)

- Push the cold start button in all the way.
- Press the electric starter button.





Info

Press the electric starter button for a maximum of 5 seconds. Wait for 30 seconds before a further attempt at starting.

At temperatures below 15 °C (60 °F), several attempts at starting may be necessary to warm-up the lithiumion battery and thereby increase the starting power. During the starting process, the malfunction indicator lamp lights up.

9.3 **Activating traction control**



Warning

Voiding of the government approval for road use and the insurance coverage If the combination switch is installed, the vehicle's approval for road use is invalidated.

Only operate the vehicle in closed-off areas remote from public road traffic if the combination switch is installed.




The traction control reduces excessive slip on the rear wheel in favor of more control and propulsion, particularly in wet conditions.

When traction control is switched off, the rear wheel may spin more during high acceleration and on surfaces with low grip.

Traction control can be switched on or off during the ride.

The setting most recently selected is activated again when restarting.



Press button TC to switch the traction control on or off. Guideline

Engine speed ≤ 4,000 rpm

The TC LED lights up when the traction control is activated.

9.4 Starting off



Info

While riding, the side stand must be folded up and secured with the rubber band.

 Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time open the throttle gently.

4

9.5 Shifting, riding



Warning

Danger of accidents If you change down at high engine speed, the rear wheel blocks and the engine races.

Do not change into a low gear at high engine speed.

i

Info

If unusual noises occur while riding, stop immediately, switch off the engine, and contact an authorized Husqvarna Motorcycles workshop.

First gear is used for starting off and for steep inclines.

- Shift into a higher gear when conditions allow (incline, road situation, etc.). To do so, release the throttle
 while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the
 throttle.
- After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is ¾ open. This
 will barely reduce the speed but fuel consumption will be considerably lower.
- Always open the throttle only as much as the engine can handle abrupt throttle opening increases fuel consumption.
- To shift down, apply the brakes and close the throttle at the same time.
- Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
- Switch off the engine if running at idle or standing for a long time.

Guideline

≥ 2 min

- Avoid frequent and longer slipping of the clutch. As a result the engine oil, engine and cooling system heat up.
- Ride at a low engine speed instead of at a high engine speed with a slipping clutch.

•

9.6 Braking



Warning

Danger of accidents Excessively forceful application of the brakes blocks the wheels.

Adjust application of the brakes to the respective riding situation and riding surface conditions.



Warning

Danger of accidents A spongy pressure point on the front or rear brake reduces braking efficiency.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.
- On sandy, wet or slippery surfaces, use the rear brake.
- Braking should always be completed before you go into a bend. Change down to a lower gear appropriate to your road speed.
- Make use of the braking effect of the engine when driving down long downhill stretches. To do so, shift back one or two gears, but do not overrev the engine. You will need to apply the brakes far less often and the brake system will not overheat.

9.7 Stopping, parking



Warning

Risk of misappropriation People who act without authorization endanger themselves and others.

- Do not leave the vehicle unattended if the engine is running.
- Protect the vehicle against access by unauthorized persons.



Warning

Danger of burns Some vehicle components become very hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, shock absorber, or brake system before the vehicle parts have cooled down.
- Let the vehicle parts cool down before you perform any work on the vehicle.

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

- Park the vehicle on a firm and level surface.
- Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.
- Apply the brakes on the motorcycle.
- Shift transmission to neutral.
- Press and hold the kill switch ⋈ while the engine is idling until the engine stops.
- Park the motorcycle on firm ground.

•

9.8 Transporting

Note


Danger of damage The parked vehicle can roll away or fall over.

Park the vehicle on a firm and level surface.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

- Do not park the vehicle near to materials which are highly flammable or explosive.
- Allow the vehicle to cool down before covering it.



- Switch off the engine.
- Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.

9.9 Refueling



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.

Note

Material damage Inadequate fuel quality causes the fuel filter to quickly become clogged.

In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system.


 Refuel only with clean fuel that meets the specified standards. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off engine.
- Open the filler cap. (≅ p. 19)
- Fill the fuel tank with fuel up to measurement A.
 Guideline

Measurement of (A)	35 mm (1.38 in)
Super unleaded (ROZ 95/RON 95/PON 91) (🕮 p. 147)	N	8.5 I (2.25 US gal)

- Close the filler cap. (
p. 19)

•

10.1 Additional information

Any further work that results from the compulsory work or from the recommended work must be ordered separately and invoiced separately.

Different service intervals may apply in your country, depending on the local operating conditions. Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule can always be found on Husqvarna Motorcycles Dealer.net. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

10.2 Required work

Every 10 operating hours when used for motorsports					
Every 45	ope	ratin	g ho	urs	
Every 30 ope	ratin	g ho	urs		
Every 15 operatir	ng ho	urs			
Once after 1 operating h	nour				
Read out the fault memory using the Husqvarna Motorcycles diagnostics tool.	0	•	•	•	•
Check that the electrical system is functioning properly.	0	•	•	•	•
Check and charge the battery.		•	•	•	•
Check the front brake linings. (🕮 p. 88)		•	•	•	•
Check the rear brake linings. (🕮 p. 94)		•	•	•	•
Check the brake discs. (p. 86)		•	•	•	•
Check the brake lines for damage and leakage.		•	•	•	•
Check the rear brake fluid level. (🕮 p. 92)		•	•	•	•
Check the free travel of the foot brake lever. (p. 91)		•	•	•	•
Check the frame.		•	•	•	•
Check the swingarm. ◀ (興 p. 81)		•	•	•	•
Check the swingarm bearing for play. ❖			•		
Check the heim joint for play. ◀			•	•	
Check the shock absorber linkage. ◀		•	•		
Check the tire condition. (@ p. 101)	0	•	•	•	•
Check the tire air pressure. (p. 101)		•	•	•	•
Check the wheel bearing for play. ◀		•	•	•	•
Check the wheel hubs. ◀		•	•	•	•
Check the rim run-out. ⁴	0	•	•	•	
Check the spoke tension. (B) p. 102)	0	•	•	•	•
Check the chain, rear sprocket, engine sprocket, and chain guide. (p. 78)		•	•	•	•
Check the chain tension. (p. 76)	0	•	•	•	•
Grease all moving parts (e.g. side stand, hand lever, chain, etc.) and check for smooth operation.		•	•	•	•
Check/correct the fluid level of the hydraulic clutch. (p. 83)		•	•	•	•
Check the front brake fluid level. (@ p. 87)		•	•	•	•
Check the free travel of the hand brake lever.		•	•	•	•
Check the play of the steering head bearing. (@ p. 59)	0	•	•	•	
Check the valve clearance.	0		•		
Check the clutch. ⁴			•		•
Change the cover seal and shaft seal rings of the water pump.			•		
Change the engine oil and oil filter, clean the oil screen. ♣ (🕮 p. 125)	0	•	•	•	•

- One-time interval
- Periodic interval

10.3 Recommended work

			Α	nnu	ally
Every 135	opeı	atin	g ho	urs	
Every 70 operating hours when used for a	moto	rspo	orts		
Once after 20 operating	ıg ho	urs			
Once after 10 operating ho	ours				
Change the front brake fluid. ◀					•
Change the rear brake fluid. ⁴					•
Change the hydraulic clutch fluid. ◄ (의 p. 84)					•
Lubricate the steering head bearing. ◄ (의 p. 61)					•
Service the fork.	0				
Perform the shock absorber service.		0			
Change the fuel filter.				•	

			Α	nnu	ally
Every 135	oper	ating	g ho	urs	
Every 70 operating hours when used for r	noto	rspo	rts		
Once after 20 operatin	g ho	urs			
Once after 10 operating ho	urs				
Perform engine service including removing and installing the engine. (Change the spark plug and spark plug connector. Change the piston. Check/measure the cylinder. Check the cylinder head. Change the valves, valve springs, and valve spring seats. Check the camshaft and cam lever. Change the connecting rod, conrod bearing, and crank pin. Change the shaft seal rings of the water pump. Check the transmission and shift mechanism. Check the oil pressure regulator valve. Change the suction pump. Check the force pump and lubrication system. Check the timing assembly. Change the timing chain. Change all engine bearings. Change the freewheel.)			•	•	


- One-time interval
- Periodic interval

11.1 Checking the basic chassis setting with the rider's weight

i

Info

When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, Husqvarna motorcycles are adjusted for an average rider's weight (with full protective clothing).
 Guideline

Standard rider weight	75 85 kg (165 187 lb.)
-----------------------	------------------------

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

11.2 Compression damping of the shock absorber

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed. High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.

The high-speed setting, for example, has an effect on the landing after a jump: the rear wheel suspension compresses quickly.

The low-speed setting, for example, has an effect when riding over long ground swells: the rear wheel suspension compresses slowly.

These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

11.3 Adjusting the low-speed compression damping of the shock absorber



Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.


The shock absorber is filled with highly compressed nitrogen.

 Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

The effect of the low-speed setting can be seen in slow to normal compression of the shock absorber.



 Turn adjusting screw clockwise with a screwdriver as far as the last perceptible click.



Info

Do not loosen fitting 2!

 Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Compression damping, low-speed		
Comfort	17 clicks	
Standard	15 clicks	
Sport	13 clicks	



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

11.4 Adjusting the high-speed compression damping of the shock absorber



Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.


The shock absorber is filled with highly compressed nitrogen.

 Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

The effect of the high-speed setting can be seen in fast compression of the shock absorber.



Using an open end wrench, turn adjusting screw clockwise all the way.



Info

Do not loosen fitting **2**!

Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

Compression damping, high-s	speed			
Comfort	2.5 turns			
Standard	2 turns			
Sport	1.5 turns			



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

•

11.5 Adjusting the rebound damping of the shock absorber




Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.

Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Turn adjusting screw 1 clockwise up to the last perceptible
- Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

11.6 Measuring the rear wheel dimension unloaded



Raise the motorcycle with a lift stand. (
p. 53)


Main work

Position the sag gauge in the rear axle and measure the distance to marking SAG on the rear fender.

Sag gauge (00029090500)
Pin for sag gauge (00029990010)

Note down the value as dimension A.






Finishing work

Remove the motorcycle from the lift stand. (p. 53)

11.7 Checking the static sag of the shock absorber



- Hold the motorcycle upright with the aid of an assistant.
- Again measure the distance between the rear axle and marking SAG on the rear fender using the sag gauge.
- Note down the value as dimension **B**.



Info


The static sag is the difference between measurements $\bf A$ and $\bf B$.

- Check the static sag.

Static sag 35 mm (1.38 in)

- » If the static sag is less or more than the specified value:
 - Adjust the spring preload of the shock absorber.
 p. 47)

11.8 Checking the riding sag of the shock absorber



- Measure dimension (A) of rear wheel unloaded. (p. 45)
- With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
 - ✓ The rear wheel suspension levels out.
- Another person again measures the distance between the rear axle and marking SAG on the rear fender using the sag gauge.
- Note down the value as dimension **(6)**.



Info

The riding sag is the difference between measurements $oldsymbol{A}$ and $oldsymbol{G}$.

Check the riding sag.

Guideline

Riding sag 110 mm (4.33 in)

- » If the riding sag differs from the specified measurement:
 - Adjust the riding sag. ⁴ (≅ p. 48)

11.9 Adjusting the spring preload of the shock absorber &



Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.

Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Info

Before changing the spring preload, make a note of the present setting, e.g., by measuring the spring

Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)
- Remove the shock absorber. 4 (p. 62)
- After removing the shock absorber, clean it thoroughly.



- Loosen screw 1.
- Turn adjusting ring 2 until the spring is no longer under ten-

Holding wrench (90129051000)

- Measure the overall spring length while the spring is not under tension.
- Tighten the spring by turning adjusting ring 2 to specified measurement A.

Guideline

Spring preload 14 mm (0.55 in)



Info

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

Tighten screw 1.



Guideline

402659-10

Screw, shock	M5	5 Nm (3.7 lbf ft)
absorber adjusting		
ring		

Finishing work

- Install the shock absorber. 📤 (🕮 p. 64)
- Check the free travel of the foot brake lever. (p. 91)
- Remove the motorcycle from the lift stand. (p. 53)

11.10 Adjusting the riding sag 4

Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)
- Remove the shock absorber. ⁴ (≅ p. 62)
- After removing the shock absorber, clean it thoroughly.



Main wor

Choose and mount a suitable spring.

Guideline

Spring rate		
Weight of rider: 65 75 kg (143 165 lb.)	45 N/mm (257 lb/in)	
,	40.11/ (07.4 !! /;)	
Weight of rider: 75 85 kg (165 187 lb.)	48 N/mm (274 lb/in)	
	54 N/((004 H- /i)	
Weight of rider: 85 95 kg (187 209 lb.)	51 N/mm (291 lb/in)	



B00292-10

Info

The spring rate is shown on the outside of the spring. Smaller weight differences can be compensated by changing the spring preload.

Finishing work

- Install the shock absorber. ◄ (


 p. 64)
- Remove the motorcycle from the lift stand. (
 p. 53)
- Check the riding sag of the shock absorber. (🗐 p. 46)

11.11 Checking the basic setting of the fork



Info

For various reasons, no exact riding sag can be determined for the fork.



- As with the shock absorber, smaller differences in the rider's weight can be compensated by the spring preload.
- However, if the fork frequently bottoms out (hard end stop on compression), harder springs must be fitted to avoid damage to the fork and frame.
- If the fork feels unusually hard after extended periods of operation, the fork legs need to be bled.

•

11.12 Adjusting the compression damping of the fork

i

Info

The hydraulic compression damping determines the fork suspension behavior.



- Turn white adjusting screw 1 clockwise as far as it will go.

Info

Adjusting screw 1 is located at the upper end of the left fork leg.

The compression damping is located in left fork leg **COM** (white adjusting screw). The rebound damping is located in right fork leg **REB** (red adjusting screw).

 Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Compression damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

11.13 Adjusting the rebound damping of the fork



Info

The hydraulic rebound damping determines the fork suspension behavior.



- Turn red adjusting screw 1 clockwise as far as it will go.



Info

Adjusting screw 1 is located at the upper end of the right fork leg.

The rebound damping is located in right fork leg **REB** (red adjusting screw). The compression damping is located in left fork leg **COM** (white adjusting screw).

Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

11.14 Adjusting the spring preload of the fork

Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)

Main work

- Turn the adjusting wings 1 counterclockwise all the way.
 - The marking +0 aligns with the adjusting wing on both fork legs.



Info

Make the adjustment by hand only. Do not use a tool. Make the same adjustment on both fork legs.

- Turn the adjusting wings clockwise.

Guideline

Spring preload - Preload Adjuster	
Comfort	+0
Standard	+0
Sport	+3

✓ The adjusting wings engage noticeably at the numerical values.



Info

Adjust the spring preload to the numerical values only as the preload will not engage between the numerical values.


Turn clockwise to increase the spring preload; turn counterclockwise to reduce the spring preload. Adjusting the spring preload has no influence on the absorption setting of the rebound.

Basically, however, you should set the rebound damping higher with a higher spring preload.

Finishing work

Remove the motorcycle from the lift stand. (
 p. 53)

11.15 Handlebar position



On the upper triple clamp, there are two holes at a distance of **A** to each other.

Hole distance A 15 mm (0.59 in)

The holes on the handlebar supports are placed at a distance of **B** from the center.

3.5 mm (0.138 in) Hole distance **B**

The handlebar supports can be mounted in four different positions.

11.16 Adjusting the handlebar position 4




Warning

Danger of accidents A repaired handlebar poses a safety risk.

If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

Change the handlebar if the handlebar is damaged or bent.



Remove screws 1. Take off the handlebar clamps. Take off the handlebar and lay it to one side.



Cover the components to protect them against dam-

Do not bend the cables and lines.

- Remove screws 2. Take off the handlebar supports.
- Place the handlebar supports in the required position. Mount and tighten screws 2.

Guideline

Screw, handle-	M10	40 Nm (29.5 lbf ft)
bar holder		Loctite [®] 243™



Position the left and right handlebar holders evenly.

Position the handlebar.



Make sure the cables and wiring are positioned cor-

Position the handlebar clamps. Mount and tighten screws 1 evenly.



Guideline


Screw, handlebar	M8	20 Nm (14.8 lbf ft)
clamp		



Info

Make sure the gap width is even.

12.1 Raising the motorcycle with a lift stand



Note

Danger of damage The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.
- Raise the motorcycle at the frame underneath the engine.

Lift stand (81329955100)


- ✓ Neither wheel is in contact with the ground.
- Secure the motorcycle against falling over.

12.2 Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle can roll away or fall over.

- Park the vehicle on a firm and level surface.




- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, press side stand 1 to the ground with your foot and lean the motorcycle on it.



Info

When you are riding, the side stand must be folded up and secured with the rubber band.

12.3 Bleeding the fork legs



Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)

Main work

- Release bleeder screws 1.
 - Any excess pressure escapes from the interior of the fork.
- Tighten the bleeder screws.

Finishing work

402556-10

- Remove the motorcycle from the lift stand. (🕮 p. 53)

12.4 Cleaning the dust boots of the fork legs



Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)
- Remove the fork protector. (🕮 p. 54)

Main work

Push dust boots 1 of both fork legs downward.



Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.
- Clean and oil the dust boots and inner fork tubes of both fork leas.


Universal oil spray (🕮 p. 148)

- Press the dust boots back into their installation position.
- Remove excess oil.

Finishing work


- Install the fork protector. (
 p. 55)
- Remove the motorcycle from the lift stand. (
 p. 53)

12.5 Removing the fork protector



- Remove screws 1 and take off the clamp.
- Remove screws 2 on the left fork leg and take off the left fork protector.
- Remove screws 3 on the right fork leg and take off the right fork protector.

12.6 Installing the fork protector



 Position the fork protector on the left fork leg. Mount and tighten screws ①.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

- Position the brake line, wiring harness, and clamp. Mount and tighten screws 2.
- Position the fork protector on the right fork leg. Mount and tighten screws 3.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		


12.7 Removing the fork legs 4

Preparatory work

- Raise the motorcycle with a lift stand. (
 p. 53)
- Remove the front wheel. ♣ (₱ p. 97)


Main work

- Remove screws 1 and take off the clamp.
- Remove the cable tie.
- Remove screws 2 and take off the brake caliper.
- Allow the brake caliper and brake line to hang loosely to the side.




- 3 4
- Loosen screws 3. Remove the left fork leg.
- Loosen screws 4. Remove the right fork leg.

12.8 Installing the fork legs 4



Main work

Position the fork legs.






Info

The compression damping is located in left fork leg **COM** (white adjusting screw). The rebound damping is located in right fork leg **REB** (red adjusting screw).

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.



Tighten screws 2.


Guideline

Screw, top triple	M8	17 Nm (12.5 lbf ft)
clamp		

Tighten screws 3.

Guideline

Screw, bottom triple	M8	15 Nm (11.1 lbf ft)
clamp		



Position the brake caliper, and mount and tighten screws 4.
 Guideline

Screw, front	M8	25 Nm (18.4 lbf ft)
brake caliper		Loctite [®] 243™

- Mount the cable tie(s).
- Position the brake line, wiring harness, and clamp. Mount and tighten screws 5.

Finishing work


- Install the front wheel. ♣ (♥ p. 98)
- Install the headlight mask with the headlight. (
 p. 109)
- Check the headlight setting. (Fig. 111)

12.9 Removing the lower triple clamp 4

Preparatory work


- Remove the headlight mask with the headlight. (₱ p. 109)
- Raise the motorcycle with a lift stand. (
 p. 53)
- Remove the front wheel. ♣ (

 p. 97)
- Remove the fork legs. ◀ (學 p. 55)
- Remove front fender. (p. 61)
- Remove the handlebar cushion.



Main work

- Open the cable holder in front of the right radiator and detach the wiring harness.
- Remove screws 1 and hang the voltage regulator to the
- Open the cable holder in front of the left radiator and detach the wiring harness.




- Remove screw 2.
 - Remove screw 3.
- Take off the upper triple clamp with the handlebar and set it aside.



Info

Cover the components to protect them against dam-


Do not kink the cables and lines.



- Remove O-ring 4 and protective ring 5.
- Take off the lower triple clamp with the steering stem.
- Remove the upper steering head bearing.



12.10 Installing the lower triple clamp &



Main work


Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (


p. 148)

- Position the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Check whether upper steering head seal
 is correctly positioned.
- Mount protective ring 2 and O-ring 3.

12 SERVICE WORK ON THE CHASSIS



- Position the upper triple clamp with the handlebar.
- Mount screw 4 but do not tighten yet.



- Secure wiring harness and clutch line with cable holder.
- Position the voltage regulator, and mount and tighten screws 6.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		


- Secure the wiring harness with the cable holder in front of the right radiator.
- Position the fork legs.
 - Bleeder screws 6 are positioned toward the front.



H01672-10

Info


The rebound damping is located in right fork leg **REB** (red adjusting screw). The compression damping is located in left fork leg **COM** (white adjusting screw). Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.



Tighten screws 7.

Guideline

Screw, bottom triple	M8	15 Nm (11.1 lbf ft)
clamp		



Tighten screw 4.


Guideline

Screw, top steering	M20x1.5	12 Nm (8.9 lbf ft)
head		




Mount and tighten screw **3**. Guideline

Screw, top	M8	17 Nm (12.5 lbf ft)
steering stem		Loctite [®] 243™



Tighten screws **9**.
 Guideline

Screw, top triple	M8	17 Nm (12.5 lbf ft)
clamp		



- Position the brake caliper, and mount and tighten screws **10**. Guideline

Screw, front	M8	25 Nm (18.4 lbf ft)
brake caliper		Loctite [®] 243™

- Mount the cable tie(s).
- Position the brake line, wiring harness, and clamp. Mount and tighten screws 1.

Finishing work

- Mount the handlebar cushion.
- Install front fender. (
 p. 62)
- Install the headlight mask with the headlight. ([□] p. 109)
- Check that the wiring harness, throttle cables, and brake and clutch lines can move freely and are routed correctly.
- Remove the motorcycle from the lift stand. (p. 53)
- Check the headlight setting. (Fig. p. 111)

12.11 Checking the play of the steering head bearing




Warning

Danger of accidents Incorrect steering head bearing play impairs the handling characteristic and damages components.

 Correct incorrect steering head bearing play immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Info

If the vehicle is operated for a lengthy period with play in the steering head bearing, the bearings and the bearing seats in the frame can become damaged over time.



Preparatory work

- Raise the motorcycle with a lift stand. (
p. 53)

Main work

 Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

Play should not be detectable on the steering head bearing.

- » If there is detectable play:
- Move the handlebar to and fro over the entire steering range.

It must be possible to move the handlebar easily over the entire steering range. There should be no detectable detent positions.

- » If detent positions are detected:

 - Check the steering head bearing and replace if necessary.

Finishing work

Remove the motorcycle from the lift stand. (
 p. 53)

12.12 Adjusting the steering head bearing play >

S02077-10

Preparatory work

Main work

- Loosen screws 1.
- Remove screw 2.
- Loosen and retighten screw 3.

Guideline

Screw, top steering	M20x1.5	12 Nm (8.9 lbf ft)
head		

- Using a plastic hammer, tap lightly on the upper triple clamp to avoid stresses.
- Tighten screws 1.

Guideline

Screw, top triple	M8	17 Nm (12.5 lbf ft)
clamp		

Mount and tighten screw 2.


Guideline

Screw, top	M8	17 Nm (12.5 lbf ft)
steering stem		Loctite [®] 243™

Finishing work

- Check the play of the steering head bearing. (
 p. 59)
- Remove the motorcycle from the lift stand. (🕮 p. 53)

12.13 Lubricating the steering head bearing 4



•


12.14 Removing front fender

Preparatory work


- Remove the headlight mask with the headlight. (🕮 p. 109)

Main work

- Remove screws 1.
- Remove screws 2. Take off the front fender.



12.15 Installing front fender



Main work

Position front fender. Mount and tighten screws ①.
 Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

- Mount and tighten screws 2.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

Finishing work

- Install the headlight mask with the headlight. (p. 109)


12.16 Removing the shock absorber 4

Preparatory work


- Raise the motorcycle with a lift stand. (p. 53)

Main work

- Remove the cable ties.
 - Remove screws 1.
- Remove screws 2 with the washers.
- Remove the frame protectors on the left and right.



- Remove screw 3.
- Remove fitting 4.




i

S02085-10

Info


Raise the wheel slightly to be able to remove the screws more easily.




- Press angle lever **5** toward the rear.
- Press linkage lever 6 downward.




Disconnect plug-in connector 7.



- Remove screws 8.
- Pull off foot brake cylinder from the push rod.




- Remove the connecting link of the chain.
- Take off the chain.




- Remove nut **9** and pull out the swingarm pivot.
- Push the swingarm back and secure it against falling over.

12 SERVICE WORK ON THE CHASSIS



- Hold the shock absorber and remove screw $\mathbf{0}$.
- Remove the shock absorber carefully at the bottom.

12.17 Installing the shock absorber 4



Main work

- Carefully position the shock absorber into the vehicle from the bottom.
- Mount and tighten screw 1.

Guideline

Screw, top	M10	60 Nm (44.3 lbf ft)
shock absorber		Loctite [®] 2701™

Position the swingarm and mount the swingarm pivot.



Info

Pay attention to flat area (A).

attention to hat area

Mount and tighten nut 2.

Guideline


Nut, swingarm pivot M16x1.5 100 Nm (73.8 lbf fi


- S02081-11
- Mount the chain.
- Connect the chain with connecting link 3.
 Guideline

The closed side of the chain joint lock must face in the direction of travel.



Connect plug-in connector 4.







- ✓ Push rod **5** engages in the foot brake cylinder.
- ✓ The dust boot is correctly positioned.
- Mount and tighten screws **6**.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

- Position the angle lever and linkage lever.
- Mount and tighten fitting 7.

Guideline

Nut, linkage lever on	M14x1.5	80 Nm (59 lbf ft)
angle lever		



Info

Pay attention to flat area **B**.

Mount and tighten screw 8.


Guideline

Screw, bottom	M10	60 Nm (44.3 lbf ft)
shock absorber		Loctite [®] 2701™



Info

Raise the wheel slightly to be able to mount the screw more easily.



- Mount and tighten screws **9**.

Guideline

Screw, frame pro-	M5	3 Nm (2.2 lbf ft)
tector		

Mount and tighten screws with the washers.


Guideline

Screw, frame pro-	M5	3 Nm (2.2 lbf ft)
tector		


Mount the new cable ties.

Finishing work

- Check the free travel of the foot brake lever. (
 p. 91)
- Remove the motorcycle from the lift stand. (🕮 p. 53)



12.18 Removing the seat




Preparatory work

- Remove the air filter box cover. (p. 67)

Main work

- Remove screw **1** with the bushing.
- Pull seat back and lift it off.

12.19 Mounting the seat



Main work


- Mount the front of the seat on the collar bushing of the fuel tank, lower the seat at the rear, and push the seat forward.
- Make sure that the seat is locked in correctly.
- Mount and tighten screw with the bushing.
 Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

Finishing work


- Install the air filter box cover. (₽ p. 67)

12.20 Removing the air filter box cover



- Pull off the air filter box cover sideways in areas (A), (B) and (D), and remove toward the front.

12.21 Installing the air filter box cover



- Position air filter box cover on collar bushings and and and push toward the rear.
- Engage the air filter box cover in areas (A), (B) and (O).

12.22 Removing the air filter 4

Note

Engine damage Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt will enter the engine without an air filter.

- Never start to use the vehicle without an air filter.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Preparatory work


- Remove the air filter box cover. (p. 67)



Main work

- Detach retaining tab 1. Remove air filter with air filter support.
- Remove air filter from air filter support.


12.23 Installing the air filter 4



Main work

- Mount the clean air filter on the air filter support.
- Grease the air filter in area \mathbf{A} .

Long-life grease (🕮 p. 148)



- Insert air filter and position retaining pin 1 in bushing 1.
- ✓ The air filter is correctly positioned.
- Insert retaining tab 3.
 - Retaining pin 2 is secured with retaining tab 3.



Info

If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.

Finishing work

- Install the air filter box cover. (p. 67)

12.24 Cleaning the air filter and air filter box 4



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.

Preparatory work

- Remove the air filter box cover. (@ p. 67)
- Remove the air filter. ♣ (🕮 p. 67)



Main work

Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaner (p. 148)



Info

Only press the air filter to dry it, never wring it out.

Oil the dry air filter with a high quality filter oil.

Oil for foam air filter (
p. 148)

- Clean the air filter box.
- Check the intake flange for damage and firm seating.

Finishing work

- Install the air filter. 🔌 (🕮 p. 68)
- Install the air filter box cover. (p. 67)

12.25 Sealing the air filter box &




Remove the air filter box cover. (p. 67)



Seal the air filter box in the marked area (A).






Finishing work


Install the air filter box cover. (p. 67)

12.26 Removing the right side cover



- Remove screw 1.
- Pull off the side cover sideways in areas (A) and (B), and remove toward the front.

12.27 Installing the right side cover



- Position the side cover on collar bushings **1** and **2**, and push toward the rear.
- Engage the side cover in areas **A** and **B**.
- Mount and tighten screw 3.

Guideline

Remaining screws,	M5	5 Nm (3.7 lbf ft)
chassis		

12.28 Removing the main silencer



Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down before performing any work on the vehicle.

Preparatory work

- Remove the right side cover. (p. 69)

Main work

Detach spring 1.


Spring hook (5030501700004)

(EU)


 Remove screws 2 and take off the main silencer with the catalytic converter.

(AU)

Remove screws 2 and take off the main silencer.




12.29 Installing the main silencer



Main work (EU)

- Position catalytic converter in the main silencer.



- Position the main silencer.
- Mount screws 1 but do not tighten yet.
- Attach spring 2.

Spring hook (5030501700004)

Tighten screws 1.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

Finishing work

- Install the right side cover. (₩ p. 70)

12.30 Changing the glass fiber yarn filling in the main silencer



Warning

Danger of burns The exhaust system gets very hot when the vehicle is driven.

- Allow the exhaust system to cool down before performing any work on the vehicle.




Info

Over time, the fibers of the glass fiber yarn escape and the damper "burns" out. Not only is the noise level higher, the performance characteristic changes.

Preparatory work

- Remove the right side cover. (□ p. 69)
- Remove the main silencer. (@ p. 70)



Main work

- Remove all screws on the main silencer.
- Take off silencer cap 1.
- Take off outer tube 2.
- Remove glass fiber yarn filling 3 from the inner tube with connecting cap 4.
- Clean the parts that need to be reinstalled and check for damage.
- Mount the new glass fiber yarn filling with connecting cap onto the inner tube.
- Position the inner tube with the connecting cap and glass fiber yarn filling in the outer tube.
- Position the silencer cap in the outer tube.
- Mount and tighten all of the screws.
 Guideline

Screws on the main	M5	7 Nm (5.2 lbf ft)
silencer		

Finishing work

- Install the right side cover. (
 p. 70)

12.31 Removing the fuel tank 4



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.




Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.

Preparatory work

- Remove the seat. (🕮 p. 66)
- Remove the right side cover. (p. 69)



Main work

- Unplug connector 1 of the fuel pump.
- Clean plug-in connection 2 of the fuel line thoroughly with compressed air.



Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve!

Disconnect the plug-in connection of the fuel line.




Info

Remaining fuel may flow out of the fuel hose.


Mount wash cap set A.

Wash cap set (81212016100)


- Remove the tube from the fuel tank breather.
- Remove screws 3 with the collar bushings.
- Hang the horn and horn bracket to one side.



Remove screw 4 with the rubber bushing.



 Pull both spoilers off the sides of the radiator bracket and lift off the fuel tank.



12.32 Installing the fuel tank 4



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.


- Do not refuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning


Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.




Main work


- Position the fuel tank and fit the two spoilers to the sides in front of the radiator bracket.
- Make sure that no cables or throttle cables are trapped or damaged.



- Attach the fuel tank breather hose.
- Mount and tighten screw with the rubber bushing.
 Guideline


Re	maining screws,	M6	10 Nm (7.4 lbf ft)
cha	assis		





Mount and tighten screws with the collar bushings.
 Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		



- Plug in connector 3 for the fuel pump.
- Remove the wash cap set.
- Thoroughly clean the plug-in connection of the fuel line using compressed air.



Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve!

 Lubricate the O-ring and connect plug-in connection 4 for the fuel line.




Info

Route the cable and fuel line at a safe distance from the exhaust system.

Finishing work

- Mount the seat. (@ p. 66)
- Install the air filter box cover. (≅ p. 67)
- Install the right side cover. (≅ p. 70)

12.33 Checking for chain dirt accumulation



- Check the chain for coarse dirt accumulation.
 - » If the chain is very dirty:
 - Clean the chain. (🕮 p. 76)

12.34 Cleaning the chain



Warning

Danger of accidents Oil or grease on the tires reduces the road grip.

- Remove the lubricant from the tires using a suitable cleaning agent.



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Note


Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

The service life of the chain depends largely on its maintenance.



Preparatory work

- Raise the motorcycle with a lift stand. (@ p. 53)

Main work

- Rinse off loose dirt with a soft jet of water.
- Remove old grease residue with chain cleaner.

Chain cleaner (E p. 148)

After drying, apply chain spray.

Off-road chain spray (🕮 p. 148)

Finishing work

Remove the motorcycle from the lift stand. (
 p. 53)

12.35 Checking the chain tension



Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)



Main work

- Pull the chain at the end of the chain sliding piece upward to measure chain tension **A**.



Info

The lower chain section must be taut.

When the chain guard is mounted, it must be possible to pull up the chain at least to the point where it makes contact with chain guard .

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	55 58 mm (2.17
	2.28 in)

- » If the chain tension does not meet the specification:
 - Adjust the chain tension. (p. 77)

Finishing work

- Remove the motorcycle from the lift stand. (p. 53)

12.36 Adjusting the chain tension



Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

- Check the chain tension regularly.
- Set the chain tension in accordance with the specification.

Preparatory work

- Raise the motorcycle with a lift stand. (🕮 p. 53)
- Check the chain tension. (p. 76)



00000000

Main work

- Loosen nut 1.
- Loosen nuts 2.
- Adjust the chain tension by turning adjusting screws 3 left and right.

Guideline

Chain tension	55 58 mm (2.17
	2.28 in)
Turn adjusting screws 3 on the left and right so that the	
markings on the left and right chain adjusters are in the	

Turn adjusting screws on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks. The rear wheel is then correctly aligned.

- Tighten nuts 2.
- Make sure that the chain adjusters 4 are fitted correctly on the adjusting screws 3.
- Tighten nut 1.

Guideline

Nut, rear wheel spin-	M20x1.5	80 Nm (59 lbf ft)
dle		



Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.

Chain adjusters 4 can be turned by 180°.

Finishing work

Remove the motorcycle from the lift stand. (
 p. 53)

12.37 Checking the chain, rear sprocket, engine sprocket, and chain guide

Preparatory work

- Raise the motorcycle with a lift stand. (p. 53)

Main work


- Shift the transmission to idle.
- Check the chain, rear sprocket and engine sprocket for wear.
 - If the chain, rear sprocket or engine sprocket is worn:
 - Change the drivetrain kit.



Info

The engine sprocket, rear sprocket and chain should always be replaced together.

Property and origin; real sprooker, engine sprook



Pull at the top part of the chain with the specified weight **(A)**. Guideline

Weight of chain wear mea-	10 15 kg (22 33 lb.)
surement	

Measure distance **(B)** of 18 chain rollers in the lower chain section.



Info

Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance B at	272 mm (10.71 in)
the longest chain section	


- » If distance **B** is greater than the specified measurement:
 - Change the drivetrain kit.



Info


When a new chain is mounted, the rear sprocket and engine sprocket should also be changed.

New chains wear out faster on old, worn sprockets.




- » If the lower edge of the chain pins is in line with, or below, the chain sliding guard:
 - Change the chain sliding guard. 4
- Check that the chain sliding guard is firmly seated.
 - » If the chain sliding guard is loose:
 - Tighten the screws on the chain sliding guard.
 Guideline

Screw, chain	M6	14 Nm (10.3 lbf ft)
sliding guard		Loctite [®] 243™




12 SERVICE WORK ON THE CHASSIS



- Check the chain sliding piece for wear.
 - » If the lower edge of the chain pins is in line with or below the chain sliding piece:
 - Change the chain sliding piece. 🔦
- Check that the chain sliding piece is firmly seated.
 - » If the chain sliding piece is loose:
 - Tighten the screw of the chain sliding piece.
 Guideline

Screw, chain slid-	M8	15 Nm
ing piece		(11.1 lbf ft)




Check the chain guide for wear.



Info

Wear can be seen on the front of the chain guide.

- » If the light part of the chain guide is worn:
 - Change the chain guide.



- Check that the chain guide is firmly seated.
 - » If the chain guide is loose:
 - Tighten the fitting on the chain guide.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)

Finishing work

- Remove the motorcycle from the lift stand. (■ p. 53)

12.38 Checking the frame 4



- Check the frame for cracks and deformation.
 - » If the frame exhibits cracks or deformation due to a mechanical impact:
 - Change the frame.



Info

Always replace a frame that has been damaged due to a mechanical impact. Repair of the frame is not authorized by Husqvarna Motorcycles.

12.39 Checking the swingarm 4



- Check the swingarm for damage, cracking, and deformation.
 - » If the swingarm shows signs of damage, cracking, or deformation:
 - Change the swingarm.




Info

Always change a damaged swingarm. Repair of the swingarm is not authorized by Husqvarna Motorcycles.

12.40 Checking throttle cable routing

Preparatory work

- Remove the air filter box cover. (🕮 p. 67)
- Remove the seat. (₩ p. 66)
- Remove the right side cover. (🕮 p. 69)
- Remove the fuel tank. ♣ (≅ p. 72)



Main work

- Check throttle cable routing.


Both throttle cables must be routed, side by side, on the back of the handlebars and above the fuel tank bracket, to the throttle valve body. Both throttle cables must be secured behind the fuel tank contact area rubber band.

- » If the throttle cable routing is not as specified:
 - Correct throttle cable routing.

Finishing work

- Install the fuel tank. ◄ (🕮 p. 74)
- Mount the seat. (
 p. 66)

12.41 Checking the rubber grip



 Check the rubber grips on the handlebar for damage, wear, and looseness.



Info


The rubber grips are vulcanized onto a sleeve on the left and onto the handle tube of the throttle grip on the right. The left sleeve is clamped onto the handlebar. The rubber grip can only be replaced with the sleeve or the throttle tube.

- » If a rubber grip is damaged, worn, or loose:
 - Change the rubber grip.
- Check that screw 1 is firmly seated.

Guideline



Diamond A must be located at the top.



12.42 Adjusting the basic position of the clutch lever



 Adjust the basic position of the clutch lever to your hand size by turning adjusting screw 1.



Info

When the adjusting screw is turned clockwise, the clutch lever moves closer to the handlebar. When the adjusting screw is turned counterclockwise, the clutch lever moves away from the handlebar. The range of adjustment is limited. Turn the adjusting screw by hand only, and do not apply any force.

Do not make any adjustments while riding.

12.43 Checking/correcting the fluid level of the hydraulic clutch



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info

The fluid level rises with increasing wear of the clutch facing discs.

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and clutch lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Take off cover 2 with membrane 3.
- Check the fluid level.

Fluid level below container	4 mm (0.16 in)
rim	

- » If the fluid level does not meet specifications:
 - Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 / DOT 5.1 (Fig. p. 146)

 Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.

12.44 Changing the hydraulic clutch fluid 4



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.





Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and clutch lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint. Only use clean brake fluid from a sealed container.

- Move the clutch fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Take off cover 2 with membrane 3.






Fill bleeding syringe 4 with the appropriate hydraulic fluid.

Syringe (50329050000)

Brake fluid DOT 4 / DOT 5.1 (@ p. 146)

On the clutch slave cylinder, remove bleeder screw **5** and mount bleeding syringe **4**.



- Now press the fluid into the system until it emerges from the hole 6 of the master cylinder without bubbles.
- Now and then, extract fluid from the master cylinder reservoir to prevent overflow.
- Remove the bleeding syringe. Mount and tighten screws bleeder screw.
- Correct the fluid level of the hydraulic clutch.

Guideline

Fluid level below container	4 mm (0.16 in)
rim	


 Position the cover with the membrane. Mount and tighten the screws.



Info


Clean up overflowed or spilled brake fluid immediately with water.

12.45 Removing the engine guard



- Remove screws 1 and engine guard.

12.46 Installing the engine guard



- Attach the engine guard on the frame at the rear and swing up at the front.
- Mount and tighten screws 1.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

13.1 Adjusting the basic position of the hand brake lever



 Adjust the basic position of the hand brake lever to your hand size by turning adjusting screw 1.



Info

Turn the adjusting screw clockwise to decrease the distance between the hand brake lever and the handlebar.

Turn the adjusting screw counterclockwise to increase the distance between the hand brake lever and the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.

Do not make any adjustments while riding.


13.2 Checking the brake discs



Warning

Danger of accidents Worn-out brake discs reduce the braking effect.

 Make sure that worn-out brake discs are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



 Check the front and rear brake disc thickness at multiple points for the dimension A.



Info

Wear reduces the thickness of the brake disc around the contact surface of the brake linings.

Brake discs - wear limit		
front	2.5 mm (0.098 in)	
rear	3.5 mm (0.138 in)	

- » If the brake disc thickness is less than the specified value:
 - Change the front brake disc.
 - Change the rear brake disc.
- Check the front and rear brake discs for damage, cracking, and deformation.
 - » If the brake disc exhibits damage, cracking, or deformation:
 - Change the front brake disc.
 - Change the rear brake disc.

•



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.


 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Check the brake fluid level in level viewer 1.
 - » If the brake fluid level has dropped below the marking **A**:
 - Add front brake fluid. 4 (
 p. 87)

13.4 Adding front brake fluid 4



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



Preparatory work

- Check the front brake linings. (E) p. 88)

Main work

- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Take off cover **2** with membrane **3**.
- Add brake fluid to level (A).

Guideline

Level (A) (brake fluid level 5 mm (0.2 in) below reservoir rim)



 Position the cover with the membrane. Mount and tighten the screws.



Info

Clean up overflowed or spilled brake fluid immediately with water.

13.5 Checking the front brake linings




Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

 Ensure that worn-out brake linings are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Minimum thickness A



Check the brake linings for minimum thickness A.

≥ 1 mm (≥ 0.04 in)

- » If the minimum thickness is less than specified:
 - Change the front brake linings. ◀ (🕮 p. 89)
- Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:

13.6 Changing the front brake linings 4



Warning

Danger of accidents Incorrect maintenance will cause the brake system to fail.

 Ensure that service work and repairs are performed professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Warning

Danger of accidents Brake linings which have not been approved alter the braking efficiency.

Not all brake linings are tested and approved for Husqvarna motorcycles. The structure and friction coefficient of the brake linings, and thus their brake power, may vary greatly from that of original brake linings.

If brake linings are used that differ from the original equipment, compliance with the original homologation is not guaranteed. In this case, the vehicle no longer corresponds to its condition at delivery and the warranty shall be void.

- Only use brake linings approved and recommended by Husqvarna motorcycles.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



- Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
- Remove screws 1.
- Take off cover **2** with membrane **3**.




 Manually press the brake caliper toward the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir, if necessary extract excess



Info

Make sure that you do not press the brake caliper against the spokes when pushing back the brake pistons.

- Remove cotter pin 4.
- Push leaf spring 6 upwards and remove pin 6.
- Remove brake linings.
- Clean the brake caliper and brake caliper support.
- Check that leaf spring 6 in the brake caliper and sliding plate 7 in the brake caliper support are seated correctly.






- Insert the new brake linings.
- Mount pin 6.
 - ✓ Leaf spring **6** engages in the groove on the pin.



Info

Always change the brake linings in pairs.

- Mount cotter pins 4.
- Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



Correct the brake fluid quantity to level A.
 Guideline

Level A (brake fluid level	5 mm (0.2 in)
below reservoir rim)	

Brake fluid DOT 4 / DOT 5.1 (Fig. p. 146)

- Position cover 2 with membrane 3.
- Mount and tighten screws 1.



Info

Clean up overflowed or spilled brake fluid immediately with water.

13.7 Checking the free travel of foot brake lever




Warning

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake

- Set the free travel on the foot brake lever in accordance with the specification.



- Disconnect spring 1.
- Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel .

Guideline

Free travel at foot brake	3 5 mm (0.12 0.2 in)
lever	

- If the free travel does not meet specifications:
 - Adjust the basic position of the foot brake lever. ⁴
 (♠ p. 92)
- Reconnect spring 1.

•

13.8 Adjusting the basic position of the foot brake lever &




Warning

Danger of accidents The brake system fails in the event of overheating.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear

Set the free travel on the foot brake lever in accordance with the specification.



- Disconnect spring 1.
- Loosen nut 4 and, with push rod 5, turn it back until you have maximum free travel.
- To adjust the basic position of the foot brake lever individually, loosen nut 2 and turn screw 3 accordingly.



Info

The range of adjustment is limited.

Turn push rod **5** accordingly until you have free travel **A**. If necessary, adjust the basic position of the foot brake lever. Guideline

Free travel at foot brake	3 5 mm (0.12 0.2 in)
lever	

Hold screw 3 and tighten nut 2. Guidelina

Guideline		
Nut, foot brake lever	M8	20 Nm (14

1.8 lbf ft) stop

Hold push rod **5** and tighten nut **4**.

Guideline

Remaining nuts,	M6	10 Nm (7.4 lbf ft)
chassis		

Reconnect spring 1.

13.9 Checking the rear brake fluid level



Warning

Danger of accidents
An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.


Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Old brake fluid reduces the braking effect.

Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Stand the vehicle upright.
- Check the brake fluid level in level viewer 1.
 - » If the brake fluid level has dropped below marking A:
 - Add rear brake fluid. 🔌 (🕮 p. 93)

13.10 Adding rear brake fluid 4



Warning

Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

 Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info

Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.

Preparatory work



Main work

- Stand the vehicle upright.
- Remove the cable ties on the frame protector.
- Remove screw cap 1 with membrane 2 and the shim.
 - Add brake fluid up to the marking (A).

Brake fluid DOT 4 / DOT 5.1 (Fig. p. 146)

 Mount and tighten screw cap with the membrane and the shim.



Info

Clean up overflowed or spilled brake fluid immediately with water.

Mount new cable ties on the frame protector.


13.11 Checking the rear brake linings



Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

 Ensure that worn-out brake linings are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



- Check the brake linings for minimum thickness **A**.

1.1

Minimum thickness (A)

≥ 1 mm (≥ 0.04 in)

- » If the minimum thickness is less than specified:
 - Change the rear brake linings. ◄ (□ p. 94)
- Check the brake linings for damage and cracking.
 - » If damage or cracking is visible:

13.12 Changing the rear brake linings 4



Warning

Danger of accidents Incorrect maintenance will cause the brake system to fail.

 Ensure that service work and repairs are performed professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Skin irritation Brake fluid causes skin irritation.

- Keep brake fluid out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
- Consult a doctor immediately if brake fluid has been swallowed.
- Rinse the affected area with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
- If brake fluid spills on to your clothing, change the clothing.



Warning

Danger of accidents Old brake fluid reduces the braking effect.

 Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.



Warning

Danger of accidents Brake linings which have not been approved alter the braking efficiency.

Not all brake linings are tested and approved for Husqvarna motorcycles. The structure and friction coefficient of the brake linings, and thus their brake power, may vary greatly from that of original brake linings.

If brake linings are used that differ from the original equipment, compliance with the original homologation is not guaranteed. In this case, the vehicle no longer corresponds to its condition at delivery and the warranty shall be void.

- Only use brake linings approved and recommended by Husqvarna motorcycles.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.




Info


Never use DOT 5 brake fluid. It is silicone-based and purple in color. Oil seals and brake lines are not designed for DOT 5 brake fluid.

Avoid contact between brake fluid and painted parts. Brake fluid attacks paint.

Only use clean brake fluid from a sealed container.



- Stand the vehicle upright.
- Remove the cable ties on the frame protector.
- Remove screw cap 1 with membrane 2 and the shim.




 Press the brake caliper onto the brake disc by hand to push back the brake piston and ensure that brake fluid does not flow out of the brake fluid reservoir, extract it if necessary.




Info

Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove cotter pin 3.
- Push leaf spring 4 downwards and remove pin 6.
- Remove brake linings.
- Clean the brake caliper and brake caliper support.



 Check that leaf spring 4 in the brake caliper and sliding plate 6 in the brake caliper support are seated correctly.



- Insert the new brake linings.
- Mount pin 6.
 - ✓ Leaf spring **4** engages in the groove on the pin.



Info

Always change the brake linings in pairs.

Make sure that decoupling plate is mounted on the piston side brake lining.

- Mount cotter pins 3.
- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.
- Add brake fluid to level A.

Brake fluid DOT 4 / DOT 5.1 (Fig. 146)

Mount and tighten screw cap **1** with membrane **2** and the shim.




Info


Clean up overflowed or spilled brake fluid immediately with water.

- Mount new cable ties on the frame protector.





14.1 Removing the front wheel 4



Preparatory work


Raise the motorcycle with a lift stand. (p. 53)

Press the brake caliper onto the brake disc by hand in order to push back the brake pistons.




Info

Make sure that you do not press the brake caliper against the spokes when pushing back the brake pistons.



- Loosen screw 1 by several rotations.
- Loosen screws 2.
- Press on screw 1 to push the wheel spindle out of the axle clamp.
- Remove screw 1.





Warning

Danger of accidents Damaged brake discs reduce the braking effect.

- Always lay the wheel down in such a way that the brake disc is not damaged.
- Hold the front wheel and remove the wheel spindle. Take the front wheel out of the fork.



Info

Do not pull the hand brake lever when the front wheel is removed.

H00934-10

Remove spacers 3.


14.2 Installing the front wheel 4




Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.





- Check the wheel bearing for damage and wear.
 - If the wheel bearing is damaged or worn:
 - Change front wheel bearing.
- Clean and grease shaft seal rings 1 and contact surface A of the spacers.

Long-life grease (EP p. 148)

- Insert the spacers.
- Clean and grease the wheel spindle.

Long-life grease (E p. 148)

- Position the front wheel and insert the wheel spindle.
 - ✓ The brake linings are correctly positioned.
- Mount and tighten screw 2.

Guideline

Screw, front wheel	M20x1.5	35 Nm (25.8 lbf ft)
spindle		

- Operate the hand brake lever several times until the brake linings are seated correctly against the brake disc.
- Remove the motorcycle from the lift stand. (
 p. 53)
- Operate the front brake and compress the fork a few times firmly.
 - ✓ The fork legs straighten.
- Tighten screws 3.

Guideline


Screw, fork stub	M8	15 Nm (11.1 lbf ft)

•

14.3 Removing the rear wheel 4

Preparatory work

Raise the motorcycle with a lift stand. (
 p. 53)



Main work

 Press the brake caliper onto the brake disc by hand in order to push back the brake piston.



Info

Make sure when pushing back the brake piston that you do not press the brake caliper against the spokes.

- Remove nut 1.
- Remove chain adjuster 2. Pull out wheel spindle 3 far enough to allow the rear wheel to be pushed forward.
- Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.



Info

Cover the components to protect them against damage.



Warning

Danger of accidents Damaged brake discs reduce the braking effect.


- Always lay the wheel down in such a way that the brake disc is not damaged.
- Hold the rear wheel and remove the wheel spindle. Take the rear wheel out of the swingarm.



Info

Do not operate the foot brake lever when the rear wheel is removed.

Remove spacers 4.




14.4 Installing the rear wheel 4





Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

- Always keep the brake discs free of oil and grease.
- Clean the brake discs with brake cleaner when necessary.







Main work

- Check the wheel bearing for damage and wear.
 - » If the wheel bearing is damaged or worn:
 - Change the rear wheel bearing.
 - Clean and grease shaft seal rings 1 and contact surface A of the spacers.

Long-life grease (Fig. 148)

- Insert the spacers.
- Clean and grease the wheel spindle.

Long-life grease (
p. 148)

- Position the rear wheel and insert wheel spindle $\mathbf{2}$.
- Mount the chain.
 - ✓ The brake linings are correctly positioned.
- Position chain adjuster 3. Mount nut 4, but do not tighten it yet.
- Make sure that chain adjusters 3 are fitted correctly on adjusting screws 5.
- Tighten nut 4.

Guideline

Nut, rear wheel spin-	M20x1.5	80 Nm (59 lbf ft)
dle		



Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.

Chain adjusters 3 can be turned by 180°.

 Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work

- Remove the motorcycle from the lift stand. (♠ p. 53)



Info


Only mount tires approved and/or recommended by Husqvarna Motorcycles.

Other tires could have a negative effect on handling characteristics.

The type, condition, and air pressure of the tires all have a major impact on the handling of the motorcycle

The tires mounted on the front and rear wheels must have a similar profile.

Worn tires have a negative effect on handling characteristics, especially on wet surfaces.



- Check the front and rear tires for cuts, run-in objects, and other damage.
 - » If the tires have cuts, run-in objects, or other damage:
 - Change the tires.
- Check the tread depth.




Info

Adhere to the legally required minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)
---------------------	--------------------

- » If the tread depth is less than the minimum tread depth:
 - Change the tires.
- Check the tire age.





The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.

Husqvarna Motorcycles recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

- » If the tires are more than 5 years old:
 - Change the tires.


14.6 Checking the tire air pressure



Info

Low tire air pressure leads to abnormal wear and overheating of the tire.

Correct tire air pressure ensures optimal riding comfort and maximum tire service life.



- Remove the protection cap.
- Check the tire air pressure when the tires are cold.

Tire air pressure off road	
front	1.0 bar (15 psi)
rear	1.0 bar (15 psi)

Road tire pressure	
front	1.5 bar (22 psi)
rear	1.8 bar (26 psi)

- » If the tire pressure does not meet specifications:
 - Correct the tire pressure.
- Mount the protection cap.

14.7 Checking spoke tension




Warning

Danger of accidents Incorrectly tensioned spokes impair the handling characteristic and result in secondary damage.

The spokes break due to being overloaded if they are too tightly tensioned. If the tension in the spokes is too low, then lateral and radial run-out will form in the wheel. Other spokes will become looser as a result.

 Check spoke tension regularly, and in particular on a new vehicle. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



Strike each spoke briefly using a screwdriver blade.



Info

The frequency of the sound depends on the spoke length and spoke diameter.

If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.

- » If the spoke tension differs:
 - Correct the spoke tension.
- Check the spoke torque.

Guideline

Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)

Torque wrench kit (58429094000)

•


15.1 Removing the battery 4



Warning

Risk of injury Batteries contain harmful substances.


- Keep batteries out of the reach of children.
- Keep sparks and open flames away from the batteries.
- Only charge batteries in well-ventilated rooms.
- Maintain a minimum clearance from inflammable materials when charging batteries.
 Minimum clearance
 1 m (3 ft)
- Do not charge deeply discharged batteries if charge is already below the minimum voltage.
 Minimum voltage before the start of the charge 9 V
- Dispose of batteries with less than the minimum voltage correctly.




- Remove the air filter box cover. (p. 67)
- Remove the seat. (B p. 66)



- Pull back the negative terminal cover 1 and disconnect negative cable 2 from the battery.
- Pull back the positive terminal cover 3 and disconnect positive cable 4 from the battery.
- Remove screw 6.
- Pull holding bracket 6 forward and remove battery toward the top.



15.2 Installing the battery 4



Main work

Insert the battery into the battery compartment with the terminals facing forward and secure with holding bracket 1.

Battery (HJTZ5S-FP) (@ p. 142)

Mount and tighten screw 2.

Guideline

Remaining screws,	M6	10 Nm (7.4 lbf ft)
chassis		

Connect positive cable 5 to the battery.

Guideline

Screw, battery termi-	M5	2.5 Nm (1.84 lbf ft)
nal		



Info

Contact disks **A** must be mounted under the screw **3** and the cable lug **4** with the claws toward the battery terminal.

- Slide positive terminal cover 6 over the positive terminal.
- Connect negative cable to the battery.

Guideline

Screw, battery termi-	M5	2.5 Nm (1.84 lbf ft)
nal		



Info

Contact disks **A** must be mounted under the screw **3** and the cable lug **4** with the claws toward the battery terminal.

- Slide negative terminal cover **8** over the negative terminal.

Finishing work

- Mount the seat. (
 p. 66)
- Install the air filter box cover. (p. 67)

15.3 Recharging the battery 4



Warning

Risk of injury Batteries contain harmful substances.

- Keep batteries out of the reach of children.
- Keep sparks and open flames away from the batteries.
- Only charge batteries in well-ventilated rooms.
- Maintain a minimum clearance from inflammable materials when charging batteries.
 Minimum clearance
 1 m (3 ft)
- Do not charge deeply discharged batteries if charge is already below the minimum voltage.
 Minimum voltage before the start of the charge 9 V
- Dispose of batteries with less than the minimum voltage correctly.



Note

Environmental hazard Batteries contain environmentally-hazardous materials.

- Do not dispose of batteries as household waste.
- Dispose of batteries at a collection point for used batteries.



Note

Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Even when there is no load on the battery, it discharges steadily.

The charging level and the method of charging are very important for the service life of the battery.

Rapid recharging with a high charging current shortens the service life of the battery.

If the charging current or charging voltage are exceeded, the battery will be destroyed.

If the battery is depleted by repeated starting, the battery must be charged immediately.


If the battery is left in a discharged state for an extended period, it will become over-discharged and sulfated, destroying the battery.

The battery is maintenance-free.



- Remove the battery. ⁴ (≅ p. 103)





- » Battery voltage: < 9 V
 - Do not charge the battery.
 - Replace the battery and dispose of the old battery properly.
- » If the specifications have been met:

Battery voltage: ≥ 9 V

 Connect the battery charger to the battery. Switch on the battery charger.


Guideline

The charging current, charging voltage, and charging duration must not be exceeded.	
Maximum charging voltage	14.4 V
Maximum charging cur- rent	3.0 A
Maximum charging time	24 h
Charge the battery regularly when the motorcycle is not in use	6 months

(EU) battery charger (26529974000)

Alternative 1

(US) battery charger (26529974500)



These battery chargers test whether the battery retains its voltage. It is also impossible to overcharge the battery with these battery chargers. The charging time may be longer at low temperatures.

These battery chargers are only suitable for lithium iron phosphate batteries. Read the accompanying instructions for Husqvarna Motorcycles accessories.



Never remove cover 1.



Switch off the battery charger after charging and disconnect from the battery.

Finishing work

- Install the battery. 🌂 (🕮 p. 104)
- Mount the seat. (p. 66)
- Install the air filter box cover. (p. 67)

15.4 Changing the main fuse



Warning

Fire hazard Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.



Info

The main fuse protects all power consumers of the vehicle.


Preparatory work

- Press and hold the kill switch ⋈ while the engine is idling until the engine stops.
- Remove the air filter box cover. (p. 67)
- Remove the seat. (B p. 66)

Main work

Pull starter relay 1 from the holder.





- Take off protection caps 2.
- Remove faulty main fuse 3.



Info

A faulty fuse has a burned-out fuse wire **A**. A spare fuse **4** is located in the starter relay.

Install a new main fuse.

Fuse (58011109120) (
p. 142)

- Check that the electrical system is functioning properly.



Tip

Insert a spare fuse so that it is available if needed.

- Mount the protection caps.
- Mount the starter relay onto the holder and route the cable.

Finishing work

- Mount the seat. (
 p. 66)
- Install the air filter box cover. (p. 67)

15.5 Changing the fuses of individual power consumers




Info


The fuse box containing the fuses of individual power consumers is located under the seat.

Preparatory work

Main work

- Pull EFI control unit 1 off the holder and hang to the side.





- Open fuse box cover 2.
- Remove the faulty fuse.

Guideline

(EU)

Fuse 1 - 10 A - EFI control unit, lambda sensor, combination instrument, combination switch (optional), fuel injection, diagnostics connector, fuse 4

(AU)

Fuse 1 - 10 A - EFI control unit, combination instrument, combination switch (optional), fuel injection, diagnostics connector, fuse 4

Fuse 2 - 10 A - high beam, low beam, position light, tail light, license plate lamp

Fuse 3 - 10 A - radiator fan, horn, brake light, turn signal

Fuse 4 - 5 A - fuel pump

Fuses res - 10 A - spare fuse



Info

A faulty fuse has a burned-out fuse wire **A**.





Warning

Fire hazard Incorrect fuses overload the electrical system.

- Only use fuses with the required ampere value.
- Do not bypass or repair fuses.
- Insert a spare fuse with the correct rating only.


Fuse (75011088010) (p. 142)

Fuse (75011088005) (p. 142)



Replace the spare fuse in the fuse box so that it is available if needed.

- Check that the power consumer is functioning properly.
- Close the fuse box cover.
- Mount EFI control unit 1 on the holder.




Finishing work


- Mount the seat. (p. 66)
- Install the air filter box cover. (p. 67)




- Detach brake line 1 and wiring harness 2.
- Release rubber bands 3. Slide the headlight mask up and swing it forward.



 Detach plug-in connectors 4 and take off the headlight mask with the headlight.




15.7 Installing the headlight mask with the headlight




Main work

Connect plug-in connectors ①.



- Position the headlight mask and secure it with rubber bands 2.
 - ✓ The holding lugs engage in the fender.



 Position brake line 3 and wiring harness 4 in the brake line guide.

Finishing work

15.8 Changing the headlight bulb

Note

Damage to reflector Grease on the reflector reduces the brightness.

Grease on the bulb will evaporate due to the heat and be deposited on the reflector.


- Clean and degrease the bulbs before mounting.
- Do not touch the bulbs with your bare hands.

F00343-10

Preparatory work

Main work

- Turn protection cap 1 together with the underlying bulb socket counterclockwise all the way and remove it.
- Pull bulb socket 2 of the position light out of the reflector.



- Pull out headlight bulb 3.
- Insert the new headlight bulb.

Headlight (HS1/socket PX43t) (🕮 p. 142)

Insert the protection cap with the bulb socket into the reflector and turn it clockwise all the way.



Info

Ensure that O-ring 4 is seated properly.

Insert the bulb socket of the position light into the reflector.

Finishing work

_

15.9 Changing the turn signal bulb

Note

Damage to reflector Grease on the reflector reduces the brightness.

Grease on the bulb will evaporate due to the heat and be deposited on the reflector.

- Clean and degrease the bulbs before mounting.
- Do not touch the bulbs with your bare hands.



Main work

- Remove the screw on the rear of the turn signal housing.
- Carefully take off diffuser 1.
- Lightly squeeze orange cap 2 in the area of the holding lugs and take it off.
- Press the turn signal bulb lightly into the socket, turn it counterclockwise by about 30°, and take it out of the socket.



Info

Do not touch the reflector with your fingers and keep it free from grease.

 Press the new turn signal bulb carefully into the socket and turn it clockwise until it stops.


Turn signal (R10W / socket BA15s) (Fig. 142)

- Mount the orange cap.
- Position the diffuser.
- Insert the screw and first turn counterclockwise until it engages in the thread with a small jerk. Tighten the screw lightly.

Finishing work

Check that the turn signal system is functioning properly.

15.10 Checking the headlight setting



- Position the vehicle upright on a horizontal surface in front of a light wall and make a mark at the height of the center of the low beam headlight.
- Make another mark at a distance **(B)** under the first mark. Guideline

Distance **B** 5 cm (2 in)

Position the vehicle vertically at a distance **A** away from the wall.

Guideline

Distance 6 5 m (16 ft)

- The rider now sits down on the motorcycle.
- Switch on the low beam.
- Check the headlight setting.

The boundary between light and dark must be exactly on the lower mark for a motorcycle with rider.

- » If the light-dark border does not meet specifications:

15.11 Adjusting the headlight range

Preparatory work

- Check the headlight setting. (p. 111)

Main work

- Loosen screw 1.
- Adjust the headlight range by pivoting the headlight.
 Guideline

The boundary between light and dark must be exactly on the lower marking for a motorcycle with rider (instructions on how to apply the marking: Checking the headlight setting).



Info

A change in weight on the vehicle may require a correction of the headlight range.

Tighten screw 1.


15.12 Changing the combination instrument

F00363-10

Preparatory work

Main work

- Remove screws with the washers.
- Pull the combination instrument upward out of the holder.




- Using a coin, turn protection cap 2 all the way counterclockwise and remove it.
- Remove combination instrument 3.
- Insert the new battery with the label facing outward.

Combination instrument battery (CR 2032) (🕮 p. 142)

- Check the O-ring of the protection cap for correct seating.

112




- Position protection cap 2 and turn all the way clockwise using a coin.
- Press any button on the combination instrument.
 - ✓ The combination instrument is activated.
- Position the combination instrument in the holder.
- Mount and tighten the screws with washers.

Finishing work


- Install the headlight mask with the headlight. (■ p. 109)
- Adjust the combination instrument. (p. 24)

15.13 Diagnostics connector



Diagnostics connector 1 is located under the seat.

16.1 Cooling system



Water pump 1 in the engine ensures forced circulation of the coolant.

The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap 2. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

The radiator fan provides extra cooling. It is controlled by a thermoswitch.

16.2 Checking the antifreeze and coolant level



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.




Warning

Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

Condition

The engine is cold.



- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the antifreeze in the coolant.

- » If the antifreeze in the coolant does not match the specified value:
 - Correct the antifreeze in the coolant.
- Check the coolant level in the radiator.

Coolant level (A) above the	10 mm (0.39 in)
radiator fins	

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Mount the radiator cap.

16.3 Checking the coolant level



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.




Warning

Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



The engine is cold.



- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the coolant level in the radiator.

Coolant level (A) above the	10 mm (0.39 in)
radiator fins	

- » If the coolant level does not match the specified value:
 - Correct the coolant level.

Coolant (@ p. 146)

Mount the radiator cap.

16.4 Draining the coolant 4



Warning

Danger of scalding During motorcycle operation, the coolant gets very hot and is under pressure.


- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Warning

Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



Condition

The engine is cold.

- Position the motorcycle upright.
- Place a suitable container under the water pump cover.
- Remove screw 1. Take off radiator cap 2.
- Completely drain the coolant.
- Mount and tighten screw with a new seal ring.
 Guideline

Screw, water pump	M6	10 Nm (7.4 lbf ft)
cover		

16.5 Refilling coolant 4




Warning

Danger of poisoning Coolant is toxic and a health hazard.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

4



Main work

- Make sure that the screw 1 is tightened.
- Stand the vehicle upright.
- Pour coolant in up to measurement **A** above the radiator fins.

Guideline

10 mm (0.39 in)		
Coolant	1.2 l (1.3 qt.)	Coolant (@ p. 146)


- Refit the radiator cap.

Finishing work

- Take a short test ride.
- Check the coolant level. (₽ p. 115)

•

17.1 Checking the play in the throttle cable



- Check the throttle grip for smooth operation.
- Move the handlebar to the straight-ahead position. Turn the throttle grip back and forth slightly and determine the play in throttle cable A.

Play in throttle cable

3 ... 5 mm (0.12 ... 0.2 in)

- If the throttle cable play does not meet the specified value:
 - Adjust the play in the throttle cable. ◄ (□ p. 118)
- Push the cold start button in all the way.

When the throttle grip is turned forward, the cold start button returns to its original position.

- » If the cold start button does not return to its original position:
 - Adjust the play in the throttle cable. ⁴ (♥ p. 118)



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.
- Start the engine and let it run idle. Move the handlebar to and fro over the entire steering range.

The idle speed must not change.

- If the idle speed changes:
 - Adjust the play in the throttle cable. ♣ (♣ p. 118)

4

17.2 Adjusting the play in the throttle cable 4




Info

If the correct routing of the throttle cables has already been secured, the fuel tank does not need to be removed.

Preparatory work

- Remove the seat. (🕮 p. 66)
- Remove the right side cover. (E p. 69)
- Remove the fuel tank. (Image) p. 72)



Main work

- Move the handlebar to the straight-ahead position.
- Push back sleeve 1.
- Loosen nut **2**.
- Turn adjusting screw 3 in as far as possible.
- Loosen nut 4.
- Push cold start button 6 all the way to the stop.
- Turn adjusting screw 6 so that the cold start button moves to the basic position when the throttle grip is turned to the front.
- Tighten nut 4.
- Turn adjusting screw 3 so that there is play in the throttle cable at the throttle grip.

Guideline

Play in throttle cable 3 ... 5 mm (0.12 ... 0.2 in)

- Tighten nut 2.
- Slide on sleeve 1.
- Check the throttle grip for smooth operation.

Finishing work

- Check the play in the throttle cable. (p. 118)


17.3 Adjusting the characteristic map of the throttle response 4



Info

On the throttle grip, the characteristic map of the throttle response is changed by changing the guide plate


A guide plate with a different characteristic map is supplied.



Main work

- Push back sleeve 1.
- Remove screws 2 and half-shells 3.
- Detach the throttle cables and take off the grip tube.

17 TUNING THE ENGINE





Position the required guide plate on the grip tube.
 Guideline

The label **OUTSIDE** must be visible. Marking **(A)** must be positioned at marking **(B)**.

Grey guide plate (79002014000)

Alternative 1

Black guide plate (79002014100)



Info


The gray guide plate opens the throttle valve more slowly.

The black guide plate opens the throttle valve more quickly.

The gray guide plate is mounted upon delivery.



- Clean the outside of the handlebar and the inside of the grip tube. Mount the grip tube on the handlebar.
- Attach the throttle cables to the guide plate and route correctly.



Position half-shells (3), mount and tighten screws (2).

Guideline

Screw, throttle grip M6 5 Nm (3.7 lbf ft)

 Slide on sleeve and check the throttle grip for ease of movement.

Finishing work

- Check the play in the throttle cable. (
p. 118)

17.4 Changing the mapping



Warning

Voiding of the government approval for road use and the insurance coverage If the combination switch is installed, the vehicle's approval for road use is invalidated.

 Only operate the vehicle in closed-off areas remote from public road traffic if the combination switch is installed.



Info

The desired engine characteristic can be activated via the MAP button on the combination switch.

The setting most recently selected is activated again when restarting.

The traction control can also be activated in each mapping using the **TC** button.

The mapping can also be changed during the ride.







Activating STANDARD mapping:

- Press button MAP until LED 1 lights up.

Guideline

Engine speed < 4,000 rpm







Activating ADVANCED mapping:

- Press button MAP until LED 2 lights up.

Guideline

Engine speed < 4,000 rpm

✓ ADVANCED – direct response

17.5 Adjusting the idle speed




Warning

Danger of accidents The engine may go out spontaneously if the idle speed is set too low.

 Set the idle speed to the specified value. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

17 TUNING THE ENGINE



- Run the engine until warm.
 - ✓ The cold start button is deactivated The cold start button is in its basic position. (

 p. 20)



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.
- Set the idle speed by turning idle speed adjusting screw ①.
 Guideline

Idle speed 2,050 ... 2,150 rpm

Tachometer (45129075000)



Info


Turning counterclockwise lowers the idle speed. Turning clockwise raises the idle speed.

17.6 Teaching the throttle valve position



Info

If the control unit detects that the throttle valve idle position needs to be retaught, then the malfunction indicator lamp flashes 2x per second.





Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.
- Allow the vehicle to idle.
 - The malfunction indicator lamp stops flashing once teaching is completed.



Info

If the engine becomes too hot, perform a cool-down ride at medium revs.

Then do not switch off the engine after this, but leave it running at idle speed until teaching is completed.


•

17.7 Checking the basic position of the shift lever

i

Info

When driving, the shift lever must not touch the driver's boot when in the basic position. When the shift lever keeps touching the boot, the transmission will be subject to an excessive load.




 Sit on the vehicle in the riding position and determine the distance between the upper edge of your boot and the shift lever.


Gap between the shift lever	10 20 mm (0.39
and the top of the boot	0.79 in)

- » If the distance does not meet the specifications:
 - Set the basic position of the shift lever. ◄ (🕮 p. 123)

17.8 Adjusting the basic position of the shift lever -



Remove screw with the washers and take off shift lever exercises.



- Clean gear teeth A of the shift lever and shift shaft.
- Mount the shift lever on the shift shaft in the required position and engage the gearing.



Info

The range of adjustment is limited.

The shift lever must not come into contact with any other vehicle components during the shift procedure.

Mount and tighten screw with the washers.
 Guideline

Screw, shift	M6	14 Nm (10.3 lbf ft)
lever		Loctite [®] 243™

18.1 Changing the fuel screen 4



Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



Warning

Danger of poisoning Fuel is poisonous and a health hazard.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.


S02100-10



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



 Clean plug-in connection 1 of the fuel line thoroughly with compressed air.



Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve!

- Disconnect the plug-in connection of the fuel line.



Info

Remaining fuel may flow out of the fuel hose.

- Pull fuel screen 2 out of the connecting piece.
- Insert the new fuel screen all the way into the connecting niece
- Lubricate the O-ring and connect plug-in connection of the fuel line.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.
- Start the engine and check the response.

4

18.2 Checking the engine oil level

Preparatory work

Stand the motorcycle upright on a horizontal surface.



The engine is cold.

- Check the engine oil level.

The engine oil reaches the lower edge of level viewer \mathbf{A} .

- » If the engine oil does not reach the lower edge of the level viewer:
 - Add engine oil. (
 p. 128)

Condition

H01675-10

The engine is at operating temperature.

- Check the engine oil level.



Info

After switching off the engine, wait one minute before checking the level.

The engine oil is at a level between lower edge **A** and middle **B** of the level viewer.

- » If the engine oil is not at a level between lower edge and middle of the level viewer:
 - Add engine oil. (@ p. 128)

4

18.3 Changing the engine oil and oil filter, cleaning the oil screen 4



Warning

Danger of scalding Engine and gear oil get very hot when the motorcycle is ridden.

- Wear suitable protective clothing and safety gloves.
- In the event of scalding, rinse the area affected immediately with lukewarm water.



Note

Environmental hazard Hazardous substances cause environmental damage.

Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

Drain engine oil with engine at operating temperature.

Preparatory work

- Park the motorcycle on a level surface.
- Remove the engine guard. (
 p. 85)

Main work


- Place a suitable container under the engine.
- Remove oil drain plug 1 with the magnet and seal ring.



Info

Do not remove screws A.






- Remove screw plug 2 with oil screen 3 and the O-rings.
- Completely drain the engine oil.
- Thoroughly clean the parts and sealing surfaces.



- H01678-10
- Position oil screen 3 with the O-rings on a pin wrench.
- Position the pin wrench through the drill hole of the screw plug in the opposite section of the engine case.
- Push the oil screen all the way into the engine case.



Mount and tighten screw plug 2 with the O-ring. Guideline

Screw plug, oil	M20x1.5	15 Nm (11.1 lbf ft)
screen		


Mount and tighten oil drain plug 1 with the magnet and a new seal ring.

Guideline

Oil drain plug with	M12x1.5	20 Nm (14.8 lbf ft)
magnet		



 Remove screws 4. Remove the oil filter cover with the Oring.



Pull oil filter 5 out of the oil filter housing.

Lock ring plier (51012011000)

- Completely drain the engine oil.
- Thoroughly clean the parts and sealing surface.




- Lay the motorcycle on its side and fill the oil filter housing to about ½ full with engine oil.
- Place the oil filter into the oil filter housing.
- Oil the O-ring of the oil filter cover and mount it together with oil filter cover 6.
- Mount and tighten the screws.

Guideline

|--|

- Stand the motorcycle upright.
- Remove filler plug from the clutch cover together with the O-ring, and fill up with engine oil.

Engine oil	1.0 l (1.1 qt.)	Engine oil
		(SAE 10W/50)
		(🕮 p. 146)





Info

Too little engine oil or poor-quality engine oil will result in premature wear of the engine.

Mount and tighten the filler plug together with the O-ring.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.
- Start the engine and check for tightness.

Finishing work


- Check the engine oil level. (p. 125)

18.4 Adding engine oil



Info

Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



Main work

- Remove filler plug with the O-ring.
- Fill engine oil to the middle A of the level viewer.

Engine oil (SAE 10W/50) (p. 146)



Info

For optimal performance of the engine oil, do not mix different types of engine oil.

We recommended changing the engine oil when necessary.

Mount and tighten the filler plug together with the O-ring.



A00351-10

Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use an effective exhaust extraction system when starting or running the engine in an enclosed space.
- Start the engine and check for tightness.

Finishing work

•

19.1 Cleaning the motorcycle

Note

Material damage Components become damaged or destroyed if a pressure cleaner is used incorrectly. The high pressure forces water into the electrical components, connectors, throttle cables, and bearings, etc. Pressure which is too high causes malfunctions and destroys components.

- Do not direct the water jet directly on to electrical components, connectors, throttle cables or bearings.
- Maintain a minimum distance between the nozzle of the pressure cleaner and the component.
 Minimum clearance
 60 cm (23.6 in)



Note


Environmental hazard Hazardous substances cause environmental damage.

 Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.



Info

To maintain the value and appearance of the motorcycle over a long period, clean it regularly. Avoid direct sunshine when cleaning the motorcycle.



- Close off the exhaust system to keep water from entering.
- Remove coarse dirt particles with a gentle water jet.
- Spray heavily soiled parts with a normal commercial motorcycle cleaner and then brush off with a soft brush.



Info

Use warm water containing normal motorcycle cleaner and a soft sponge.

Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

- After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
- Remove the closure of the exhaust system.



Warning

Danger of accidents Moisture and dirt impair the brake system.

- Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.
- After cleaning, ride the vehicle a short distance until the engine warms up.



Info

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

- After the motorcycle has cooled down, lubricate all moving parts and pivot points.
- Clean the chain. (p. 76)

Treat bare metal (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber (p. 148)

 Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces (p. 148)

Grease steering lock.

Universal oil spray (
p. 148)


19.2 Checks and maintenance steps for winter operation



Info

If you use the vehicle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.

If the vehicle was operated in road salt, clean it with cold water after riding. Warm water would enhance the corrosive effects of salt.



- Clean the motorcycle. (
 p. 129)
- Clean the brake system.



Info

After **EVERY** trip on salted roads, thoroughly wash the brake calipers and brake linings, in the cooled down and installed state, with cold water and dry carefully. After riding on salted roads, thoroughly wash the vehicle with cold water and dry it well.

 Treat the engine, swingarm, and all other bright and zincplated parts (except for the brake discs) with a wax-based corrosion inhibitor.



Info

Corrosion inhibitor is not permitted to come in contact with the brake discs as this would greatly reduce the braking force.

- Clean the chain. (Fig. 76)

•

20.1 Storage



Warning

Danger of poisoning Fuel is poisonous and a health hazard.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- In case of skin contact, rinse the affected area with plenty of water.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing in case of fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.



Info

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed.

Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.
- Refuel. (🕮 p. 38)
- Change the engine oil and oil filter, clean the oil screen. ▲
 (♠ p. 125)
- Check the antifreeze and coolant level. (
 p. 114)
- Check the tire air pressure. (Fig. p. 101)
- Remove the battery. ◀ (🕮 p. 103)

Storage temperature of bat-	0 35 °C (32 95 °F)
tery without direct sunshine	

 Store the vehicle in a dry location that is not subject to large fluctuations in temperature.



Info

Husqvarna Motorcycles recommends raising the motorcycle.

- Raise the motorcycle with a lift stand. (
 p. 53)
- Preferably cover the vehicle with a tarp or similar cover that is permeable to air. Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.




Info

Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

•

20.2 Preparing for use after storage



- Remove the motorcycle from the lift stand. (🕮 p. 53)
- Install the battery. ◄ (≅ p. 104)
- Take a test ride.

4

Faults	Possible cause	Action
The engine cannot be cranked (electric starter)	Operating error	- Carry out the start procedure. (© p. 34)
	Battery is discharged	 Recharge the battery. ◄ (≅ p. 104)
		 Check the charging voltage.
		 Check the open-circuit current.
		 Check the stator winding of the alternator.
	Main fuse blown	 Change the main fuse. (≅ p. 106)
	Starter relay defective	 Check the starter relay. ⁴
	Starter motor defective	 Check the starter motor. ⁴
The engine turns but does not start	Operating error	Carry out the start procedure. (
	The plug-in connection of the fuel hose connection is not connected	Connect the plug-in connection of the fuel line.
	Fuse 1 blown	 Change the fuses of individual power consumers. (
	Fuse 4 blown	Change the fuses of individual power consumers. (
	Idle speed is not set correctly	 Adjust the idle speed. ◄ ((
	Spark plug oily or wet	Clean and dry the spark plug or replace if necessary.
	Electrode distance (plug gap)	 Adjust the plug gap.
	of spark plug too wide	Guideline Spark plug electrode gap 1.0 mm (0.039 in)
	Ignition system defective	 Check the ignition system. ⁴
	Short-circuit cable in wiring harness frayed, kill switch or	Check the wiring harness. (visual check)
	emergency OFF switch defective	Check the electrical system.
	Defect in fuel injection system	 Read out the fault memory using the Husqvarna Motorcycles diagnostics tool.
Engine does not speed up	Defect in fuel injection system	 Read out the fault memory using the Husqvarna Motorcycles diagnostics tool.
	Ignition system defective	 Ignition coil - check the secondary winding. ⁴
		 Check the spark plug connector.
		 Check the stator winding of the alternator.
Engine has too little power	Air filter heavily contaminated	Clean the air filter and air filter box. (♠ p. 68)
	Fuel filter is very dirty	 Change the fuel filter. ⁴
	Fuel screen is very dirty	 Change the fuel screen.

Faults	Possible cause	Act	ion
Engine has too little power	Defect in fuel injection system		Read out the fault memory using the Husqvarna Motorcycles diagnostics tool.
	Exhaust system leaky,	-	Check exhaust system for damage.
	deformed or too little glass fiber yarn filling in main silencer		Change glass fiber yarn filling in the main silencer. ◀ (p. 71)
	Valve clearance too little	_	Adjust the valve clearance.
	Ignition system defective		Ignition coil - check the secondary winding.
			Check the spark plug connector.
			Check the stator winding of the alternator. ❖
The engine dies during the trip	Lack of fuel	+	Refuel. (🗐 p. 38)
	Fuse 1 blown		Change the fuses of individual power consumers. (p. 107)
	Fuse 4 blown		Change the fuses of individual power consumers. (p. 107)
Engine overheats	Coolant level low in cooling	-	Check the cooling system for leaks.
	system	-	Check the coolant level. (p. 115)
	Insufficient airflow	_	Switch off engine when stationary.
	Radiator fins very dirty	_	Clean radiator fins.
	Foam formation in cooling sys-		Drain the coolant. ዺ (p. 116)
	tem		Refill the coolant. ◀ (🕮 p. 116)
	Bent radiator hose		Change the radiator hose. 🔦
	Thermostat defective		Check the thermostat. 4
			Guideline Opening temperature: 70 °C (158 °F)
	Defect in radiator fan system	-	Check fuse 3.
			Check the radiator fan. 4
Malfunction indicator lamp lights up or flashes	Defect in fuel injection system		Stop the motorcycle and identify the faulty part using the blink code.
			Check the cabling for damage and the electrical plug-in connectors for corrosion and damage.
			Read out the fault memory using the Husqvarna Motorcycles diagnostics tool.
High oil consumption	Engine vent hose bent		Route the vent hose without bends or replace it if necessary.
	Engine oil level too high	-	Check the engine oil level. (Fig. p. 125)
	Engine oil too thin (low viscosity)		Change the engine oil and oil filter, clean the oil screen. ♣ (p. 125)
	Piston and cylinder worn		Measure the piston/cylinder mounting clearance. ◀
Battery discharged	Battery is not being charged by alternator	_	Check the charging voltage. ❖ Check the stator winding of the alternator. ❖

Faults	Possible cause	Action
Battery discharged	Undesired power consumer	 Check the open-circuit current. ⁴
Combination instrument values deleted (time, stop watch, lap times)	The battery in the combination instrument is discharged	 Change the combination instrument. (♠ p. 112)
The high beam, low beam, tail light, position light, and license plate lamp are not working	Fuse 2 blown	 Change the fuses of individual power consumers. (
Combination instrument, horn, brake light, turn signal, and radiator fan are not working	Fuse 3 blown	 Change the fuses of individual power consumers. (

Info

The blink codes are only displayed by the derestricted version of the vehicle.

Blink code for malfunction indicator lamp		
tion indicator lamp	02a Malfunction indicator lamp flashes 2x per second	
Error level condition	Teaching of throttle valve position required	
Blink code for malfunc-	Pict.	
tion indicator lamp		
	02 Malfunction indicator lamp flashes 2x short	
Error level condition	Crankshaft position sensor - circuit fault	
Blink code for malfunc-	~	
tion indicator lamp	OC Malfore attention in director leaves flack as Countries.	
Error level condition	06 Malfunction indicator lamp flashes 6x short	
Error level condition	Throttle position sensor circuit A - input signal too low Throttle position sensor circuit A - input signal too high	
	Throttie position sensor circuit A - input signal too nigh	
Blink code for malfunc-	i co	
tion indicator lamp	09 Malfunction indicator lamp flashes 9x short	
Error level condition	Manifold absolute pressure sensor cylinder 1 - input signal too low	
	Manifold absolute pressure sensor cylinder 1 - input signal too high	
D 1.6. 16		
Blink code for malfunction indicator lamp		
tion maloutor lamp	12 Malfunction indicator lamp flashes 1x long, 2x short	
Error level condition	Engine coolant temperature sensor - input signal too low	
	Engine coolant temperature sensor - input signal too high	
Blink code for malfunc-	X .	
tion indicator lamp		
	13 Malfunction indicator lamp flashes 1x long, 3x short	
Error level condition	Intake air temperature sensor - input signal too low	
	Intake air temperature sensor - input signal too high	
Blink code for malfunc-	~	
tion indicator lamp	15 Malfunction indicator lamp flashes 1x long, 5x short	
Error level condition	Rollover sensor (A/D type) - input signal too low	
Life level condition	Rollover sensor (A/D type) - input signal too low	
	Thenever contact (VB type) imput digital too might	
Blink code for malfunc- tion indicator lamp	i co	
tion indicator famp	21 Malfunction indicator lamp flashes 2x long, 1x short	
Error level condition	Battery voltage - input voltage too high	
Blink code for malfunc-		
tion indicator lamp		
	22 Malfunction indicator lamp flashes 2x long, 2x short	
Forman Lancett and a state of	Gear position sensor – input voltage too high	
Error level condition	dear position sensor – input voltage too riigh	

Blink code for malfunction indicator lamp		
	33 Malfunction indicator lamp flashes 3x long, 3x short	
Error level condition	Injector cylinder 1 - circuit fault	
Blink code for malfunction indicator lamp	37 Malfunction indicator lamp flashes 3x long, 7x short	
	1	
Error level condition	Ignition coil 1, cylinder 1 - circuit fault	
Blink code for malfunction indicator lamp	41 Malfunction indicator lamp flashes 4x long, 1x short	
Error level condition	Fuel pump relay - short circuit to ground or open circuit	
	Fuel pump relay - input signal too low	

23.1 Engine

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	249.91 cm³ (15.2505 cu in)
Stroke	52.3 mm (2.059 in)
Bore	78 mm (3.07 in)
Compression ratio	12.8:1
Control	DOHC, four valves controlled via cam lever, drive via
	timing chain
Valve diameter, intake	32.5 mm (1.28 in)
Valve diameter, exhaust	26.5 mm (1.043 in)
Valve clearance	
Intake at: 20 °C (68 °F)	0.10 0.15 mm (0.0039 0.0059 in)
Exhaust at: 20 °C (68 °F)	0.13 0.18 mm (0.0051 0.0071 in)
Crankshaft bearing	2 cylinder bearings
Conrod bearing	Slide bearing
Piston pin bearing	Bearing bush
Pistons	Forged light alloy
Piston rings	1 compression ring, 1 oil scraper ring
Engine lubrication	Pressure circulation lubrication with two Eaton
	pumps
Primary transmission	24:73
Clutch	Multidisc clutch in oil bath/hydraulically activated
Gearbox	6-gear, claw shifted
Transmission ratio	
First gear	13:32
Second gear	16:30
Third gear	16:24
Fourth gear	23:28
Fifth gear	23:23
Sixth gear	26:20
Alternator	12 V, 196 W
Ignition	Contactless controlled fully electronic ignition with
	digital ignition adjustment
Spark plug	NGK LMAR9AI-10
Spark plug electrode gap	1.0 mm (0.039 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Starting aid	Electric starter

23.2 Engine tightening torques

[h	1	Ton (4.5 #.66)
Nozzle, crank chamber ventilation	M4	2 Nm (1.5 lbf ft) Loctite [®] 243™
Oil nozzle for alternator cooling	M4	2 Nm (1.5 lbf ft) Loctite [®] 243™
Oil nozzle for balancer shaft lubrication	M4	2 Nm (1.5 lbf ft) Loctite®243™
Oil nozzle for clutch lubrication	M4	2 Nm (1.5 lbf ft)
Oil nozzle for conrod bearing lubrication	M4	2 Nm (1.5 lbf ft) Loctite®243™
Screw, oil nozzle for piston cooling	M4	2 Nm (1.5 lbf ft) Loctite®243™
Locking screw for bearing	M5	6 Nm (4.4 lbf ft) Loctite®243™
Oil channel screw plug in alternator cover	M5	2 Nm (1.5 lbf ft) Loctite®243™
Oil nozzle for cam lever lubrication	M5	3 Nm (2.2 lbf ft) Loctite®243™
Oil nozzle, piston cooling	M5	2 Nm (1.5 lbf ft) Loctite®243™
Screw, bearing bolt, oil pump idler gear	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, clutch spring	M5	6 Nm (4.4 lbf ft)
Screw, crankshaft position sensor	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, gear position sensor	M5	5 Nm (3.7 lbf ft) Loctite®243™
Screw, locking lever	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, oil pump cover	M5	6 Nm (4.4 lbf ft) Loctite®243™
Screw, stator	M5	6 Nm (4.4 lbf ft) Loctite®243™
Nut, cylinder head	M6	10 Nm (7.4 lbf ft) Lubricated with engine oil
Nut, water pump impeller	M6	6 Nm (4.4 lbf ft) Loctite®243™
Screw, alternator cover	M6	10 Nm (7.4 lbf ft)
Screw, clutch cover	M6	10 Nm (7.4 lbf ft)
Screw, clutch slave cylinder	M6	10 Nm (7.4 lbf ft)
Screw, engine case	M6	10 Nm (7.4 lbf ft)
Screw, exhaust flange	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, oil filter cover	M6	10 Nm (7.4 lbf ft)
Screw, shift drum locating	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift lever	M6	14 Nm (10.3 lbf ft) Loctite®243™

Screw, starter motor	M6	10 Nm (7.4 lbf ft)
Screw, timing chain guide rail	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, timing chain securing guide	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, valve cover	M6	8 Nm (5.9 lbf ft)
Screw, water pump cover	M6	10 Nm (7.4 lbf ft)
Stud, cylinder head	M6	10 Nm (7.4 lbf ft)
Screw, camshaft bearing bridge	M7x1	14 Nm (10.3 lbf ft) Lubricated with engine oil
Screw plug, crankshaft location	M8	10 Nm (7.4 lbf ft)
Screw, timing chain tensioning rail	M8	15 Nm (11.1 lbf ft) Loctite®243™
Screw, engine sprocket	M10	60 Nm (44.3 lbf ft) Loctite®2701™
Plug, oil channel	M10x1	15 Nm (11.1 lbf ft) Loctite®243™
Screw plug, cam lever axis	M10x1	10 Nm (7.4 lbf ft)
Screw, rotor	M10x1	70 Nm (51.6 lbf ft) Collar and thread oiled / cone degreased
Screw, unlocking of timing chain tensioner	M10x1	8 Nm (5.9 lbf ft)
Spark plug	M10x1	10 12 Nm (7.4 8.9 lbf ft)
Engine coolant temperature sensor	M10x1.25	12 Nm (8.9 lbf ft)
Nut, cylinder head	M10x1.25	Tightening sequence: Tighten diagonally. 1st tightening stage 10 Nm (7.4 lbf ft) 2nd tightening stage 30 Nm (22.1 lbf ft) 3rd tightening stage 50 Nm (36.9 lbf ft) Thread and washer oiled with engine oil
Stud, cylinder head	M10x1.25	20 Nm (14.8 lbf ft) Loctite®243™
Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
Plug, oil pressure regulator valve	M12x1.5	20 Nm (14.8 lbf ft)
Oil drain plug	M14x1.5	15 Nm (11.1 lbf ft)
Nut, inner clutch hub	M18x1.5	100 Nm (73.8 lbf ft) Loctite [®] 243™
Nut, primary gear	M18LHx1.5	100 Nm (73.8 lbf ft) Loctite®243™
Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)
Plug, timing chain tensioner	M24x1.5	40 Nm (29.5 lbf ft)
Screw, alternator cover	M24x1.5	18 Nm (13.3 lbf ft)

23.3	Capacities
23.3.1	Engine oil

23.3.2 Coolant

Coolant	1.2 l (1.3 qt.)	Coolant (p. 146)

23.3.3 Fuel

Super unleaded (ROZ 95/RON 95/PON 91) (@ p. 147)	8.5 I (2.25 US gal)

Fuel reserve, approx.	1.5 I (1.6 qt.)
-----------------------	-----------------

23.4 Chassis

Frame	Central tube frame made of chrome molybdenum
	steel tubing
Fork	WP SuspensionXplor 48 PA
Suspension travel	
front	300 mm (11.81 in)
rear	330 mm (12.99 in)
Fork offset	22 mm (0.87 in)
Shock absorber	WP Suspension 5018 DCC Link
Brake system	Disc brakes, brake calipers on floating bearings
Brake discs - diameter	
front	260 mm (10.24 in)
rear	220 mm (8.66 in)
Brake discs - wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)
Tire air pressure off road	
front	1.0 bar (15 psi)
rear	1.0 bar (15 psi)
Road tire pressure	
front	1.5 bar (22 psi)
rear	1.8 bar (26 psi)
Final drive	14:52 (13:52)
Chain	5/8 x 1/4"
Rear sprockets available	48, 50, 52
Steering head angle	63.5°
Wheelbase	1,495 ± 10 mm (58.86 ± 0.39 in)
Seat height unloaded	970 mm (38.19 in)
Ground clearance unloaded	370 mm (14.57 in)
Weight without fuel, approx.	105.8 kg (233.2 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)

Maximum permissible overall weight 335 kg (739 lb.)

23.5 Electrical system

Battery	HJTZ5S-FP	Lithium-ion battery Battery voltage: 12 V Nominal capacity: 2.0 Ah Maintenance-free
Combination instrument battery	CR 2032	Battery voltage: 3 V
Fuse	75011088005	5 A
Fuse	75011088010	10 A
Fuse	58011109120	20 A
Headlight	HS1/socket PX43t	12 V 35/35 W
Position light	W5W / socket W2.1x9.5d	12 V 5 W
Indicator lamp	W2.3W / socket W2x4.6d	12 V 2.3 W
Turn signal	R10W / socket BA15s	12 V 10 W
Brake/tail light	LED	•
License plate lamp	LED	

23.6 Tires

Front tire Rear tire	
90/90 - 21 M/C 54M M+S TT 140/80 - 18 M/C 70M M+S TT Metzeler MCE 6 Days Extreme Metzeler MCE 6 Days Extreme	
The tires specified represent one of the possible series production tires. Additional information is available in	

The tires specified represent one of the possible series production tires. Additional information is available in the Service section under:

www.husqvarna-motorcycles.com

23.7 Fork

Fork article number	14.15.8S.61	
Fork	WP SuspensionXplor 48 PA	
Compression damping		
Comfort	18 clicks	
Standard	15 clicks	
Sport	12 clicks	
Rebound damping		
Comfort	18 clicks	
Standard	15 clicks	
Sport	12 clicks	
Spring preload - Preload Adjuster		
Comfort	+0	
Standard	+0	
Sport	+3	
Spring length with preload spacer(s)	474 mm (18.66 in)	

Spring rate	
Weight of rider: 65 75 kg (143 165 lb.)	3.8 N/mm (21.7 lb/in)
Weight of rider: 75 85 kg (165 187 lb.)	4.0 N/mm (22.8 lb/in)
Weight of rider: 85 95 kg (187 209 lb.)	4.2 N/mm (24 lb/in)
Fork length	928 mm (36.54 in)

Fork oil per fork leg	642 ± 10 ml (21.71 ± 0.34 fl. oz.)	Fork oil (SAE 4) (48601166S1)
		(₽ p. 147)

23.8 Shock absorber

Shock absorber article number	18.15.7S.69
Shock absorber	WP Suspension 5018 DCC Link
Compression damping, low-speed	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Compression damping, high-speed	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns
Rebound damping	
Comfort	17 clicks
Standard	15 clicks
Sport	13 clicks
Spring preload	14 mm (0.55 in)
Spring rate	
Weight of rider: 65 75 kg (143 165 lb.)	45 N/mm (257 lb/in)
Weight of rider: 75 85 kg (165 187 lb.)	48 N/mm (274 lb/in)
Weight of rider: 85 95 kg (187 209 lb.)	51 N/mm (291 lb/in)
Spring length	260 mm (10.24 in)
Gas pressure	10 bar (145 psi)
Static sag	35 mm (1.38 in)
Riding sag	110 mm (4.33 in)
Fitted length	477 mm (18.78 in)

Shock absorber oil	Shock absorber fluid (SAE 2.5)
	(50180751S1) (🕮 p. 147)

23.9 **Chassis tightening torques**

Remaining screws, chassis	EJOT PT® K60x25-Z	2.0 Nm (1.48 lbf ft)
Screw, combination switch	EJOT PT® K50x18	2 Nm (1.5 lbf ft)
Screw, intake air temperature sensor	EJOT PT® K50x18	2 Nm (1.5 lbf ft)
Screw, fixed grip	M4	5 Nm (3.7 lbf ft) Loctite®243™
Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)

Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)
Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)
Screw, shock absorber adjusting	M5	5 Nm (3.7 lbf ft)
ring		
Nut, cable on starter motor	M6	4 Nm (3 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Screw, ball joint of push rod on	M6	10 Nm (7.4 lbf ft)
foot brake cylinder		Loctite [®] 243™
Screw, chain sliding guard	M6	14 Nm (10.3 lbf ft)
0 ()	140	Loctite®243™
Screw, front brake disc	M6	14 Nm (10.3 lbf ft) Loctite[®]243™
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft)
Corow, roar brane dice	W.S	Loctite®243™
Screw, throttle grip	M6	5 Nm (3.7 lbf ft)
Fuel connection on fuel pump	M8	10 Nm (7.4 lbf ft)
Nut, foot brake lever stop	M8	20 Nm (14.8 lbf ft)
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft)
		Loctite [®] 2701™
Nut, rim lock	M8	12 Nm (8.9 lbf ft)
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)
Screw, bottom triple clamp	M8	15 Nm (11.1 lbf ft)
Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)
Screw, engine brace	M8	25 Nm (18.4 lbf ft)
		Loctite [®] 2701™
Screw, fork stub	M8	15 Nm (11.1 lbf ft)
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft) Loctite®243™
Caratt handlahar alama	MO	
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
Screw, manifold	M8	15 Nm (11.1 lbf ft) 35 Nm (25.8 lbf ft)
Screw, side stand attachment	M8	Loctite®2701™
Screw, subframe	M8x20	30 Nm (22.1 lbf ft)
		Loctite®2701™
Screw, subframe	M8x30	30 Nm (22.1 lbf ft)
		Loctite [®] 2701™
Screw, top steering stem	M8	17 Nm (12.5 lbf ft)
	110	Loctite®243™
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
Engine attachment bolt	M10	60 Nm (44.3 lbf ft)
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)
Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft)
		Loctite [®] 2701™

Screw, handlebar holder	M10	40 Nm (29.5 lbf ft)
		Loctite [®] 243™
Screw, top shock absorber	M10	60 Nm (44.3 lbf ft)
		Loctite [®] 2701™
Nut, fuel pump fixation	M12	15 Nm (11.1 lbf ft)
Nut, angle lever on swingarm	M14x1.5	80 Nm (59 lbf ft)
Nut, frame on linkage lever	M14x1.5	80 Nm (59 lbf ft)
Nut, linkage lever on angle lever	M14x1.5	80 Nm (59 lbf ft)
Nut, swingarm pivot	M16x1.5	100 Nm (73.8 lbf ft)
Nut, rear wheel spindle	M20x1.5	80 Nm (59 lbf ft)
Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)
Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
Screw-in nozzles, cooling system	M20x1.5	12 Nm (8.9 lbf ft)
		Loctite [®] 243™

Brake fluid DOT 4 / DOT 5.1

Standard/classification

DOT

Guideline

 Use only brake fluid that complies with the specified standard (see specifications on the container) and that exhibits the corresponding properties.

Recommended supplier

Castrol

REACT PERFORMANCE DOT 4

Motorex®

Brake Fluid DOT 5.1

Coolant

Guideline

- Only use high-grade, silicate-free coolant with corrosion inhibitor additive for aluminum motors. Low grade and unsuitable antifreeze causes corrosion, deposits and frothing.
- Do not use pure water as only coolant is able to meet the requirements needed in terms of corrosion protection and lubrication properties.
- Only use coolant that complies with the requirements stated (see specifications on the container) and that has the relevant properties.

	Antifreeze protection to at least	−25 °C (−13 °F)
--	-----------------------------------	-----------------

The mixture ratio must be adjusted to the necessary antifreeze protection. Use distilled water if the coolant needs to be diluted.

The use of premixed coolant is recommended.

Observe the coolant manufacturer specifications for antifreeze protection, dilution and miscibility (compatibility) with other coolants.

Recommended supplier

Motorex[®]

COOLANT M3.0

Engine oil (SAE 10W/50)

Standard/classification

- JASO T903 MA2 (≅ p. 149)
- SAE (□ p. 149) (SAE 10W/50)

Guideline

 Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Fully synthetic engine oil

Recommended supplier Motorex®

Cross Power 4T

Fork oil (SAE 4) (48601166S1)

Standard/classification

- SAE (🕮 p. 149) (SAE 4)

Guideline

 Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)

Standard/classification

SAE (♥ p. 149) (SAE 2.5)

Guideline

 Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Super unleaded (ROZ 95/RON 95/PON 91)

Standard/classification

- DIN EN 228 (ROZ 95/RON 95/PON 91)

Guideline

- Only use unleaded super fuel that matches or is equivalent to the specified fuel grade.
- Fuel with an ethanol content of up to 10 % (E10 fuel) is safe to use.



Info

Do **not** use fuel containing methanol (e. g. M15, M85, M100) or more than 10 % ethanol (e. g. E15, E25, E85, E100).

Air filter cleaner

Recommended supplier

Motorex[®]

Racing Bio Dirt Remover

Chain cleaner

Recommended supplier Motorex®

Chain Clean

High viscosity grease

Recommended supplier SKF®

- LGHB 2

Long-life grease

Recommended supplier Motorex®

- Bike Grease 2000

Off-road chain spray

Recommended supplier Motorex®

Chainlube Offroad

Oil for foam air filter

Recommended supplier Motorex®

- Racing Bio Liquid Power

Preserving materials for paints, metal and rubber

Recommended supplier

Motorex®

Moto Protect

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces

Recommended supplier Motorex®

Quick Cleaner

Universal oil spray

Recommended supplier Motorex®

Joker 440 Synthetic

JASO T903 MA2

Different technical development directions required a separate specification for motorcycles – the **JASO T903 MA2** standard.

Earlier, engine oils from the automobile industry were used for motorcycles because there was no separate motorcycle specification.

Whereas long service intervals are demanded for automobile engines, the focus for motorcycle engines is on high performance at high engine speeds.

In most motorcycle engines, the transmission and clutch are lubricated with the same oil.

The JASO T903 MA2 standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

27 INDEX OF SPECIAL TERMS

OBD	On-board diagnosis	Vehicle system, which monitors the specified param-
		eters of the vehicle electronics

Art. no.	Article number
ca.	circa
cf.	compare
e.g.	for example
etc.	et cetera
i.a.	inter alia
no.	number
poss.	possibly

29.1 Yellow and orange symbols

Yellow and orange symbols indicate an error condition that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

Q	Malfunction indicator lamp lights up/flashes yellow – The OBD has detected an error in the vehicle electronics. Come safely to a halt, and contact an authorized Husqvarna Motorcycles workshop.
	The fuel level warning lamp lights up yellow – The fuel level has reached the reserve mark.

29.2 Green and blue symbols

Green and blue symbols reflect information.

	The high beam indicator lamp lights up blue – The high beam is switched on.
(+ + +)	Turn signal indicator lamp flashes green – The turn signal is switched on.

A	Chain guide
Accessories	checking
Air filter	Chain tension adjusting
cleaning	checking
installing	Characteristic map of the throttle response
removing	adjusting
Air filter box	Chassis number
cleaning	
sealing	Clutch
Air filter box cover	fluid level, checking/correcting
installing 67	
removing 67	Clutch lever
Antifreeze	
checking 114	Cold start button
Auxiliary substances	Combination instrument
В	adjusting
	adjusting the clock
Basic chassis setting checking with rider's weight 43	battery, changing
	message
Battery installing	overview
recharging	service display, adjusting
removing	Compression damping
starting power	fork, adjusting
Blink code	Coolant
Brake discs	antifreeze and coolant level, checking 114
checking	draining 116
Brake fluid	level, checking 115
front brake, adding 87	refilling 116
of rear brake, adding	Cooling system
Brake fluid level	Customer service
front brake, checking	D
rear brake, checking	Diagnostics connector
Brake linings	Difficult operating conditions
front brake, changing	dry sand 32
front brake, checking	high temperatures
of rear brake, changing	low temperature
rear brake, checking 94	muddy surfaces
Brake system	slow speed
C	wet sand
Capacity	wet surfaces
coolant	Difficult riding conditions
engine oil	•
Chain	E
checking	Electric starter button
cleaning	Emergency OFF switch
	Engine
	running-in

Engine guard	Н
installing	Hand brake lever
Engine number	Handlebar position 51
Engine oil	adjusting
adding 128	Headlight
changing125	range, adjusting
Engine oil level	Headlight adjustment
checking	checking
Engine sprocket	Headlight bulb
checking	changing
Environment	Headlight mask with headlight
F	installing
Figures	removing 109
Filler cap	High-speed compression damping
closing 19	shock absorber, adjusting 44
opening	Horn button
Filling up fuel	
Foot brake lever	Idle speed
basic position, adjusting	adjusting 121
free travel, checking	Idle speed adjusting screw 20
Fork legs	Implied warranty
basic setting, checking 48	Indicator lamps overview
bleeding	Intended use 7
dust boots, cleaning 54	K
installing 56	Key number
removing	Kill switch
spring preload, adjusting 50	L
Fork protector	Light switch
installing	Lower triple clamp
ŭ	installing
Frame checking 81	removing 56
Front fender	Low-speed compression damping
installing 62	shock absorber, adjusting 43
removing	M
Front wheel	Main fuse
installing	changing 106
removing	Main silencer
Fuel screen	glass fiber yarn filling, changing
changing 124	installing
Fuel tank	removing
installing 74	Mapping abording 121
removing	changing
Fuse	Misuse 7 Motorcycle
individual power consumers, changing 107	cleaning
main fuse, changing	120

lift stand, raising with	Shock absorber
removing from lift stand	installing
0	riding sag, checking
Oil filter	spring preload, adjusting 47
changing	static sag, checking 46
Oil screen cleaning	Side stand
Operating substances	Spare parts
Owner's Manual 9	Spoke tension checking
P	Starting
Play in throttle cable	Starting power of lithium-ion batteries at low
adjusting	temperatures 31
checking	Steering
Preparing for use	locking
advice on first use	unlocking
after storage	Steering head bearing
preparing for use	lubricating 61
Protective clothing 9	Steering head bearing play adjusting 60
R	checking
	Storage
Rear sprocket checking	Swingarm
Rear wheel	checking
installing	Т
removing	Technical data
Rebound damping	capacities 141
fork, adjusting	chassis
shock absorber, adjusting 45	chassis tightening torques
Riding sag adjusting 48	electrical system
Right side cover	engine tightening torques
installing	fork
removing	shock absorber
Rubber grip	tires
checking 82	Throttle cable routing checking
S	Throttle grip
Safe operation 8	Throttle valve position
Seat	teaching
mounting	Tire air pressure
removing	checking
Service 10 Service schedule 40-42	Tire condition
Shift lever	checking 101
basic position, adjusting	Traction control
basic position, checking	activating 35
	Transporting
	Troubleshooting



Turn signal bulb
changing111
Turn signal switch
Type label
U
Use definition
V
View of vehicle
front left
rear right
W
Warranty
Winter operation checks and maintenance steps 130
Work rules



3402245en

05/2018



