2010 OWNER'S MANUAL

ZERO ST

ZERO DS"



Table Of Contents

ntroduction	1-1
An Important Message To You From Zero	o 1-1
Introduction	1-1
Index	1-1
Useful Information For Safe Riding.	1-2
Plug In Your Power Pack	1-2
Owner Information	1-3
Vehicle Identification Number (VIN)	1-4
VIN Location	1-4
VIN Break Down	1-4
General Information	1-6
Zero S Technical Specifications	1-6
Zero DS Technical Specifications	1-7
Vehicle Range	1-9
Optimizing Your Range By Adapting	Your
Riding Style	1-9
Public Charging Stations	1-10
Emissions Information	1-10
Transporting	1-11

Safety Information	2-
General Safety Precautions	2-
Important Operating Information	2-
Location Of Important Labels	2-
Power Pack Information Label	2-
Throttle And Speed Control Label	2-
Power Pack Labels	2-
Power Pack (Battery) Fuse Label	2-
Main Power Cut-Off Label	2-
Performance Specifications/	
Operation Guidelines	2-
Performance Envelope	2-
Z-Force Air Induction System	2-
System Error Indicator	2-
Controls And Components	3-
Motorcycle Controls	3-
Left Side View	3-

Right Side View	3-5
Instrument Panel	3-7
Indicators	3-8
Handlebar Controls	3-9
Starting And Operating	4-1
First Time Set-Up	4-1
Uncrating Your Motorcycle	4-2
General Operation	4-4
Pre-Ride Inspection	4-4
Key Switch Positions	4-5
Fork Lock	4-5
Main Power Cut-Off	4-6
Power Pack	4-7
Operating Your Motorcycle	4-14
Suspension Adjustment	4-15
Maintaining Your Motorcycle	5-1
Owner's Responsibilities	5-1
Bolt Torque Table	5-2
Power Pack	5-5
General Maintenance	5-6
Motor	5-6
Brakes	5-6

Suspension	5-8
Wheels And Tires	5-8
Tire Inflation	5-9
Chain	5-10
Headlamp Alignment	5-13
Headlamp Bulb Replacement	5-14
Turn Signal Bulb Replacement	5-16
Stop/Tail Lamp Bulb Replacement	5-16
Running Lamp Bulb Replacement	5-17
Cleaning	5-18
Parking And Long Term Storage	5-19
Maintenance Schedule	5-20
Parts/Maintenance Items	5-23
Accessories	5-23
Fuses	5-23
Troubleshooting	6-1
Power Pack And Charger	6-1
Understanding Beep Sequences	6-3
Safety Interlocks	6-6
General Troubleshooting	6-11

Warranty/Customer Assistance	7-1
Customer Assistance	7-1
Warranty Information	7-2
Zero Motorcycles Limited Warranties	7-3
Standard Warranty	7-3
Extended Warranty	7-4
No Fault Warranty	7-5
Disclaimers Applicable to Standard	
Warranty, Extended Warranty and	
No Fault Warranty	7-5
Proper Use	7-6
Purchaser's Responsibilities	
Warranty Procedures	7-7
Transfer Of Ownership And Warranty .	7-8

NOTES		
TOC-4		

Introduction

An Important Message To You From Zero

Congratulations and thank you for purchasing the 2010 Zero S/DS electric motorcycle; we welcome you to the community of Zero Motorcycle riders. This manual is designed to provide you with a better understanding of the operation, inspection, and basic maintenance requirements of this motorcycle. Zero continually seeks advancements in product design and quality. Therefore, this manual contains the most current product information available at the time of printing. Because of this, your motorcycle may differ from the information supplied in this owner's manual. No legal claims can be made on the basis of data in this manual. When it comes time to sell your Zero motorcycle, please remember to hand over this manual; it is, by law, an important part of the vehicle. If you have any questions concerning the operation or maintenance of your motorcycle, please contact Zero at support@zeromotorcycles.com.

Introduction Index

A good place to locate information about the motorcycle is in the index in the back of the manual. The terms "right" or "left" refer to the rider's right or left when sitting on the motorcycle.

Useful Information For Safe Riding

This manual contains the word CAUTION to tell about something that could hurt you or others. It also contains the word WARNING to tell about things that could damage your motorcycle.

CAUTION: Please read this manual carefully and completely before operating this motorcycle. Do not attempt to operate this motorcycle until you have attained adequate knowledge of its controls and operating features, and until you have been trained in safe and proper riding techniques. Regular inspections and careful maintenance, along with good riding skills, will help you to safely enjoy the capabilities and the reliability of this motorcycle. Disregarding them may render the warranty invalid.

Plug in Your Power Pack

WARNING: Proper care of the motorcycle's power pack is essential! When not in use, the power pack should be left on the charger even if fully charged. Failure to do so could damage the power pack and therefore void your battery warranty. See page 4-7 for other important information about the power pack.


Owner Information

Record important information here pertaining to your motorcycle. When contacting your Certified Service Center (CSC) you may need to provide this information.

CSC Information	Motorcycle Information
Address	VIN
	Model
Telephone No	Battery Serial Number
E-mail	
	Date of Purchase

Vehicle Identification Number (VIN)


VIN Location



See Location Of Important Labels on page 2-3.

VIN Break Down

The VIN is a 17-digit number stamped on the head tube of the frame. Do not alter or remove this number as it is the legal identifier for your motorcycle.



General Information

Zero S Technical Specifications

MOTOR		
Туре	Brushed permanent magnetic electric	
Est. Top Speed	108 km/h (67 mph)	
POWER SYSTEM		
Туре	Patent-pending lithium ion array	
Capacity	4 kwh (58 V @ 70 Ah)	
Range	Up to 80 km (50 miles)	
Recharge Time	Less than 4 hours	
Input	Standard 110 V AC or 220 V AC	
DRIVETRAIN		
Transmission	Clutchless one speed	
Drive System	16T/53T Sprocket, 420 Chain	

CHASSIS/SUSPENSION/BRAKES		
Front Suspension Travel	203.2 mm (8 in)	
Rear Suspension Travel	203.2 mm (8 in)	
Front Brakes	2 Piston Hydraulic, Stainless Rotor, Hand Actuated	
Rear Brakes	1 Piston Hydraulic, Stainless Rotor, Foot Actuated	
Front Tire	110/70-16 in	
Rear Tire	140/70-16 in	
Front Wheel	16 x 3.0 in	
Rear Wheel	16 x 4.0 in	

DIMENSIONS		
Wheel Base	144.3 cm (56.8 in)	
Seat Height (Standard)	86.4 cm (34 in)	
Low Seat Height (Option)	81.3 cm (32 in)	
Rake	22 degrees	
Steering Angle	+35 degrees, -35 degrees	
Trail	82.8 mm (3.26 in)	
WEIGHT		
Frame	8.16 kg (18 pounds)	
Power Pack	43.1 kg (95 pounds)	
Curb Weight	123.8 kg (273 pounds)	
GVWR	260.8 kg (575 pounds)	
Carrying Capacity	136.0 kg (302 pounds)	
ECONOMY		
Typical Cost to Recharge	Less than \$.01 per mile or kilometer	

Zero DS Technical Specifications

MOTOR		
Туре	Brushed permanent magnetic electric	
Est. Top Speed	108 km/h (67 mph)	
POWER SYSTEM		
Туре	Patent-pending lithium ion array	
Capacity	4 kwh (58 V @ 70 Ah)	
Range	Up to 80 km (50 miles)	
Recharge Time	Less than 4 hours	
Input	Standard 110 V AC or 220 V AC	

DRIVETRAIN		
Transmission	Clutchless one speed	
Drive System	16T/53T Sprockets, 420 Chain	
CHASSIS/SUSPENSION/BRAKES		
Front Suspension Travel	228.6 mm (9 in)	
Rear Suspension Travel	203.2 mm (8 in)	
Front Brakes	2 Piston Hydraulic, Stainless Rotor, Hand Actuated	
Rear Brakes	1 Piston Hydraulic, Stainless Rotor, Foot Actuated	
Front Tire	3.25-17 in	
Rear Tire	110/90-16 in	
Front Wheel	17 x 2.15 in	
Rear Wheel	16 x 3.0 in	

DIMENSIONS					
Wheel Base	146.8 cm (56.75 in)				
Seat Height (Standard)	88.9 cm (35 in)				
Low Seat Height (Optional)	83.8 cm (33 in)				
Rake	24 degrees				
Trail	82.8 mm (3.26 in)				
Steering Angle	+35 degrees, -35 degrees				
WEIGHT					
Frame	8.16 kg (18 pounds)				
Power Pack	43.1 kg (95 pounds)				
Curb Weight	125.6 kg (277 pounds)				
GVWR	260.8 kg (575 pounds)				
Carrying Capacity	134.7 kg (297 pounds)				
ECONOMY					
Typical Cost to Recharge	Less than \$.01 per mile or kilometer				

Vehicle Range

The range of an electric vehicle is defined as the distance the vehicle will travel on a single full charge of the power pack. Just like EPA mileage estimates on an automobile, "your mileage may vary." Your range results are a direct reflection of your riding habits. The more conservative you ride the better range you can expect from your Zero S/DS Motorcycle.

Some of the factors which affect range include speed, acceleration, number of starts and stops, as well as changes in elevation. The combination of these factors, as you travel from one point to another, defines your trip profile. In addition, tire pressure and payload are important considerations.

We suggest that you ride conservatively when you first get your Zero S/DS motorcycle and get to know your motorcycle and your commute. Once you become familiar with the range versus performance of your motorcycle then you can adjust your riding characteristics if you so desire. This applies mainly to riders with trip profiles which are at the edge of the performance envelope. Those of you with relatively short commutes can expect to ride quite aggressively and reach your destination with energy to spare.

An average rider can expect to achieve 64 km (40 miles) of average range under normal use (stop and go traffic), with a maximum range of 97 km (60 miles) of steady riding at 40 km/h (25 mph). You can expect to achieve 48 km (30 miles) of range on the freeway of steady riding at 89 km/h (55 mph).

Optimizing Your Range By Adapting Your Riding Style

- Apply the throttle slowly and try to match the motorcycle's acceleration with your throttle position.
- Hard acceleration will cause a voltage drop, thereby making the energy gauge drop significantly; the gauge should recover when you roll off the throttle.
- If 108 km/h (67 mph) can be reached at 100% throttle, 75% throttle will give you about 89-95 km/h (55-59 mph) (a 25% energy savings for an approximate 12% speed loss).
- Coasting whenever possible makes a significant difference; the motorcycle will coast for a long distance (take advantage of this).

Public Charging Stations

There are more public charging stations coming online every day and there may be some in your area. These stations are often available at a variety of locations including shopping centers, city parking lots, airports, hotels, government offices, and other businesses. We recommend that you search the internet for locations in your area. For example, search for "charging stations."

Emissions Information

The Zero S/DS electric motorcycle is a true freeway capable zero emissions vehicle under California (CARB), U.S. Federal (EPA), and European Union standards. It uses no gasoline or other liquid fuel. It has no tailpipe and therefore no tailpipe emissions. It also has no exhaust or evaporative emissions. Because the Zero S/DS runs solely on electricity, it is the only kind of vehicle which actually gets cleaner in terms of air pollution each year, as the electricity grid gets cleaner and more renewable. Zero Emissions Vehicles (ZEV's) offer greater efficiency, and can help solve the serious air pollution, global warming, and energy security problems facing the country and the world.

Emissions

The Zero S and DS do not require any gasoline and, as a result, do not get 'miles per gallon.' For the sake of emissions comparisons, the EPA estimates there to be about 33.705 kilowatt hours in one gallon of gasoline (33.705 kwh/gal). When operating a Zero S or DS we estimate that you will use 3.7 kwh before recharging. Based on the EPA estimate, 3.7 kwh is equivalent to .10978 gallons. With that .10978 gallons a rider can travel up to 80 kilometers (50 miles). This means that the Zero S or DS achieves incredible efficiency at 455.45 MPG.

Calculation


EPA Electric vs. Gas Equivalent: 33.705 kwh/gal Energy used riding the Zero S/DS: 3.7 kwh Range of the Zero S/DS: 50 miles MPG= 50 miles/[3.7 kwh/33.705 kwh] MPG= 455.45

WARNING! Please use only Zero approved parts and accessories for your Zero motorcycle. Parts and products for your Zero motorcycle have been checked and tested for safety and suitability. Zero is unable to accept any liability whatsoever for parts and accessories which have not been approved.


Transporting

When the front fork is compressed, the built up pressure must be released to help prevent fork seal leaks. There is a 3 mm Allen "bleed" screw located just in front of the rebound adjuster on each fork leg. This "bleed" screw (A) is used to release the built up pressure. Loosen the screw slowly, but do not remove. Once all the air is out, tighten the bleed screw.


When the fork is released, with no weight on the front tire, the screw must be opened again to allow for stabilization. Ensure that the screw is tightened before riding.



It is recommended that the motorcycle be tied-down using ratchet straps and a fork support (A) to prevent fork damage. Place the ratchet straps around the frame or a solidly mounted part. Soft straps must be used to prevent scratches or other damage.



Use two ratchet straps in the front and two in the rear. The tie down straps should be at a 45° angle from the motorcycle. Follow the manufacturer's instructions for the ratchet straps you are using.



NOTES	
	1 12

NOTES			
1 1 1 1			

Safety Information

General Safety Precautions

- This is a performance motorcycle and should be treated with extreme caution.
- 2. Proper safety gear, including a DOT approved helmet, riding boots, gloves, and protective clothing should be worn while riding to reduce the risk of potential injury. We highly recommend the use of full height riding boots since the vast majority of motorcycle injuries are leg and foot injuries. It is not recommended to ride without protective clothing; this applies to even short journeys, and to every season of the year.
- 3. Read all additional warnings and product instructions in this owner's manual, and safety labels, before operating the electric motorcycle.
- Never carry a passenger. This motorcycle is designed for a SINGLE RIDER ONLY.
- Never permit a guest to ride your electric motorcycle without proper instruction. These are performance motorcycles and should be treated with extreme caution.

- Do not ride on wet, frozen, oily or pitted surfaces. Avoid potholes, surface cracks, and other obstacles.
- Never use alcohol or mind-altering drugs before operating an electric motorcycle.
- Persons unwilling or unable to take responsibility for their actions should not use this motorcycle. You assume all responsibility while operating your motorcycle. The seller will assume no liability for misuse or operator negligence.
- Prior to each use the rider must check everything in the "every ride" column of the maintenance schedules on pages 5-20 through 5-22, and the power pack function level as indicated on the instrument panel energy gauge.
- 10. Your safety depends in part on the good mechanical condition of the motorcycle. Be sure to follow the maintenance schedule and adjustment requirements contained in this manual. Be sure you understand the importance of checking all items thoroughly before riding.

- Modifications of the motorcycle may render the vehicle unsafe and may cause severe personal injury. Zero Motorcycles cannot be held liable for non-approved modifications.
- 12. Be very careful when loading or adding accessories to your motorcycle. Large, bulky, or heavy items may adversely affect the handling and performance of your motorcycle.
- 13. Failure to follow battery storage and charging instructions, as described in this Zero Motorcycles Owner's Manual, may void the warranty of your Zero motorcycle. These guidelines have been rigorously tested to ensure maximum battery efficiency and service.

Important Operating Information

 Always turn the key switch and the kill switch to the OFF position when not actively riding. It is very easy to forget that the motorcycle is powered up because it is silent. An accident can occur if the motorcycle is left powered up while getting on or off the motorcycle.

- Switch the power OFF when backing up or pushing the motorcycle while dismounted. It is possible to unintentionally twist the throttle, resulting in unexpected acceleration.
- 3. Use the rear brake when you are stopped on an incline. Do not hold the motorcycle using partial throttle or damage to the motor may occur.
- The Zero S/DS power pack should be plugged in when storing the motorcycle for extended periods of time.
- 5. Keep your Zero S/DS connected to the charger when your motorcycle is sitting in storage or if it will be sitting unused for more than 7 days.

WARNING: Charge the Zero power pack with the Zero charger.


The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged. Zero recommends that you plug in your Zero motorcycle after 7 days even if charged. Please leave your Zero motorcycle plugged in whenever possible.

- Always firmly apply the rear brake while turning the key switch ON or OFF. In the event of a malfunction, the firm application of the rear brake will help keep the motorcycle from running away.
- 7. The power pack does not require or tolerate deep discharging. To get the most power pack life, recharge each power pack immediately after each ride. Leaving a power pack in a discharged state will cause damage. See Charging The Power Pack on page 4-12.

Location Of Important Labels

The Vehicle Certification Label contains the following information:

- Gross Vehicle Weight Rating (GVWR)
- · Gross Axle Weight Rating (GAWR) Front and Rear
- Vehicle Identification Number (VIN)
- Rim Size
- Tire Pressures
- Manufactured Date



- A. Vehicle Certification Label
- B. Power Pack Information Label
- C. Throttle and Speed Control Label
- D. Vehicle Identification Number (VIN) Label. See Vehicle Identification Number (VIN) on page 1-4.

Power Pack Information Label

IMPORTANT POWER PACK INFORMATION



• Before operating the motorcycle you must fully charge the power pack

• YOU MUST NEVER LEAVE THE POWER PACK UNPLUGGED/OFF THE CHARGER. **FOR MORE THAN 7 DAYS**

- Leaving the power pack unplugged for more than 7 days can cause irreparable harm to the power pack and may void your warranty.
- Always leave the power pack plugged in when not in use
- The power pack can remain plugged in for an indefinite amount of time
- Over long durations the charger will monitor and maintain proper voltages within the power pack.

Please read the owner's manual for more information prior to operating the motorcycle.

Throttle And Speed Control Label



IMPORTANT

THROTTLE AND SPEED CONTROL

The fully electric drivetrain of this motorcycle is different than any gas counterpart:


- There is no engine braking and no engine noise
- When going into corners or coming to a stop you will be fully dependent on your brakes
- It is easy to find yourself speeding due to the absence of engine noise
- Passersby will not hear your approach - be extra cautious when making turns, entering intersections or when people are likely to cross your path

Be aware that your motorcycle is still ON during stops and while at an "idle". Accidently twisting the throttle can cause serious harm.
Please read the user manual

for more information prior to operating the motorcycle.


IMPORTANT


Power Pack Labels



Power Pack (Battery) Fuse Label

Main Power Cut-Off Label





Performance Specifications/ Operation Guidelines


The Zero S/DS motorcycle is designed to provide many years of trouble free commuting and riding excellence. Please read the information below to get a sense for the motorcycle's performance abilities and limitations.

Performance Envelope

- An average rider can expect to achieve 64 km (40 miles) of average range under normal use (stop and go traffic), with a maximum range of 97 km (60 miles) of steady riding at 40 km/h (25 mph). You can expect to achieve 48 km (30 miles) of range on the freeway of steady riding at 89 km/h (55 mph).
- The Zero S/DS has the ability to start, from a standstill, up a steep 10% grade when fully loaded. It is not recommended that you stop on a grade of more than 10% with a fully loaded motorcycle.


Z-Force Air Induction System

The air induction system is a compact forced air delivery system. It consists of a powerful low maintenance fan motor (A) located under the rear fender. The fan is connected to the motor by means of a flexible duct. The system allows the motor to run cooler and increase power by efficiently moving air through the motor core. The fan is automatically controlled by the motorcycle control unit and will turn on as the motor temperature increases. In the unlikely event that you exceed the motorcycle's performance capabilities, the motor warning system will activate. See System Error Indicator on page 2-8.



System Error Indicator

The Zero S/DS is equipped with a motor brush carrier temperature error indicator. In the unlikely event that you exceed the motorcycle's performance capabilities, it will provide you with an illuminated lamp (A) in three distinct stages:



Stage 1

The brush carrier begins to reach an undesirable temperature:

- A slow blink is clearly seen on the dash-mounted warning indicator.
- You can continue to ride without performance interruptions.
- You should reduce speed this will lower power output and the brush carrier temperature to eliminate the blinking warning indicator.

Stage 2

If the brush carrier continues to heat up:

- A fast blink is clearly seen on the dash-mounted warning indicator.
- The power to the motor begins to drop off, resulting in a noticeable reduction in available torque. This provides tactile feedback to the rider and also helps prevent the motor from heating further. As the motor cools again, full-power will be restored.

- At this point it is strongly recommended that you reduce your speed and consider finding a safe area to exit the road.
- You may still have time to back off the throttle to reduce heat. This will restore full power to the motor and eliminate the warning indicator.

Stage 3

If the critical temperature threshold of the brush carrier is reached:

You will not reach this stage without knowingly ignoring stage 1 and stage 2.


- A ten second sequence of close intervals of rapid pulsing will be visible on the warning indicator and then power to the motor will be disabled.
- You must quickly find a safe place to park the motorcycle off of the road.
- When power to the motor is disabled the warning indicator goes solid.

- The brush carrier should take no longer than about 10 minutes to cool.
- When the warning indicator turns off you can safely operate the motorcycle again.
- Use the throttle sparingly at first to ensure that the brush carrier does not overheat.

NOTES			
2-10			

Controls And Components

Motorcycle Controls



A. Mirrors

This motorcycle is equipped with convex mirrors. A convex mirror has a curved surface. Convex mirrors offer a greater field of view than a similar flat mirror. However, the greater field of view makes objects seem further away than they really are. Care must be used when judging the distance of objects seen in these mirrors.


- B. Fork LockFor description and operation see page 4-5.
- C. Instrument Panel
 For description and operation see pages 3-7 and 3-8.
- D. Warning IndicatorSee System Error Indicator on page 2-8.
- E. Front Brake Fluid Reservoir/Master Cylinder For description and operation see Brakes on page 5-6.

F. Front Brake Lever

The front brake lever controls the front brake when the lever is squeezed. When braking, the throttle should be in the neutral/returned position. The stop lamp will illuminate when the brake lever is applied.

- G. Left Handlebar Control For description and operation see pages 3-9 and 3-10.
- H. Key Switch For description and operation see page 4-5.
- Right Handlebar Control For description and operation see pages 3-9 and 3-10.

Left Side View



A. Headlamp

- For headlamp operation, see Handlebar Controls on page 3-10.
- For headlamp bulb replacement, see Headlamp Bulb Replacement on page 5-14.
- For headlamp alignment, see Headlamp Alignment on page 5-13.
- B. Main Power Cut-Off
 For description and operation, see page 4-6.
- C. Stop/Tail Lamp For stop/tail lamp bulb replacement, see Stop/Tail Lamp Bulb Replacement on pages 5-16 and 5-17.

D, E. Turn Signals


- For turn signal operation, see Handlebar Controls on page 3-10.
- For turn signal bulb replacement, see Turn Signal Bulb Replacement on page 5-16.

- F. AC Charger Power Connection For description and operation, see Charging The Power Pack on page 4-12.
- G. On-Board Battery Charger For description and operation, see Battery Charger on pages 4-9 and 4-10.
- H. Kickstand Switch
 This switch is a safety feature that prevents motor
 operation when the kickstand is down. If the
 kickstand were down when riding it could contact
 the ground causing you to lose control of the
 motorcycle and cause personal injury.

WARNING: Park only on a flat firm surface otherwise the motorcycle could fall over causing damage.


Kickstand
The kickstand swings out from the side and supports the motorcycle when parked. The key switch should be in the OFF position when parked.

Right Side View




- A Rear Brake Fluid Reservoir See Rear Brake on page 5-7.
- B. Drive Chain Adjuster
 See Drive Chain Adjustment Procedure on page 5-12.
- C. Rear Brake Pedal The rear brake pedal controls the rear brake when the pedal is pressed. When braking, the throttle should be in the neutral/returned position. The stop lamp will illuminate when the rear brake pedal is applied.
- D. Power PackFor description and operation see page 4-7.

Instrument Panel



Indicators



A and F. Turn Signals
An arrow on the instrument
panel will flash green in the
same direction as selected by
the turn signal switch. This will
remain on until the turn signal
request has been canceled.



B. High Beam
When the headlamp high
beams are on, this indicator
will illuminate blue and will
remain on until the high
beams are turned off

C. Speedometer

The speedometer is an analog and digital display in either kilometers per hour (km/h) or miles per hour (mph).

D. Main Power Indicator

The main power indicator is OFF any time the key is in the ON position. If the main power indicator is flashing, the system has detected a fault. For troubleshooting, see pages 6-9 and 6-10.

E. Energy Gauge

This bar graph displays the amount of energy remaining in the power pack, similar to the fuel gauge on a gasoline powered vehicle.

G. Select Button

By pressing the select button you can change the display units that appear on the instrument panel between English or Metric.

H. Adjust Button

By pressing the adjust button you can toggle between the trip odometer settings. Holding it down will clear the trip odometer resetting it back to zero.

I. Warning Indicator

This motor brush carrier temperature error indicator will blink in the unlikely event that you exceed the motorcycle's performance capabilities. See System Error Indicator on page 2-8 for more information.


J. Trip Odometer

The trip odometer displays individual trip mileage, and is reset by pressing and holding the Adjust button.

K. Odometer


The odometer displays the total distance the motorcycle has been ridden in kilometers or miles.

Handlebar Controls



A. Flash-to-Pass

When the headlamp is in the low beam position, push the flash-to-pass switch and the high beam will illuminate and will stay illuminated until the switch is released. When released, this switch will default back to the low beam position. The high beam indicator will also illuminate.



B. Headlamp High/Low Beam Switch

When the switch is pushed, the headlamp will change from low beam to high beam. It will stay in the selected position until it is switched back. When in high beam position, the high beam

indicator on the handlebar control and the high beam indicator on the instrument panel will illuminate.

C. Front Brake Lever

The front brake lever controls the front brake when the lever is squeezed. When braking, the throttle should be in the neutral/returned position. The stop lamp will also illuminate.

D. High Beam Indicator

When the headlamp is in high beam position or the flash-to-pass switch is pressed this indicator will illuminate.

E. Horn Switch


When the key is in the ON position, the horn will sound when the switch is pressed. Electric vehicles run quietly; the horn can be used to warn pedestrians or other motorists of your presence.



F. Turn Signal Switch When the turn signal switch is pushed in the left or right position, the corresponding front and rear turn signal will flash. When the turn signal switch is ON, the corresponding turn signal indicator

on the instrument panel will illuminate.

Always signal your turns and other maneuvers as required by law. Unlike an automobile, the turn signals must always be cancelled manually on the motorcycle. Push in on the switch and it will return to the center or OFF position.




G. Kill Switch

When the switch (A) is pressed, it will kill power to the motor controller. The motor controller will remain in this state until the ON (B) button is pressed. The switch does not turn off all electrical circuits, just the operation of the motor.

H. Throttle Control

Twist the throttle in a counter-clockwise rotation (A) to energize the motor and start the motorcycle in a forward direction. Release the throttle and it will snap back to the neutral/returned position (B), de-energizing the motor.



DTES	
•	

Starting And Operating

First Time Set-Up

If your motorcycle was direct shipped you will need to perform the following:

- Remove the motorcycle from its shipping crate.
 See Uncrating Your Motorcycle on page 4-2.
- You must charge the power pack before riding the motorcycle. See Charging The Power Pack on page 4-12.
- Identify and inspect the wheels and brakes for leaks or irregularities.
- Check the tire pressure and adjust to proper specifications. See Tire Inflation on page 5-9.


- Inspect the hydraulic brake system. Follow the hydraulic line from the reservoirs to the calipers and verify that there are no leaks or damage to the brake lines. Verify that the brakes function properly.
- Make sure the motorcycle key switch is OFF, then twist the throttle to make sure it's rotation is smooth and returns correctly.
- Inspect bolts and make sure they are tight. See Bolt Torque Table on page 5-2. Double check the fork, wheel, and brake bolts.
- 8. Insert the key in the key switch, engage the rear brake and turn the key to the ON position. The energy gauge should read fully charged.

Uncrating Your Motorcycle


The S/DS motorcycle arrives almost entirely assembled. It is recommended that you have an assistant to help with the uncrating procedure. We advise wearing protective gloves and protective eyewear when uncrating the Zero motorcycle. It is possible during shipping that sharp edges or points may occur, please use caution. Retain the crate and all other shipping items for future shipping of the motorcycle.

Note: The shipping crate may differ slightly than shown, below are general guidelines for uncrating the motorcycle.


- 1. Remove the crate clamps (A) and remove the crate end panel (B).
- With the aid of an assistant, lift and move (C) the crate off of the base.



- 3. With the assistant holding the motorcycle upright, remove the ratchet straps (B).
- 4. Fold down the ramp (A) and lower the protective plastic.



Remove the fork support (A), located between the wheel and front fender.



- 6. Carefully roll the motorcycle off of the crate base.
- 7. Secure and adjust the mirrors.

General Operation

Pre-Ride Inspection

Before operating the Zero S/DS motorcycle, check the following to make sure the motorcycle is secure and intact:

Power Pack

Make sure the onboard energy gauge is indicating a charged power pack. If the energy gauge reads below 6 bars (1/2), we suggest you recharge before use. Always keep the charger cord with the motorcycle.

Drive Chain

Check chain slack and condition. Adjust and lubricate if necessary. The drive chain must be cleaned and lubricated at the intervals specified in the maintenance schedule; otherwise it will quickly wear out, especially when riding in dusty or wet areas. See Chain on page 5-10.

Brakes

Squeeze the brake lever and press the brake pedal individually while pushing the motorcycle to see if it rolls. You should be able to lock-up the wheels completely by applying the brakes.

Throttle

With the key switch in the OFF position, apply the throttle and release to verify that the throttle is smooth and returns correctly.

Tires


Check both tires for condition and tread depth. Check cold tire pressure frequently. Check for damage and alignment. Maintain correct tire pressure as specified on page 5-9. Replace the tires when the tread height is 2 mm (0.08 in) or less.

CAUTION: Under-inflation is the most common cause of tire failure and may result in severe tire cracking, tread separation, "blowout," or unexpected loss of motorcycle control causing personal injury and possible death.

Electrical System

Check for correct function of the headlamp, turn signals, and the stop/tail lamps.

Key Switch Positions



This is a two-position switch that is located on the top/front of the motorcycle below the handlebar. The switch positions are as follows:

- OFF
- ON

The key should be removed from the motorcycle when parked to prevent theft.

There is a red dot (A) indicating the ON position. The key (B) can be folded down.

Fork Lock

CAUTION: Do not operate the motorcycle with the fork locked. This will prevent the motorcycle's ability to steer and could cause personal injury.


Using the fork lock when parked will prevent unauthorized use and help prevent theft. The fork lock key is different from the key switch key.

To Lock

- 1. Turn the fork all the way to the left.
- Insert the key (A) into the lock (see image on page 4-6) then turn the key clockwise and remove the key. The fork should not turn.

To Unlock

1. Install the key and turn counter-clockwise.




Remove the key. Never ride with the key in the fork lock.

Main Power Cut-Off

The main power cut-off switch (A) is located on the left rear of the Z-Force power pack. This is a slide switch. This switch is used to connect or disconnect the Z-Force power pack from the motorcycle. When the switch is slid down to OFF (disconnected) all electricity to the motorcycle is turned off, this includes the charger. When charging or operating, the switch must be slid up to the ON (connected) position.

This switch must be in the OFF position when transporting or shipping the motorcycle.



Power Pack

The battery is located within the power pack and requires no special break in period. Under normal use and correct power pack maintenance, the power pack should maintain most of its capacity for approximately 5 years, dependent on use.

The charging time is the same if connected to 110 V AC or 220 V AC; this is an input to the charger. The charger output will be the same.

The normal recharging time of the power pack is usually less than 4 hours in ambient temperatures. Out-of-the-normal temperature range charging and run-time times will vary. The power pack should not be used outside of the range of -7°C - 71°C (20°F - 160°F); the Battery Management System (BMS) will turn off the motor controller outside of this range.

It is recommended that you leave the motorcycle on the charger if you expect it to sit in storage or unused for over 7 days. The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged. Zero recommends you plug in your Zero motorcycle after 7 days, even if fully charged. Please leave your Zero motorcycle plugged in whenever possible.

The 6 digit serial number for the battery is located on a label on the top of the power pack.

Add On Electrical Equipment

WARNING: Do not add anything electrical to your motorcycle unless approved by your CSC. Some electrical components can damage your motorcycle. Some add on electrical equipment can keep other components from working as they should or can dramatically reduce the range and or life expectancy of the power pack.

Battery Management System (BMS)

Every power pack contains a Battery Management System (BMS) which monitors the condition of the cells and optimizes the charging process to provide the highest-performance, longest-range, and longest-life for the power pack.

The BMS also monitors the battery for a host of predefined conditions and then takes actions according to these conditions. Some of these conditions are listed below. Also see Understanding Beep Sequences on page 6-3.

Low Voltage

Action: When a low voltage is detected, the beeper is sounded to alert the rider that they should stop riding the motorcycle. This beeper beeps approximately once every 10-12 seconds when the motorcycle is being ridden and then once every minute when the motorcycle is inactive.

Dangerously Low Voltage

Action: If the voltage drops to the point that may damage the battery cells, the battery sends a signal to disable the motor controller and the motorcycle will not run until the voltage returns to an acceptable level.

• High or Low Temperature

Action: If the BMS senses that the power pack is too hot, above 71°C (160°F), or too cold, below - 7°C (20°F), it sends a signal to disable the motor controller and the motorcycle will not run until the temperature returns to an acceptable level. The charger will also be disabled in this condition.

High Voltage

Action: If the BMS detects a voltage that is too high, it shuts down the charger to prevent over-charging.

The BMS is sealed inside the power pack. As a rider, you don't need to think much about the BMS - it just silently does its job as you charge, ride, and store your motorcycle. There are only two things you might need to know about your Z-Force BMS:

Beep-Signals

The BMS will emit an "OK" beep-tone every time you turn-on your motorcycle. The BMS might also respond to other internal conditions and errors with different kinds of beeps. This section explains the different beep-patterns and their meanings.

Safety Interlocks

The BMS can disable the motorcycle's throttle-control if the power pack is fully discharged, or in case of other errors. The BMS can also disable charging under certain circumstances. The information below explains the different conditions which can cause the BMS to disable the throttle-control or the battery charger.

Beeps


The BMS includes an electronic beeper, sealed inside the power pack. The beeper is located on the upper front left corner of the power pack.

The BMS will beep under only two circumstances:

- When the motorcycle key switch is turned from "OFF" to "ON." When the motorcycle is turned ON, the BMS will perform a self-test. It will always sound a beep-signal when the test finishes. The beep-pattern reports the self-test result.
- When the key switch is "ON," and the power pack is nearly empty. The BMS will continuously sound a warning when the power pack is low. The warning will stop when the motorcycle is turned-off.

Battery Charger


When charging the motorcycle's power pack (battery) the charger (A) can be left ON, even after the battery is fully charged. There are two possible cases that can occur:



- When left on the charger the power pack will receive a full charge. Once fully charged, the charger will check the status of the power pack once every 72 hours to ensure that it maintains a full charge. When fully charged a green light will illuminate on the charger. Should the charger not read that the power pack is full, it will continue to attempt to fully charge the power pack. In this event the green light may not illuminate, however, the power pack may be fully charged. To ensure that the power pack is charged, check the energy gauge prior to riding.
- If the power pack terminates the charge before the charger reaches the state above, then the charger will continue to cycle and will top off the power pack until the power pack is removed or the charger reaches the complete state noted above.

Charger LED Indicators

Note: The charger must be plugged in for the charger's indicators to illuminate. See Battery Charger on pages 4-9 and 4-10 for location.




Ammeter (Amber)		Solid:	Displays approximate scale of current output during bulk phase. High internal charge temperature. Current output reduced.	
		Flashing:	Also displays algorithm #1-6 for 11 seconds if no power pack is connected.	
80% Charge	\(\)	Solid:	Bulk charge phase complete, 80% charged. In Absorption phase.	
(Amber)		Flashing:	With no power pack connected, indicates algorithm # selected by number of flashes.	
100% Charge	100% Charge		Charging complete. Charger in Maintenance Mode.	
(Green)		Flashing:	Absorption phase complete. In Finish phase.	
AC On	ſ	Solid:	AC Power good.	
(Amber)	L	Flashing:	Low AC Voltage, check voltage and extension cord length 7.6m (25 FT) 12 AWG	
Fault (Red)	VA	Flashing:	ng: Charger error. Reset charger power and see Troubleshooting Section 6.	

Power Pack LED Indicator Diagram

Charging The Power Pack

WARNING: Charge the Zero power pack with the Zero charger. It is possible for lithium ion cells to overheat and burst. It is recommended to charge in a location that is away from combustible materials and in a well ventilated area. Avoid outdoor charging of your Zero motorcycle in the rain.

- When the motorcycle's energy gauge is on the third or fourth bar when not under load, the power pack needs to be charged. Frequent top off charging is good for the power pack's life span, so do not hesitate to charge frequently.
- Ensure that the key switch is in the OFF position.
- Plug the supplied power cord (A) into the onboard charger connector. Always keep the power cord with the motorcycle.



4. Always connect the charger to a GROUNDED outlet. When using an extension cord, avoid excessive voltage drops by using a grounded, 3-wire, 12-AWG cord no longer than 7.6 m (25 ft). The charger can be used on 110 V AC or 220 V AC current. The voltage does not change the amount of time that the motorcycle takes to charge.

- AVOID connecting the Zero motorcycle charger and another device to a single 15A/20A or the circuit may become overloaded.
- Charging a fully discharged power pack takes about 4 hours.
- 7. Your power pack is equipped with an "Emergency Energy Reserve Beep." When your power pack makes an audible beep, it has only a few miles of range left. This beep tells you your power pack is dangerously low on energy and needs to be recharged immediately. Your power pack will continue to beep even when it's charging until it has recovered its "Emergency Energy Reserve."
- 8. When the power pack is fully charged, disconnect the power cord from the charger.

Operating Your Motorcycle

Starting

- With the brake applied, press the kill switch to the ON position.
- 2. Turn the key switch to the ON position.
- Verify that the energy gauge reads fully charged.
- 4. With the kickstand up, release the brake and twist the throttle toward you (counter-clockwise) to increase speed. When the throttle is twisted away from you (clockwise), the speed will decrease.

Braking

 On the right handlebar is the hand operated brake lever. The brake lever controls the front brake when the lever is squeezed. On the right lower side, next to the foot peg, is the foot operated brake lever. This lever controls the rear brake. When braking, the throttle should be in the neutral/returned position. The front and rear brake should be applied together, with a slight amount more of the braking on the front.

CAUTION: If you apply the front or rear brake hard enough, it is possible lock the wheels. This could cause you to lose control of the motorcycle. We suggest progressive use of the brakes to bring the Zero motorcycle to a complete stop without locking the wheels. Your Zero motorcycle is a light weight performance product and therefore practice is recommended to safely perfect emergency stops.

Stopping

- With the throttle in the neutral position and the brake applied, press the kill switch to the OFF position. This switch can also be used in an emergency to shut the motor off.
- Turn the key switch to the OFF position and remove the key. To prevent theft, the key should be removed anytime the motorcycle is left unattended.
- 3. Be sure to charge the power pack after each ride. See Charging The Power Pack on page 4-12.


Suspension Adjustment

Front Fork Adjustment


A shock has two main actions: compression when the shock gets compressed, and rebound when the shock returns back to full length. Compression damping is the adjustment that determines how fast or slow the fork compresses. Rebound damping is the adjustment that determines how fast or slow the fork rebounds.

- Bleed Screw The small Allen screw (A) at the top of the fork leg is the "bleed" screw. The bleed screw serves two purposes:
 - Transporting your motorcycle. See Transporting on page 1-11.
 - Bleeding the fork: Bleed the fork regularly, let any excess air out after each ride.

2. Rebound Damping - The rebound damping is adjusted by turning the slotted brass adjuster screw (B) on the top of both fork legs. Next to it will be the writing S-F, meaning Slow and Fast. The adjuster has 18 stages of adjustment. This determines how quickly the fork returns to its extended position after being compressed. Turning the rebound adjuster screw clockwise will slow the rebound speed down making it better for larger, rolling terrain or bumps. Turning the rebound adjuster screw counter-clockwise will increase the rebound speed making it better for smaller, rougher bumps. Adjust each fork leg evenly.



3. Compression Damping - The compression damping is adjusted by turning a screw on the bottom of each fork leg. There is a rubber dust cover protecting the screw and a jam nut (A) securing the screw (B). The adjuster has 12 stages of adjustment. Turn the adjuster clockwise for slower compression. To speed up compression, turn the adjuster counter-clockwise. Start with a middle setting and fine tune the compression from there. Proper compression will allow the tire to track the ground over consecutive bumps. Compression that is set too slow will pack-up (feel harsh over consecutive bumps) while compression that is set too fast will cause the fork to bottom out harshly. If the fork is bottoming out, turn the adjuster one click at a time until the bottom-out stops. Adjust each fork leg evenly. Replace the rubber dust cover after the adjustment.




Rear Shock Adjustment

Spring Adjustment:

Obtaining the correct rear spring rate is critical for proper handling. The spring rate must be set to match the weight of the rider. Heavier riders require stiffer spring rates. A good approximation of your rear spring requirements can be found by measuring the rear suspension's sag. This measurement will quickly determine if your rear spring is approximately correct for your weight. This adjustment is a recommendation guideline; personal riding preference may vary from the specifications given.


Checking Sag

- Support your motorcycle on a stand with the rear wheel off the ground.
- Measure vertically from the rear axle to the rear fender. Mark this spot as it will be used for other measurements.
- Record this measurement, this will be measurement M1.



- 4. Remove the motorcycle from the stand.
- 5. Wearing your normal riding apparel, sit on the motorcycle.
- 6. Have an assistant hold the motorcycle up, your feet should be on both pegs.
- Bounce the suspension a couple of times.

- Have a second assistant take a measurement using the same locations as in step 2.
- Record this measurement, this will be measurement M2.



10. Subtract the second measurement (M2) from the first measurement (M1).


Example:

M1		600 mm (23.6 in)
M2	-	500 mm (19.6 in)
Sag	II	100 mm (4 in)

If the total is between 90 to 100 mm (3.5 to 4.0 in), the sag is correct. If it is not within 90 to 100 mm (3.5 to 4.0 in), the spring pre-load should be adjusted. See Spring Pre-load Adjustment.

- Spring Pre-load Adjustment
 - 1. Clean any dirt or debris from the threads of the shock.
 - 2. Using a spanner wrench loosen the lock nut (A).
 - For measurements less than 90 mm (3.5 in), decrease the pre-load on the spring by turning the spring nut (B) counter-clockwise on the shock. If more than 100 mm (4.0 in), increase the pre-load on the spring by turning the spring nut (B) clockwise on the shock.
 - 4. Recheck the sag. If the sag is correct, tighten the lock nut (A).
- Rebound Adjustment The rebound adjuster knob
 (C) is at the bottom of the shock. It has 8 stages
 of adjustment. Printed on the knob is S-F,
 meaning Slow and Fast. The rebound adjuster
 knob controls how slow or fast the shock returns
 to its extended position after being compressed.
 Turning the knob clockwise, or S direction, is
 good for big impacts.

Turning the knob counter-clockwise, or F direction, is good for smaller and more frequent impacts.



NOTES			
4 20			

Maintaining Your Motorcycle

Owner's Responsibilities

- This owner's manual should be considered a permanent part of this motorcycle and should remain with it even if the motorcycle is subsequently sold.
- Perform routine care and maintenance of your electric motorcycle as detailed in this owner's manual.
- Use only genuine Zero approved parts and accessories.


- 4. The operator is responsible for learning and obeying all country, federal, state, and local laws governing the operations of an electric motorcycle.
- Always wear a DOT approved helmet, goggles, appropriate boots, and all other appropriate safety equipment when operating an electric motorcycle.

Bolt Torque Table


LOCATION	ITEM	TORQUE	NOTES	
А	Handlebar clamp mount bolts	13-15 N·m (10-11 lb ft)	Use LOCTITE® 242®*	
В	Shock mount bolts	13-15 N·m (10-11 lb ft)	Use anti-sieze lubricant	
С	Rear caliper mount bolts	11-13 N·m (8-10 lb ft)	Use LOCTITE® 242®*	
D	Fork pinch bolts	11-13 N·m (8-10 lb ft)	Use LOCTITE® 242®*	
E	Front axle pinch bolts 11-13 N·m (8-10 lb ft)		Lies LOCTITE® 242®*	
	Front axle end bolts	18-20 N·m (13-15 lb ft)	Use LOCTITE® 242®*	
F	Front caliper mount bolts	11-13 N·m (8-10 lb ft)	Use LOCTITE® 242®*	
G	Charger bolts	5-6 N·m (44-53 lb in)	Use LOCTITE® 242®*	
Н	Main pivot bolt/nut (swingarm)	105-110 N·m (77-81 lb ft)	Use LOCTITE® 270™*	
I	Rear axle pinch bolts	11-13 N·m (8-10 lb ft)	Use LOCTITE® 242®*	
J	Rear axle end bolts	18-20 N·m (13-15 lb ft)	Use LOCTITE® 242®*	
K	Triple tree pinch bolts	13-15 N·m (10-11 lb ft)	Use LOCTITE® 242®*	
L	Headlamp bolts	13-15 N·m (10-11 lb ft)	Use anti-sieze lubricant	
М	Motor mount bolts	30-32 N·m (22-24 lb ft)	Use anti-sieze lubricant	

^{*} or equivalent

See Bolt Torque Table on page 5-2.




See Bolt Torque Table on page 5-2.



5-4

See Bolt Torque Table on page 5-2.



Power Pack

WARNING: You must leave your motorcycle on the charger if you expect it to sit in storage or unused for over 7 days.

The power pack must be charged within 24 hours if fully discharged, and charged within 60 days if stored fully charged.

Zero recommends you plug in your Zero motorcycle after 7 days, even if fully charged. Please leave your Zero motorcycle plugged in whenever possible.

- The power pack is a lithium ion power system.
 While it does require charging, it does not require maintenance.
- The power pack should be kept away from excessive heat. The lithium ion cells should not get above 71°C (160°F). Do not store in a hot car or trailer, or leave the power pack in direct sunlight.
- Only an authorized service agent is qualified to have access to and troubleshoot the power pack.
- 4. Dispose of the power pack according to your state and local laws. It is encouraged that the power pack be recycled rather than disposed of in landfills. Locate a recycling center in your area. If one cannot be found, contact Zero at support@zeromotorcycles.com.

General Maintenance

Motor

CAUTION: Wear safety glasses when using compressed air to avoid eye injury.

The motor does not require much maintenance, but dust can collect inside the motor and can cause premature brush wear. If you ride in dusty conditions it is important to blow the dust out of the motor with compressed air. Do this only in a well ventilated area.


Brakes

Brake Fluid Level Inspection

WARNING: Do not spill brake fluid on painted or plastic surfaces, the finish could be damaged. Clean off any brake fluid spills immediately.

Low fluid levels may indicate worn brake pads or a leak in the hydraulic system. Inspect the brake pads for wear and or the hydraulic system for leaks. Use only new DOT 4 brake fluid from a sealed container.


Front Brake



Inspect the level of the front brake fluid through the sight glass (B). If the fluid level is visibly below the low level indicator (C), brake fluid must be added. Clean any dirt or debris from the cover (A) before opening the reservoir.

- Remove the two Phillips screws, securing the cover onto the reservoir.
- 2. Add new DOT 4 brake fluid.
- Inspect the cover seal, ensuring that it is free of any wear or damage and that it is positioned correctly.
- 4. Install the cover and tighten the Phillips screws.

Rear Brake




Inspect the level of the rear brake fluid by inspecting the level through the reservoir housing. If the fluid level is visibly below the low minimum "MIN" indicator (B), brake fluid must be added. Clean any dirt or debris from the cap opening (A) before

opening the reservoir. Unscrew the cap and add new DOT 4 brake fluid. Inspect the cap seal ensuring that it is free of any wear or damage then reinstall the cap.

Brake Pad Inspection

The brake pads must be inspected when specified in the maintenance schedule. See Maintenance Schedule on pages 5-20 through 5-22. Visually inspect the brakes by looking at the remaining brake pad material through the sides of the brake caliper. Replace the brake pads if either pad's thickness is 1.35 mm (0.05 in) or less. If the brake pads (A) are worn, replace both brake pads immediately.



Suspension

Front

For maintenance, see Maintenance Schedule on pages 5-20 through 5-22.

To adjust the fork, see Suspension Adjustment on page 4-15.

Rear

CAUTION: The shock absorber assembly contains highly pressurized gas.

- Do not attempt to tamper with or open the cylinder or shock.
- Do not subject the shock to high temperature or open flame.

Doing either of these can cause the cylinder or shock to explode causing personal injury or death.

For maintenance, see Maintenance Schedule on pages 5-20 through 5-22.

To adjust the shock, see Rear Shock Adjustment on page 4-17.

Wheels And Tires

Inspect both wheels for the following:

- Bent, loose, or missing spokes
- · Bent or cracked wheels
- Impact marks on the wheels

Inspect both tires for the following:

- Cuts, cracks, splits, missing tread lugs, or bruises in the tread or sidewall area
- · Bumps or bulges within the tire body
- Uneven tire tread wear. Wear on one side of the tire tread or flat spots in the tire tread indicate a problem with the tire or motorcycle.
- Exposed tire tread or cords

If either of the wheels or tires are found to have any of the above conditions, replace the wheel and tire immediately.

Tire Inflation

CAUTION: Under-inflation is the most common cause of tire failure and may result in severe tire cracking, tread separation, "blowout," or unexpected loss of motorcycle control causing personal injury and possible death.

Tire pressure should be checked and adjusted before each ride. Tire pressure is checked using an accurate gauge when the tires are cold. This means that the tires have not been ridden on for 3 hours. Always replace the valve stem cap when finished.

MODEL	FRONT	REAR
S	248 kpa (36 psi)	248 kpa (36 psi)
DS	220 kpa (32 psi)	220 kpa (32 psi)

Chain

Cleaning The Drive Chain

CAUTION:

- Wear safety glasses when cleaning the chain to prevent eye injuries.
- Never have the motor spinning the wheel. Turn the wheel only by hand. Failure to do so could result in serious personal injury.
- Never place your hand or any other body part between the chain and sprockets. Work with the chain only in the middle between the two sprockets. Failure to do so could result in serious personal injury.
- Do not allow any of the cleaner to get on the brake rotors or brake pads. If the rotors are contaminated with cleaner, it will impair the motorcycle's ability to stop. This could result in serious personal injury.

Follow the manufacturer's instructions for the chain cleaner you are using; below are the general guide-lines.

- 1. Remove the key from the key switch.
- Set the motorcycle on a stand or lift so the rear wheel is free to spin. While turning the wheel by HAND, spray the inside of your entire chain with a good coating of chain cleaner and let it sit for a few minutes.
- 3. Using a brush, fill the bristles with spray from the chain cleaner. Begin gently scrubbing the chain on the top of your swingarm using the brush.
- Do this for the entire length of the chain. Now do the same thing for the inside/bottom of the chain.
- 5. Using the brush, clean both sides of the rear sprocket. Let this soak for 5 minutes.
- Using a hose, rinse the entire chain and using a clean rag wipe any residual moisture from the chain.

Lubricating The Drive Chain

CAUTION:

- Wear safety glasses when lubricating the chain to prevent eye injuries.
- Never have the motor spinning the wheel. Turn the wheel only by hand. Failure to do so could result in serious personal injury.
- Never place your hand between the chain and sprockets. Work with the chain only in the middle between the two sprockets. Failure to do so could result in serious personal injury.
- Do not allow any of the lubricant to get on the brake rotors or brake pads. If the rotors are contaminated with lubricant, it will impair the motorcycle's ability to stop. This could result in serious personal injury.


Follow the manufacturer's instructions for the chain lubricant you are using; below are the general guidelines. Do not allow any of the lubricant to get on the brake rotor.

- Turn the wheel backwards slowly and spray the inside of the chain on the inside of the links.
- Turn the wheel backwards slowly and spray the outside of the chain on the outside of the links.

3. Let the motorcycle stand for 30 minutes to allow the lubricant to penetrate the link rollers.


Checking The Drive Chain

- 1. Remove the key from the key switch.
- 2. Using a ruler, grasp the chain halfway between the front and rear sprockets.
- The chain should move 16 mm (.63 in) in either direction, so 32 mm (1.25 in) of total free play.
- 4. If the chain's free play is not within specifications it will need to be adjusted. See the Drive Chain Adjustment Procedure on page 5-12.




Drive Chain Adjustment Procedure

- 1. Remove the key from the key switch.
- 2. Loosen both rear motor mount Allen bolts (A).



- 3. Loosen both front motor mount Allen bolts (B).
- Loosen the 13 mm jam nut (C) on the chain tensioner.
- 5. Turn the adjuster bolt (D) a 1/4 turn at a time until the chain free play is within specification.


- 6. Tighten all motor mount Allen bolts. See Bolt Torque Table on page 5-2.
- 7. Tighten the 13 mm jam nut on the chain tensioner. See Bolt Torque Table on page 5-2.
- 8. Test ride the motorcycle.
- 9. Recheck the chain for proper adjustment after the test ride and readjust if necessary.



Headlamp Alignment

The headlamp should be checked for correct alignment periodically. It must be aligned any time the sag is adjusted because this will affect the headlamp alignment. Before the headlamp can be aligned, the sag and tire pressure must be correctly adjusted. The headlamp can be adjusted horizontally and vertically. If the horizontal adjustment is off, the beam will point too far off to one side. If the vertical adjustment is off, it will cause the beam to point too close to or too far ahead of the motorcycle. With the headlamp on the low beam position, the motorcycle perpendicular to the ground, and the operator sitting on the motorcycle, verify the beam alignment.

To adjust the headlamp horizontally, turn screw (B) until the correct beam alignment is achieved. To adjust the headlamp vertically, loosen the housing screws (A). Move the housing up or down until the correct beam alignment is achieved. Tighten the screws. See Bolt Torque Table on page 5-2.




Headlamp Bulb Replacement


CAUTION: Halogen bulbs contain gas under pressure. Handling a bulb improperly could cause it to shatter into flying glass fragments. To help avoid personal injury:

- Turn off the key switch and allow the bulb to cool before changing the bulb.
- Leave the key switch OFF until the bulb change is complete.
- Always wear eye protection when changing a halogen bulb.
- Handle the bulb only by its base. Avoid touching the glass.


 Remove the two screws (A) from the headlamp housing.



2. Disconnect the main headlamp connector (A).



- Working with the headlamp on a bench, disconnect the headlamp bulb connector and cover.
- 4. Unhook the headlamp bulb spring clip (A) by (1) pushing down then (2) pushing to the side.
- 5. Lift up on the spring clip and remove the headlamp bulb.




WARNING: Do not touch the glass portion of the headlamp bulb. Keep the headlamp bulb free of contaminants. Oil from your fingers or contaminates will shorten the life of the bulb. Thoroughly clean any fingerprints or contaminates from the bulb using a clean cloth moistened with alcohol.

- 6. Install the headlamp bulb into the lens.
- 7. Install the headlamp spring clip.
- 8. Install the headlamp bulb cover; ensure that the arrow is pointing up.
- Connect both connectors and install the headlamp screws.


Turn Signal Bulb Replacement

- Remove the turn signal lens screw (A) and remove the lens.
- 2. Push in on the bulb, turn the bulb counterclockwise, and then pull the bulb out.
- 3. Insert the new bulb into the socket, push in and turn clockwise until it stops.
- Install the lens and screw; tighten the screw. Do not over-tighten the screw otherwise the lens may break.



Stop/Tail Lamp Bulb Replacement


 Remove the stop/tail lamp lens screws (A) and remove the lens.



- 2. Push in on the bulb and turn the bulb counterclockwise then pull the bulb out.
- 3. Insert the new bulb into the socket, push in and turn clockwise until it stops.
- Install the stop/tail lamp lens and screws; tighten the screws. Do not over-tighten the screws otherwise the lens may break.


Running Lamp Bulb Replacement

 Remove the two screws (A) from the headlamp housing.



2. Remove the bulb socket (A) from the headlamp using a rocking motion (see image on page 5-18).

- 3. Pull the old bulb out of the socket.
- 4. Push the new bulb into the socket and push the socket (A) into the headlamp.
- 5. Install the headlamp housing and screws.



Cleaning

To prolong the life of your motorcycle it should be washed periodically. Regular cleaning, using correct methods, is an important factor in maintaining the value of your motorcycle. It also ensures that safety-relevant parts remain in full working order.

CAUTION: After cleaning and before starting your journey, always test the brakes.

If tar, bugs, or other similar deposits have accumulated, wash them off as soon as possible. Do not use high pressure or steam cleaners; they can cause water intrusion of bearing, seals, and electrical components. Avoid spraying water of great force around the instrument panel. Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.

WARNING: Improper cleaning can damage electrical components, cowlings, panels, and other plastic parts. Use only a soft, clean cloth or sponge with mild detergent and water to clean plastic.

Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.

After gently washing the motorcycle, be sure to allow all of the electrical components to dry prior to operation. If the motorcycle is ridden immediately after being washed, apply both brakes several times in order to remove any moisture from the brake linings. Do not use products such as tire dressings on tires as this will deteriorate traction.

Parking And Long Term Storage

 It is recommended to always leave the power pack plugged in. The Zero S/DS charger is designed to maintain a balanced and complete charge at all times without wasting any electricity.

- 2. Over extended periods of time the power pack is checked every 72 hours to ensure that the cells are balanced and that the power pack is full. Once the power pack is "topped off" the charger stops charging and continues to monitor the power pack. This ensures that electricity is not wasted in maintaining an optimized power pack.
- To prolong the life of your power pack you should store your motorcycle in a cool area. Storing your motorcycle in a hot area will cause your power pack's life to be shortened.
- If, for some reason, your motorcycle was not plugged in for several days you should always charge it up before operation.

For more information on the power pack and the electrical system see Battery Management System (BMS) on page 4-8.

WARNING: Opening of the power packs is for trained Zero Motorcycles technicians. Please be aware that incorrect handling of a Zero battery can be dangerous. **DO NOT OPEN!**

Maintenance Schedule

The scheduled maintenance must be performed in accordance with this chart to keep the Zero S/DS motorcycle in top running condition. The initial maintenance is vitally important and must not be neglected. Where time and mileage are listed, follow the interval that occurs first.

NO.	ITEM	ROUTINE	EVERY	INITIAL	ODOMETER MILEAGE READINGS				
			RIDE	1,000 km (600 mi) or 1 month	7,000 km (4,000 mi) or 6 months	13,000 km (8,000 mi) or 12 months	19,000 km (12,000 mi) or 18 months	25,000 km (16,000 mi) or 24 months	31,000 km (20,000 mi) or 30 months
1	Front Brake	Check operation, and for fluid leakage. Replace brake pads if necessary.	✓	✓	✓	✓	✓	✓	✓
2	Rear Brake	Check operation, and for fluid leakage. Replace brake pads if necessary.	✓	✓	✓	✓	✓	✓	✓
3	Brake Hoses	Check for cracks or damage. Replace if necessary.	√		√	√	√	✓	✓
4	Wheels	Check runout and for damage. Replace if necessary.			✓	✓	✓	✓	✓
5	Tires	Check tread depth and for damage. Replace if necessary. Check air pressure. See page 5-9. Correct if necessary.	√		√	√	√	√	✓

NO.	ITEM	ROUTINE	EVERY RIDE	INITIAL ODOMETER MILEAGE READINGS					
				1,000 km (600 mi) or 1 month	7,000 km (4,000 mi) or 6 months	13,000 km (8,000 mi) or 12 months	19,000 km (12,000 mi) or 18 months	25,000 km (16,000 mi) or 24 months	31,000 km (20,000 mi) or 30 months
6	Wheel Bearings	Check bearings for smooth operation. Replace if necessary.			✓	✓	✓	✓	✓
7	Swingarm Pivot Bearings	 Check bearing assemblies for looseness. Moderately repack with lithium grease. Ensure main pivot bolt is properly torqued. See Bolt Torque Table on page 5-2. 				✓			
8	Drive Chain	 Check chain slack/alignment and condition. Adjust and lubricate chain with chain lubricant thoroughly. Replace worn chain. 	✓	Every 1,00 rain	very 1,000 km (600 mi) and after washing the motorcycle or riding in the n				
9	Steering Bearings	Check bearing assembly for looseness. Moderately repack with lithium grease every 25,000 km (16,000 mi) or 24 months.		√	>	√	>	Repack	√
10	Chassis Fasteners	Check all chassis fittings and fasteners. Correct if necessary.			✓	✓	√	✓	✓
11	Front Brake Lever Pivot Shaft	Apply lithium grease (all purpose grease) lightly.			✓	✓	✓	✓	✓

NO.	NO. ITEM ROUTINE EVERY IN RIDE		INITIAL	TIAL ODOMETER MILEAGE READINGS					
				1,000 km (600 mi) or 1 month	7,000 km (4,000 mi) or 6 months	13,000 km (8,000 mi) or 12 months	19,000 km (12,000 mi) or 18 months	25,000 km (16,000 mi) or 24 months	31,000 km (20,000 mi) or 30 months
12	Front Fork	Check operation and for oil leakage. Service/rebuild if necessary. Refer to the service manual for more information.	>		✓	√	✓	✓	✓
13	Rear Shock Absorber Assembly	Check operation and for oil leakage. Replace if necessary.	✓		✓	✓	✓	✓	✓
14	Throttle Grip	Check operation and free play.	✓		✓	✓	✓	✓	✓
15	Rear Brake Pedal Pivot Shaft	Apply lithium grease (all-purpose grease) lightly.			✓	✓	✓	✓	✓
16	Kickstand Pivots	Check operation. Apply lithium grease (all-purpose grease) lightly.			✓	✓	✓	✓	✓
17	Kickstand Switch	Check operation and replace if necessary.		√	√	√	√	√	√

NOTE: From 37,000 km (24,000 mi) or 36 months, repeat the maintenance intervals starting from 13,000 km (8,000 mi) or 12 months.

Parts/Maintenance Items

The proper replacement parts, fluids, and lubricants to use are listed in the chart below.

PART	NUMBER
Headlamp Bulb-55 watt	H4
Turn Signal Bulb	1156
Stop/Tail Lamp Bulb	1157
Front Running Lamp Bulb	194
Brake Fluid	DOT 4

Accessories

Zero accessories are designed to complement and function with other systems on your motorcycle. Your CSC can accessorize the motorcycle using genuine Zero accessories.


A full line of Parts, Accessories, and Apparel can be found on the Zero Motorcycles website.

Fuses

Whenever there is an excessive amount of current flowing through a circuit the fusible element will melt and create an open or incomplete circuit. Fuses are a one-time protection device and must be replaced each time the circuit is overloaded. Replace the fuse with one of equal current rating. If the fuse melts repeatedly, have the electrical system inspected by your CSC.


Fuse Center Location

The 12-volt fuse center is located behind the front fork. The fuse center has a protective cover that must first be removed to gain access to the fuses. To remove the cover, squeeze the tabs (A) together and lift off the cover.




Z-Force Power Pack Battery Fuses


The Z-Force power pack (A) has four MDA slow blow fuses. The fuses are located on the back of the power pack in front of the rear wheel. These fuses can be checked by removing the fuse and checking for continuity. A fuse that has no continuity is considered to be melted. Remove the fuse by pushing in on the plastic cap and turning counterclockwise. Install the fuse by pushing in and turning clockwise. For more information about the fuse label (B), see Power Pack Labels on page 2-5.



FUSE #	AMP	CIRCUITS CONTROLLED
Α	10	Headlamp, Flash-to-Pass
В	-	Not Used
С	10	Turn Signals, Horn
D	5	Instrument Panel, Tail/Stop Lamp

FUSE #	AMP	CIRCUITS CONTROLLED
1	10	Contactor (MDA)
2	20	DC Converter (MDA)
3	25	Charge Port
4	25	DC Converter Output





Follow the maintenance schedules on pages 5-20 through 5-22. After a scheduled service or routine is performed, record the information on the chart below.

DATE	ODOMETER MILEAGE READING	ITEM	SERVICE/ROUTINE DESCRIPTION

NOTES	
	5-27


NOTES			
E 20			

Troubleshooting

All of the motorcycles are carefully inspected before they are delivered. Even after the motorcycles are inspected, some technical issues can occur. The following information offers a guide to help you to identify an issue, and if possible, repair it yourself. If you are unable to solve an issue with your Zero S/DS electric motorcycle, take it to an authorized Certified Service Center (CSC) at your convenience. If there is no CSC in your area call Zero Motorcycles Customer Service.

Power Pack And Charger

If a fault occurs during charging, count the number of times the red light (A) flashes on the charger in between pauses. See the table on page 6-2 for the possible cause and solution to the issue.



NUM	MBER OF RED FLASHES	CAUSE	SOLUTION	
1	*	Power Pack High Voltage	Reset charger (interrupt AC power for 15 seconds).	
2	**	Power Pack Low Voltage	Reset charger (interrupt AC power for 15 seconds).	
3	***	Charge Timeout caused by power pack not reaching required voltage. Charger output was reduced due to high temperatures.	Check connections. Operate charger at a lower ambient temperature.	
4	***	Power pack could not be trickle charged up to minimum voltage.	Contact CSC.	
5	****	Over-Temperature: Charger shut down due to high internal temperature.	Ensure sufficient cooling air flow and reset charger (interrupt AC power for 15 seconds).	
6	****	Charger Internal Fault	Reset charger (interrupt AC power for 15 seconds). Contact CSC if fault persists.	

Understanding Beep Sequences

The Battery Management System (BMS) is located inside the power pack and is fitted with a beeper to provide audible notifications about the status of the power pack. Below you will find information on the meaning of the beep sequences.

PATTERN		WHEN	MEANING	SOLUTION
1 Short		Key-on	Self-Test Pass	BMS OK. Ready to ride!
1 Trill 2 Long		Key-on	Charger Still Plugged-In	Unplug charger & try again.
2 Long		Key-on	Power Pack Empty	Charge power pack before riding.
4 Long		Key-on	Too Hot	Let power pack cool down.
5 Long		Key-on	Power Pack Unbalanced	Leave on charger for 72 hours.
4 Short 1 Long		Riding	Low-Power Pack Warning	Charge soon.

Power Pack Empty

If the power pack is completely empty, an error-beep will sound and the BMS will disable the throttle. You cannot ride the motorcycle until you recharge the power pack. If the Power Pack Empty error-beep still sounds after two hours of charging time, contact your CSC. Your power pack may need to be repaired or replaced.

Too Hot

The power pack contains internal temperature sensors. If the BMS measures excessive internal temperatures, it will sound an error-beep and disable the throttle. You cannot ride the motorcycle until the power pack cools down. Place the motorcycle in a cool, well-ventilated location and wait a few minutes before riding again. If the Too Hot error-beep still sounds after the power pack has had time to cool down, contact your CSC. Your power pack may need to be repaired or replaced.

Power Pack Unbalanced

The power pack contains many individual cells. The BMS continuously monitors the cells and tries to keep them all "in balance" (at the same level-of-charge). If any of the cells are grossly out-of-balance, the BMS will sound a Power Pack Unbalanced error-beep and disable the throttle. You cannot ride the motorcycle until the problem is resolved.

The solution to the problem is to plug-in the charger and allow the power pack to charge for 72 hours. This will allow the BMS to re-balance the cells in the power pack. If the Power Pack Unbalanced error-beep still sounds after the power pack has spent more than 72 hours charging, contact your CSC. Your power pack may need to be repaired or replaced.

Low-Power Pack Warning

The BMS provides a low-power pack warning telling the operator that the remaining range is limited, and the power pack should be recharged soon. This is equivalent to a "low fuel" warning-light on a gasoline-powered vehicle. This beep-warning is different from the others because it can sound at any time when the motorcycle is on (the other warnings only sound when the key-switch is first turned ON).

The Low-Power Pack warning beep will sound continuously until either (1) the motorcycle is turned OFF, or (2) the throttle control is disabled for any reason, which includes the power pack being completely empty. The Low-Power Pack warning-beep will sound when you can still ride the motorcycle, but the remaining range is limited. It means: "Stop at a destination and charge-up."

The solution is to recharge the power pack. If the Low-Power Pack warning-beep still sounds after the power pack has charged for two hours, contact CSC. Your power pack may need to be repaired or replaced.

Other Error-Beep Patterns

If the BMS in your power pack produces an errorbeep which is not described in the Beep Patterns Table, then the power pack has encountered a serious internal hardware problem and must be repaired or replaced by a CSC.

BMS Appendix

There are other beeps which may occur under two circumstances that operators will normally never see. Unlike many electronic systems, the BMS essentially never "power cycles." A typical BMS is powered-on only once, in the factory, when it is connected to the wiring-harness inside the power pack. It may quite possibly operate continuously for years without ever being powered-down.

But on that one occasion when it is first powered-on, the BMS will perform a simple sanity check and report the result with a beep pattern. Note that this sanity check (and the resulting beep patterns) is different from the key on self-test. The sanity test (and the beeps) happens immediately when the board is first powered-up (connected to a power pack).

During service or maintenance, the BMS-board may be disconnected from and then reconnected to the power pack wiring harness. In those cases, the BMS will perform the sanity check (and result-beeps) every time it is plugged-in.

It is possible to encounter the sanity check result errorbeeps from a badly-malfunctioning or damaged power pack. If so, the user should return the power pack to Zero for repair or replacement.

Beep Patterns

	PATTERN	WHEN	MEANING
2 Short		Pwr-on M-cmd	Pass Sanity/ Mfg.test
3 Long		Pwr-on M-cmd	Fail Sanity/ Mfg.test

Safety Interlocks

If the BMS detects a serious internal fault, it can take either or both of two actions to prevent damage to the power pack:

- 1 Throttle-Disable The BMS will disable the throttle if the power pack is empty, or if the BMS detects certain serious internal problems. You cannot ride the motorcycle until the problem is resolved.
- 2 Charger-Disable The BMS will prevent charging if it detects certain serious internal problems - even if the power pack is connected to a charger and plugged-in to AC power. The power pack cannot be charged until the problem is resolved.

The Throttle-Disable Interlock

The BMS communicates with the main motorcycle-control module. The BMS can send a signal to the main motorcycle controller requesting that the throttle-control on the motorcycle be disabled. When the throttle-control is disabled, the motor will not deliver power to the rear wheel, and the motorcycle cannot be ridden.

If the throttle is disabled while riding, the motorcycle will cease to provide power, and the operator must pull over to a safe location.

All conditions which would cause the BMS to disable the throttle are also signaled by an error beep pattern at self-test. If you suspect that the BMS has disabled the throttle control on your motorcycle, turn the key switch OFF and back ON again to enter self test mode. The beep-pattern from the BMS will report any of the error-conditions which would cause the BMS to disable the throttle.

Each of these conditions, the associated self-test beep pattern, and the suggested remedies are discussed in Understanding Beep Sequences on page 6-3.

- Charger Still Plugged-In
- Power Pack Empty
- Too Hot
- Power Pack Unbalanced

The Charger-Disable Interlock

When the charger is attached and plugged-in to AC power, the BMS communicates with the charger. The BMS can send a signal to the charger requesting that charging terminates immediately. When the charger is disabled, the indicator-lights on the charger will show that charging has stopped.

There are two conditions that will cause the BMS to disable charging. One of these conditions is also reported by a self-test-result beep-pattern, the other is not.

Too Hot

If the BMS detects high internal power pack-temperatures, it will both disable the throttle and prevent charging. This condition is also reported by an error-beep pattern after BMS self-test when the motorcycle is turned-on. See Understanding Beep Sequences on page 6-3 for a description of the Too Hot error-beep and the solutions.

Power Pack Full (High Power Pack-Voltage)

If the BMS detects that the power pack is already full, it will disable further charging to prevent damage to the power pack.

This is not an error-condition; it is the result of a successful charging-cycle. There is no self-test error-beep which reports this condition.

During an ordinary charging cycle, when the cells are balanced, the charger (not the BMS) will sense that the power pack is full and terminate the charging-cycle with a "green light." The BMS does have a redundant back-up mechanism to prevent overcharging of the power pack. If the charger fails to terminate a charging-cycle when the power pack is full, the BMS will terminate charging itself to prevent damage.

Instrument Panel

Main Power Indicator

If a fault has been detected, count the number of times the green LED flashes. Refer to the tables on pages 6-9 and 6-10 for possible cause and solution to the issue.

	NUMBER OF GREEN FLASHES	CAUSE	SOLUTION
1	*	Motorcycle disabled due to kill switch or kickstand switch	Kill switch is in the OFF position. Press the kill switch ON button. Or, kickstand is down. Raise kickstand.
2	**	System startup failure	Board failed its power-on self test. Try power cycling the key switch.
3	***	High throttle disable	Throttle is ON or throttle/connection is bad. Verify throttle action and/or check connection.
4	***	Throttle out of range	Bad throttle or connections. Verify throttle action and/or check connection.
5	****	Motor temperature sensor not detected	Bad motor temperature sensor or connections. Replace temperature sensor and/or check connections.
6	****	Low voltage detected	Low power pack voltage or connections. Charge power pack and/or check connections.
7	****	Board is over-temperature	Board may have overheated. Let the motorcycle cool down.
8	****	Throttle enable from BMS is inactive	Low power pack, charger connected, bad connection between BMS and main motorcycle board. Charge power pack and/or check connections.

	NUMBER OF GREEN FLASHES	CAUSE	SOLUTION
9	**** ****	Precharge failure	Could not pre-charge motor controller. Contact CSC.
10	**** ****	Current sensor error	Problem with current sensor or connection. Contact CSC.
11	**** *****	Board temperature sensor error	Problem sensing temperature of board. Contact CSC.
12	*****	Unknown system error	Contact Zero or CSC.

General Troubleshooting

SYMPTOM	POTENTIAL CAUSE	POTENTIAL SOLUTION
Motorcycle does not turn on	Power Pack not charged Key not properly engaged Main power cut-off not engaged Kill Switch turned off	Charge Power Pack. Recheck key in ignition, turn OFF/ON again. Move the main power cut-off to the UP/ON position. Press the Kill Switch "ON" button.
Charger not working	A/C power missing Main power cut-off engaged	Check A/C outlet for power, A/C source check fuse/voltage. Move the main power cut-off to the UP/ON position.
	Incorrect tire pressure	Inflate to correct tire pressure. See page 5-9.
Handlebars wobbly (shimmy)	Deformed front tire	Replace/balance front tire with the same tire supplied from the factory.
	Bald tire (excess wear)	Replace/balance tire with the same tire supplied from the factory.

NOTES			
6-12	 		

Warranty/Customer Assistance

Customer Assistance

Zero Motorcycles Inc. can be contacted via the contact methods listed below. Please have available the following, as it is essential to effectively and efficiently answer your questions or resolve your concerns.

- Owner's name and address
- Owner's telephone number
- Vehicle identification number (VIN)
- Date of purchase
- Battery serial number

An owner information chart is provided on page 1-3 to record this information.

Zero Motorcycles 1 Victor Square Scotts Valley, California 95066 USA Phone: (888) 786-9376 Monday-Friday 8am to 5pm Pacific Time

E-mail: support@zeromotorcycles.com 24 hours

Warranty Information

LIMITED WARRANTY COVERAGE					
MOTORCYCLE	STAI	NDARD	EXTENDED (Replaces 2nd Year	NO FAULT (Replacement Parts are 50% of Retail Cost Unless Noted)	
PARTS COVERED	First Year	Second Year (Excluding Shipping and Labor)	of the Standard Warranty)		
Motor	✓	✓	✓	✓ (35% Discount)	
Controller	✓	✓	✓	✓	
Power Pack	✓	✓	✓	√ (20% Discount)	
Fork	✓	✓	✓	✓	
Rear Shock	✓	✓	✓	✓	
Frame	✓	✓	✓	✓	
Swingarm	✓	✓	✓	✓	
Brake Assemblies	✓	✓	✓	✓	
Electrical	✓	✓	✓	✓	
Wheels	√ *	*	√ *	√ *	

^{*} No warranty on dirt bike wheels once ridden.

Zero Motorcycles Limited Warranties

Zero Motorcycles Inc. expressly warrants all Zero manufactured products from defects in material and workmanship to the original owner under normal operating conditions and according to proper use for 2 years from the date of delivery.

These warranties are transferrable subject to a \$50 processing fee and a new registration card to subsequent owners.

Standard Warranty:

The first year of this standard limited warranty covers parts, standard shipping and labor for all major components, defined herein as including the motor, motor controller, power pack, frame, swing arm, fork, rear shock, brake assemblies, wheels, and electrical sub-assemblies.

This warranty covers Zero manufactured accessories installed at the time of purchase.

The second year of this standard limited warranty covers parts only for these same major components.

Standard Warranty Exclusions:

This warranty does not apply to tire wear, chain or sprocket condition, brake pads or rotors, fork seals, grips, foot pegs, the seat, or any other parts subject to normal wear and tear. Wheels are excluded from this standard warranty on off-road bikes once they have been ridden.

This standard warranty excludes aftermarket accessory kits which may be subject to their own warranties.

This standard warranty excludes parts and components damaged by use or operation under abnormal circumstances or contrary to the requirements described in the owner's manual, or damaged by improper use or accidents.

Racing or competitive use voids this warranty.

Modifications or alterations to major components of the manufacturer's original product or its subcomponents void all warranties. Zero Motorcycles Inc. assumes no liability for any misuse or improper operation of Zero motorcycles. Under this limited warranty and liability agreement, Zero Motorcycles Inc. shall have no obligation and the purchaser shall have no remedy against Zero Motorcycles Inc. and its officers and/or agents for any damages, including but not limited to incidental, consequential, special, punitive damages arising from direct or indirect injury to person or property, or any other loss, whether or not occasioned by negligence or otherwise on the part of Zero Motorcycles Inc.

Extended Warranty:

The extended warranty is available for purchase by the original owner within 90 days of the date of delivery of the covered product. This adds to the standard warranty by covering shipping and labor for the 2nd year of ownership.

Extended Warranty Exclusions:

This warranty does not apply to tire wear, chain or sprocket condition, brake pads or rotors, fork seals, grips, foot pegs, the seat, or any other parts subject to normal wear and tear. Wheels are excluded from this extended warranty on off-road bikes once they have been ridden.

This extended warranty excludes aftermarket accessory kits which may be subject to their own warranties.

This extended warranty excludes parts and components damaged by use or operation under abnormal circumstances or contrary to the requirements described in the owner's manual or damaged by improper use or accidents.

Racing or competitive use voids this warranty.

Modifications or alterations to major components of the manufacturer's original product or its subcomponents void all warranties. Zero Motorcycles Inc. assumes no liability for any misuse or improper operation of Zero motorcycles.

Under this limited warranty and liability agreement, Zero Motorcycles Inc. shall have no obligation and the purchaser shall have no remedy against Zero Motorcycles Inc. and its officers and/or agents for any damages, including but not limited to incidental, consequential, special, punitive damages arising from direct or indirect injury to person or property, or any other loss, whether or not occasioned by negligence or otherwise on the part of Zero Motorcycles Inc.

No Fault Warranty:

The "No Fault" warranty option is available within the first 90 days from date of delivery of the covered product. It applies to the same two year period as the standard warranty but adds additional coverage allowing for the replacement of *any* parts that need to be replaced for *any* reason at a 35% discount from retail cost for motors, a 20% discount from retail cost for Power Packs and a 50% discount from retail cost for all other parts.

For the purposes of this No Fault warranty, "No Fault" means that regardless of how the part or component may have been damaged or rendered unusable (fully or partially) by the owner or authorized user of the product, Zero will provide replacement parts at the appropriate discount without questions being asked.

This warranty also covers Zero manufactured accessories installed at the time of purchase.

No Fault Warranty Exclusions:

Accessory kits include their own warranties and are not included in this no fault coverage.

Modifications or alterations to major components of the manufacturer's original product or its subcomponents void all warranties including this no fault coverage. Zero Motorcycles Inc. assumes no liability for any misuse or improper operation of Zero motorcycles.

Under this limited warranty and liability agreement, Zero Motorcycles Inc. shall have no obligation and the purchaser shall have no remedy against Zero Motorcycles Inc. and its officers and/or agents for any damages, including but not limited to incidental, consequential, special, punitive damages arising from direct or indirect injury to person or property, or any other loss, whether or not occasioned by negligence or otherwise on the part of Zero Motorcycles Inc.

Disclaimers Applicable to Standard Warranty, Extended Warranty and No Fault Warranty:

The purchaser acknowledges that there is an inherent risk in the operation of Zero motorcycles and all other Zero Motorcycles Inc. products, and herewith assumes liability for any injury arising from all operation of any Zero Motorcycles Inc. product.

The original registered owner or subsequent registered transferee as documented on the Zero Motorcycle warranty registration form will indemnify and hold Zero Motorcycles Inc. harmless and take full responsibility for conveying all safety warnings, instructions and limited warranty if the unit is sold, loaned or otherwise transferred to other persons, and will indemnify Zero Motorcycles Inc. from any claims against it for original owner's failure to do so.

Zero Motorcycles Inc. does not assume or authorize anyone to assume for them any other obligation. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Zero Motorcycles Inc. assumes no responsibility for incidental, consequential or other damages including but not limited to: expense of returning the Zero product to a certified service center, expense of delivering it back to the owner, mechanic's travel, time, communication charges, rental of a like product during the time the warranty service is being preformed, travel, loss or damage to personal property, loss of revenue, loss of use of the product, loss of time, or inconvenience. Some states do not allow the exclusion or limitation of incidental or

consequential damages, so the above limitation or exclusion may not apply to you.

Zero Motorcycles Inc. reserves the right to change or improve the design of any electric motorcycle product without assuming any obligation to modify any product previously manufactured.

These warranties give you specific legal rights, and you also have other rights, which vary from state to state and country to country. These warranties apply to all Zero Products manufactured by Zero Motorcycles Inc.

Normal operating conditions *require routine care and maintenance by the purchaser* of the Zero Motorcycles Inc. electric motorcycle and power pack.

Proper Use:

For the purposes of these warranties, 'proper use' means only the use of a motorcycle in the manner intended for a single rider with proper safety equipment as described in the Owner's Manual on safe and dry surfaces in accordance with local regulations. "Proper use" also means charging the

Power Pack after each use and storing it in a fully charged state, or recharging it every 7 days, or keeping it on the charger when in storage or out of regular use.

Purchaser's Responsibilities:

Read and understand the Owner's Manual and all product warnings before operating your Zero Motorcycles Inc. electric motorcycle. Serious injury or death may result from improper operation or failure to observe warnings and safety instructions on any motorized motorcycle or vehicle.

Submit the warranty registration card for your Zero Motorcycle within the required time period as printed on the registration card.

Perform routine care and maintenance of your Zero Motorcycles Inc. electric motorcycle and power pack as detailed in the Owner's Manual.

The rider is responsible for learning and obeying all federal, state, and local laws governing the operations of an electric motorcycle.

Always wear a helmet, knee and elbow guards, goggles, appropriate boots and all other appropriate safety equipment when operating a motorcycle.

Warranty Procedures:

Warranty services may be obtained by contacting Zero Motorcycles Inc. at (888) 786-9376 or via e-mail at support@zeromotorcycles.com.

Service may also be available from a local Zero Motorcycles Certified Service Center please see the locator on www.zeromotorcycles.com for the nearest location.

In any written or telephonic communication, please state the specific nature of and any circumstances leading to the problem. A service technician will contact you with specific instructions to ensure that you receive the best service for your motorcycle.

Zero Motorcycles 1 Victor Square Scotts Valley, CA 95066 USA 88-01902-00

(U.S. and International Patents and Trademarks Pending)

Transfer Of Ownership And Warranty

When it comes time to sell your Zero motorcycle, please visit the Zero Motorcycles website and access the Owner Resources section to fill out the on-line transfer of ownership and warranty form. This must be performed to allow Zero Motorcycles the ability to contact the new owner in the unlikely event of a safety related issue. Use the URL address below or feel free to contact the Zero Motorcycles Customer Service department for assistance.

Phone: (888) 786-9376 Monday-Friday 8am to 5pm Pacific Time

E-mail: support@zeromotorcycles.com
24 hours

http://www.zeromotorcycles.com/owner-resources/

NOTES	
	7.

NOTES			
7-10			

INDEX

A	Brake Pad Inspection	5-7
Accessories5-23	Brakes	
Add On Electrical Equipment4-7	Brake Fluid Level Inspection	
An Important Message To You From Zero1-1	Brake Pad Inspection	
	Front Brake	
В	Rear Brake	
Battery Charger 4-9	Braking	4-14
Battery Management System (BMS)4-8		
Beep-Signals4-8	C	
Dangerously Low Voltage4-8	Chain	5-10
High or Low Temperature4-8	Checking The Drive Chain	
High Voltage4-8	Cleaning The Drive Chain	
Low Voltage4-8	Drive Chain Adjustment Procedure	
Safety Interlocks4-9	Lubricating The Drive Chain	
Beep Patterns6-6	Charger LED Indicators	
Beep-Signals4-8	Charger-Disable	6-6
Beeps4-9	Charging The Power Pack	
BMS Appendix6-5	Checking The Drive Chain	
Bolt Torque Table5-2	Cleaning	
Brake Fluid Level Inspection 5-6	Cleaning The Drive Chain	

Controls And Components3-1	Fuse Center Location	5-24
Customer Assistance	Fuses	5-23
D	G	
Dangerously Low Voltage4-8	General Information	
Disclaimers Applicable to Standard	General Maintenance	
Warranty, Extended Warranty and	Brakes	5-6
No Fault Warranty7-5	Chain	
Drive Chain4-4	Headlamp Alignment	5-13
Drive Chain Adjustment Procedure5-12	Headlamp Bulb Replacement	
•	Maintenance Schedule	5-20
E	Motor	
Electrical System4-4	Parking And Long Term Storage	5-19
Emissions Information1-10	Running Lamp Bulb Replacement	5-17
Extended Warranty7-4	Stop/Tail Lamp Bulb Replacement	
Extended Warranty	Suspension	5-8
F	Tire Inflation	5-9
	Turn Signal Bulb Replacement	5-16
First Time Set-Up	Wheels And Tires	
Fork Lock	General Operation	4-4
Front Brake		
Front Fork Adjustment4-15		

Brakes 4-4	L	
Drive Chain4-4	Left Side View	3-3
Electrical System4-4	Limited Warranties	
Power Pack4-4	Location Of Important Labels	
Throttle4-4	Main Power Cut-Off Label	
Tires4-4	Power Pack (Battery) Fuse Label	2-6
General Safety Precautions2-1	Power Pack Information Label	
General Troubleshooting6-11	Power Pack Labels	2-5
	Throttle And Speed Control Label	
Н	Low-Power Pack Warning	6-4
Handlebar Controls3-9	Lubricating The Drive Chain	5-11
Headlamp Alignment5-13		
Headlamp Bulb Replacement5-14	M	
	Main Power Cut-Off	4-6
I	Main Power Cut-Off Label	2-6
Indicators2-8	Maintaining Your Motorcycle	5-1
Instrument Panel3-7	Maintenance Schedule	5-20
Introduction1-1	Motor	5-6
	Motorcycle Controls	3-1
K		
Key Switch Positions	N	
10y 3mon 1 3shons	No Fault Warranty	7-5

Operating Information 2-2 Power Pack Empty 6 Operating Your Motorcycle 4-14 Power Pack Full (High Power Pack-Voltage) 6 Braking 4-14 Power Pack Information Label 2 Starting 4-14 Pre-Ride Inspection 2 Stopping 4-14 Power Pack Proper Use 7 Optimizing Your Range By Adapting Your Riding Style 1-9 Public Charging Stations 1-9
Operating Your Motorcycle 4-14 Power Pack Full (High Power Pack-Voltage) 6 Braking 4-14 Power Pack Information Label 7 Starting 4-14 Pre-Ride Inspection 7 Stopping 4-14 Power Pack Information Label 7 Proper Use 7 Public Charging Stations 7 Public Charging Stations 7 Power Pack Full (High Power Pack-Voltage) 7 Proper Use 7 Public Charging Stations 7
Braking
Starting 4-14 Pre-Ride Inspection 4-14 Power Pack Proper Use 7 Riding Style 1-9 Public Charging Stations 1-19
Stopping
Optimizing Your Range By Adapting Your Proper Use
Riding Style1-9 Public Charging Stations1
Trianing Otylo
Owner Information
Owner's Responsibilities5-1
R
P Rear Brake
- Parking And Long Term Storage5-19 Rear Shock Adjustment4-
Parts/Maintenance Items
Performance Envelope2-7 Running Lamp Bulb Replacement5-
Performance Specifications/Operation Guidelines 2-7
Power Pack
5 1 (5) 5 1 1 1
Caloty Information
Caroty interiorio
Oil E B B i
Other Error-Beep Patterns6-5 Starting4- Power Pack Empty6-4
Power Pack Unbalanced6-4

Starting And Operating	4-1	U	
Stop/Tail Lamp Bulb Replacement	5-16	Uncrating Your Motorcycle	4-2
Stopping	4-14	Understanding Beep Sequences	
Suspension	5-8		
Front	5-8	V	
Rear	5-8	•	4
Suspension Adjustment	4-15	Vehicle Identification Number(VIN)	
Front Fork Adjustment	4-15	VIN Break Down	
Rear Shock Adjustment		VIN Location	
System Error Indicator	2-8	Vehicle Range	1-9
т		W	
Technical Specifications	1-6	Warranty	7-3
Zero DS Technical Specifications		Disclaimers	7-5
Zero S Technical Specifications		No Fault Warranty	7-
Throttle And Speed Control Label		Standard Warranty	
Throttle-Disable		Transfer Of Ownership And Warranty	7-8
Tire Inflation		Warranty Information	7-2
Tires		Warranty Procedures	7-7
Transfer Of Ownership And Warranty		Warranty/Customer Assistance	
Transporting		Wheels And Tires	
Troubleshooting			
Turn Signal Bulb Replacement			
TUITI SIUTIAL DUID KEDIACETTIETIL	3-10		

Z

Z-Force Air Induction	System	2-7
Z-Force Power Pack	Battery Fuses5	-24
Zero Motorcycles Lin	nited Warranties	7-3

WWW.ZEROMOTORCYCLES.COM