


QJ RX8 ENGINE PARTS LIST


CYLINDER HEAD ASSY

NO	CODE	DESCRIPTION	QTY
1	30701B01F000	HEAD , CYLINDER	1
2	30507B01F000	GASKET , CYLINDER HEAD	1
3	30506G02F000	SPEAK PLUG	1
4	27101B01FF10	CYLINDER	1
5	27102B01F000	GASKET , CYLINDER	1
6	26107B01F910	STUD BOLT	4
7	26127G02F910	NUT	4



CRANKCASE ASSY


NO	CODE	DESCRIPTION	QTY
1	26111B09F000	CRANKCASE,LH	1
2	26108B09F000	GROMMET	1
3	B12016600350	BEARING	1
4	26211B09F000	CRANKCASE,RH	1
5	B12016600350	BEARING	1
6	26208G02F000	DOWEL PIN	2
7	B01070603564	PAN HEAD SCREW	9
8	26109B09F000	AXLE,engine mount	1
9	B08010001700	CIRCLIP	2
10	14109B09F000	GASKET,L CRANKCASE	1
11	14108B09F000	L CRANKCASE COVER	1
12	14133G02F000	IDLE GEAR	1
13	26123G02F000	DOWEL PIN	2
14	B01070602564	PAN HEAD SCREW	8
15	B01070603564	PAN HEAD SCREW	2
16	B01070606564	PAN HEAD SCREW	1
17	26202B09F000	OIL PLUG	1
18	26209G02F000	O RING	1




19	26121G02F000	FLANGE BOLT	1
20	26124G02F000	PLATE WASHER	1
21	26214G02F910	OIL SEAL HOLDER	1
22	B02000601263	PAN HEAD SCREW	1
23	26201G02F000	GASKET	1
24	B02000601224	PAN HEAD SCREW	2
25	15211B09F000	DRIVER SHAFT	1
26	B07030000600	PLATE WASHER	1
27	B02000601063	PAN HEAD SCREW	1
28	B12016620250	BEARING	1
29	B08010001700	CIRCLIP	1
30	18100B09F000	MISSION CASE GASKET	1
31	18101B09F000	MISSION CASE	1
32	B01070603562	SCREW M8X35	2
33	B01070605562	SCREW M8X55	5
34	18110B09F000	BRAKE SHOE ANCHOR PIN	1
35	B12016600450	BEARING	1
36	18114B09F000	NUT	1
37	26129B09F000	OIL SEAL	1
38	B12016620050	BEARING	1
39	26123B09F000	DOWEL PIN	2

PISTON CRANKSHAFT CONNECTING ROD ASSY

NO	CODE	DESCRIPTION	QTY
1	15200B01F000	CRANKCHAFT , ASSY	1
2	15201B01F000	CRANKSHAFT , LH	1
3	15202B01F000	CRANK PIN	1
4	15114B01F000	NEEDLE BEARING	1
5	15204B01F000	SONNECTING SHAFT	1
6	15205B01F000	CRANKSHAFT , RH	1
7	15101B01F000	WOODRUFF KEY	1
8	B12016620453	NEEDLE BEATRING	2
9	15213G02F000	OIL SEAL	1




10	26215G02F000	OIL SEAL ASSY	1
11	15214G02F930	COLLAR	1
12	15100B09FF10	PISTON ASSY	1
	15100B09FF20		
	15100B09FF30		
13	15105B01F000	PISTON PIN	1
14	15103B09F000	PISTON RING ASSY	1
15	15111B01F930	CIRCLIP	2
16	15110B01F000	NEEDLE BEARING	1



OIL PUMP ASSY

NO	CODE	DESCRIPTION	QTY
1	19000B09F000	OIL PUMP ASSY	1
2	B02000400623	NUT	1
3	19202G02F000	WASHER	1
4	19214B01F000	O-RING	1
5	19210G02F000	GEAR	1
6	B09030301200	PIN	1
7	B08030000800	CIRCLIP	1
8	19212B09F000	HOSE	1
9	19213G02F000	HOSE CLIP	2
10	19216G02F000	HOSE	1
11	19217G02F000	HOSE CLIP	1
12	19215G02F000	CLIP	1
13	B02000300823	SCREW	2
14	15211G02F000	PUMP DRIVE GEAR	1
15	B090103014C0	PIN	1
16	15106G02F910	CIRCLIP	2




MAGNETO ASSY

NO	CODE	DESCRIPTION	QTY
----	------	-------------	-----




1	34310G02F000	STATOR ASSY	1
2	34311B09F000	COIL GROUP	1
3	34330G02F000	PULSE TRIGGER	1
4	34350G02F000	OIL SEAT	1
5	B02000502522	SCREW	1
6	B02000501262	SCREW	2
7	B02000401622	SCREW	2
8	B07000000400	WASHER	1
9	34301B09F000	ROTOR ASSY	1
10	B07030001200	WASHER	1
11	B04011212582	NUT	1
12	B02000601622	NUT	2



KICK STARTER ASSY

NO	CODE	DESCRIPTION	QTY
1	34120G02F000	START GEAR ASSY	1
2	34121G02F000	NEEDLE BEARING	1
3	34123G02F000	THRUST WASHER	1
4	34400G02F000	START CLUTCH ASSY	1
5	34126G02F000	IDLE GEAR	1
6	34127G02F000	IDLE GEAR SHAFT	1
7	34122G02F000	PLATE WASHER	2
8	34125G02F000	IDLE GEAR HOLDER	1
9	B02000601022	SCREW	2
10	B02000602022	SCREW	2
11	17400B09F000	SHAFT, kick starter	1
12	17407G02F000	SPRING	1
13	17413G02F000	BUSH	1
14	17422B09F000	WASHER ,kick starter	1
15	B08010001500	CIRCLIP	1
16	17415B09F000	KICK PINION ASSY	1
17	17418G02F930	CLIP	1




U270

18	34200B09F000	STARTING MOTOR ASSY	1
19	34254G02F000	O-RING	1


CLUTCH ASSY

NO	CODE	DESCRIPTION	QTY
17	24104G02F000	DAMPER	3
18	24105G02F000	COLLER	1
19	24106G02F000	WASHER	1
20	24107B09F000	V BELT , DRIVE	1
21	24108B09F000	FACE , FIXED DRIVE	1
22	24109G02F000	PLATE , WOODRUFF KEY	1
23	24110G02F000	STARTING DISC	1
24	15112G02F010	WASHER , SPRING	1
25	B04011212551	NUT	1
26	24204G02F000	FACE , FIXED DRIVEN	1
27	24205G02F000	FACE , MOVABLE DRIVEN	1
28	24206G02F000	OIL SEAL	1
29	24207G02F000	O-RING	2
30	24208G02F000	PIN , GUIDE	2
31	24308B01F000	SPRING	1
32	24309G02F930	SEAT , SPRING	1
33	24106B09F000	WASHER	1




CLUTCH ASSY

NO	CODE	DESCRIPTION	QTY
1	24201B09F000	PRIMARY DRIVE GEAR	1
2	17508G02F910	WASHER	1
3	B02010601062	SCREW	1
4	B08010001700	CIRCLIP	1
5	B12016620305	ROLING BEARING	1
6	24203G02F000	OIL SEAL	1




7	24301G02F000	CLUTCH ASSY,shoe	3
8	24302G02F000	SPRING	3
9	24303G02F000	NUT	1
10	24700G02F000	HOUSING	1
11	24305G02F940	NUT	1
12	24303G02F000	O-RING	3
13	24209G02F000	BEARING	3
14	24101B09F000	FACE,movable drive	1
15	24102B09F000	ROLLER	6
16	24103G02F000	PLATE,movable drive	1




TRANSMISSION SYSTEM ASSY

NO	CODE	DESCRIPTION	QTY
1	17800B09F000	SHAFT , IDLE	1
2	B12016620050	BEARING 201	1
3	17509B09F000	PLATE WASHER12	1
4	17802B09F000	WASHER , thrust	1
5	17300B09F000	SHAFT , REAR BOX	1
6	B12016600450	NEEDLE BEARING	1
7	17317B09F000	OIL SEAL	1




REED VALVE ASSY

NO	CODE	DESCRIPTION	QTY
1	32300B09F000	REED VALVE ASSY	1
2	32320G02F000	REED VALVE	2
3	32330B09F000	REED VALVE STOPPER	2
4	B02010200862	SCREW	4
5	B07050000400	WASHER	4
6	32312G02F000	VALVE SEAT GASKET	1




AIR COOLING SYSTEM

NO	CODE	DESCRIPTION	QTY
1	20301B01FT10	COWLING,cylinder	1
2	20303G02F000	GROMMET	2
3	20201B01FT10	COELING,fan	1
4	B02000602023	BOLT	2
5	B05035504000	SCREW	1
6	20401G02F000	FAN ASSY	1
7	20402G02F000	RUBBER RING	1
8	B02000601523	SCREW	3
9	B07000000600	WASHER	3
10	B07030000600	WASHER	3
11	20102G02F000	PLATE	1
12	20206G02F000	MOLD,cowling	1
13	20208B09FT10	COLLOR	3
14	20209B09FT10	COVER	1
15	B02040403523	SCREW	3
16	20208G02F000	MOLD,cowling	1



CARBURETORASSY

NO	CODE	DESCRIPTION	QTY
1	32501B01F910	FIX SCREW	1
2	32502B01F910	INSTRANT PIPE	1
3	32503B01F223	SCREW	2
4	B07000000400	WASHER	2
5	32505B01F000	CAP	1
6	32506B01F000	GASKET	1
7	32507B01F000	SPRING , return	1
8	32508B01F000	CLIPMM,V shape	1
9	B08030001500	CLIP	1
10	32510B01F000	NEEDLE, jet	1
11	32511B01F000	VALVE,PISTON	1
12	32601B01F000	SCREW, idle speed	1
13	32602B01F000	SPRING, speed screw	1
14	32603B01F000	WASHER, speed screw	1



15	32604B01F000	O RING, speed screw	1
16	32605B01F000	SCREW, air	1
17	32606B01F000	SPRING, air screw	1
18	32607B01F000	WASHER, air screw	1
19	32608B01F000	O RING, air screw	1
20	32609B01F000	JET, idle	1
21	32610B01F000	JET, main	1
22	32611B01F000	JET, needle	1
23	32612B01F000	THERMO ASSY	1
24	B02040400823	SCREW	2
25	B07000000400	WASHER	2
26	32615B01F000	O RING	1
27	32616B01F000	BODY, carburetor	1
28	32617B01F000	VALVE, needle	1
29	32618B01F000	HOOK	1
30	32619B01F000	PIN, float	1
31	32620B01F000	FLOAT	1
32	32701B01F000	GASKET	1
33	32702B01F000	CHAMBER, float	1
34	32703B01F000	SCREW	1
35	B07000000400	WADHER	1
36	B02040401423	SCREW	1
37	32706B01F000	CLIP	1
38	32707B01F000	HOSE, drain	1
39	B02050602083	SCREW	3
40	32200B01F000	PIPE, intake	1
41	32303B01F000	GASKET	1
42	32202B01F000	CLIP	1
43	32206B01F000	SCREW	1

